

10 ft. Extendable Tree Saw (1002) - UH Staglon 4" FB w/Leather Box

- Full Tang
- 7Cr17MoV steel with 4.25" blade length and weighs 5.3 oz
- Next Gen staglon handle with satin blade finish and nickel silver finger guard
- Leather lanyard strap and lanyard hole
- Leather sheath

NO IMAGE
AVAILABLE

Attributes

- Name: UH Staglon 4" FB w/Leather Box
- Manufacturer: Uncle Herry
- Product no.: EU1000423
- Mfr. No.: 1100034
- Color: Green/Black
- Delivery weight: 1.542kg
- Shipping height: 79mm
- Shipping width: 192mm
- Shipping length: 794mm
- UPC: 661120075868

Table of Contents

- [Startpage](#)
- [English: Uncle Herry 10 ft. Extendable Tree Saw Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Herry 10 ft. Extendable Tree Saw \(1002\)](#)

Uncle Herny 10 ft. Extendable Tree Saw Safety Instructions

Introduction

Thank you for choosing the Uncle Herny 10 ft. Extendable Tree Saw. This safety instruction guide is designed to help you use this product safely and effectively, in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the tree saw.

General Safety Guidelines

- Always ensure that the product is used in accordance with the instructions provided in this manual.
- Keep the tree saw out of reach of children and vulnerable individuals.
- Inspect the tree saw for any damage or wear before each use. Do not use if damaged.
- Use the tree saw only for its intended purpose; do not attempt to use it for any other applications.
- Be aware of your surroundings and ensure there are no obstacles or hazards nearby while using the tree saw.
- Wear appropriate personal protective equipment (PPE), including gloves and safety goggles, while using the tree saw.
- Store the tree saw in a safe and dry location when not in use.

Specific Safety Precautions for Use

- Always use both hands to operate the tree saw for better control and stability.
- Ensure that the blade is sharp and properly maintained for efficient cutting.
- Do not apply excessive force when cutting; let the saw do the work.
- Keep hands and body away from the blade while cutting to prevent injury.
- Avoid cutting above shoulder height to maintain control and prevent accidents.
- Be cautious of falling branches or debris while cutting.
- If the saw becomes stuck, do not attempt to force it free; instead, carefully remove it from the cut.

Instructions for Installation and Usage

1. Unpacking the Tree Saw:

- Carefully remove the tree saw from its packaging.
- Inspect the saw for any visible damage or missing parts.

2. Extending the Tree Saw:

- To extend the tree saw, hold the handle firmly and pull the extension section until it clicks into place.
- Ensure that the extension is securely locked before use.

3. Using the Tree Saw:

- Position yourself securely and ensure that your footing is stable.
- Place the blade against the branch you wish to cut.
- Begin cutting with smooth, steady strokes, applying minimal pressure.
- Monitor your surroundings for any potential hazards while cutting.

4. After Use:

- Clean the blade and handle with a dry cloth to remove any sap or debris.
- Store the tree saw in its leather sheath to protect the blade and prevent accidents.

Disposal Instructions

- Dispose of the tree saw in accordance with local regulations regarding metal and plastic waste.
- If the saw is damaged beyond repair, ensure that it is disposed of safely to prevent injury to others.

Contact Information for Further Support

For further support or inquiries regarding the Uncle Henry 10 ft. Extendable Tree Saw, please refer to the contact information provided on the packaging or visit the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience while using the Uncle Henry 10 ft. Extendable Tree Saw. Always prioritize safety and report any unsafe conditions or incidents to the appropriate authorities. Thank you for your attention to these guidelines, and enjoy using your new tree saw!

Säkerhetsinstruktioner för Uncle Herny 10 ft. Extendable Tree Saw (1002)

Introduktion

Tack för att du valt Uncle Herny 10 ft. Extendable Tree Saw. Denna guide innehåller viktig information om säker användning, installation och avfallshantering av produkten. Vänligen läs igenom dessa instruktioner noggrant för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten före varje användning för att säkerställa att den är i gott skick.
- Använd alltid lämplig personlig skyddsutrustning, inklusive skyddsglasögon och handskar.
- Rapportera eventuella skador eller defekter till tillverkaren.

Specifika säkerhetsåtgärder för användning

- Kontrollera att sågen är korrekt monterad och att alla delar är säkra innan användning.
- Använd inte sågen om du är trött eller under påverkan av alkohol eller droger.
- Skär alltid bort från kroppen och håll händerna borta från bladet.
- Använd inte sågen för andra ändamål än avsedda.
- Var försiktig när du arbetar på ojämna ytor eller i trånga utrymmen.

Instruktioner för installation och användning

1. Montering av sågen:

- Fäst handtaget på sågens huvud enligt instruktionerna i manualen.
- Kontrollera att alla skruvar och fästen är ordentligt åtdragna.

2. Användning av sågen:

- Stå stadigt och håll ett fast grepp om handtaget.
- Rikta bladet mot det område som ska sågas.
- Använd en jämn och kontrollerad rörelse för att såga.
- Undvik att trycka för hårt; låt bladet göra jobbet.

3. Underhåll:

- Rengör sågen efter användning för att förhindra rost och slitage.
- Förvara sågen i det medföljande läderfodralet när den inte används.

Avfallshanteringsinstruktioner

- Avyttra eventuella oanvända eller trasiga delar i enlighet med lokala avfallshanteringsföreskrifter.
- Återvinn material där det är möjligt, inklusive metall och läder.
- Lämna in produkten till en återvinningsstation om den är i dåligt skick.

Kontaktinformation för vidare support

För frågor eller säkerhetsärenden, vänligen kontakta tillverkaren. En EUbaserad kontakt kommer att finnas tillgänglig för att hjälpa till med eventuella säkerhetsrelaterade frågor.

Slutord

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av Uncle Herry 10 ft. Extendable Tree Saw. Tack för att du valt vår produkt och för att du prioriterar säkerhet.