

Hand Held Chain Saw - Uncle Herny UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife Clam Pack

- Full Tang
- 7Cr17MoV steel with 3.1" blade length and weighs 2.5 oz
- Next Gen staglon handle with satin blade finish
- Lanyard hole
- Leather sheath

NO IMAGE
AVAILABLE

Attributes

- Name: Uncle Herny UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife Clam Pack
- Manufacturer: Uncle Herny
- Product no.: EU1000432
- Mfr. No.: 1100093
- Color: Black
- Delivery weight: 0.12kg
- Shipping height: 264mm
- Shipping width: 140mm
- Shipping length: 25mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Uncle Herry Hand Held Chain Saw Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Herry Hand Held Chain Saw och UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife](#)

Uncle Herny Hand Held Chain Saw Safety Instructions

Introduction

Thank you for choosing the Uncle Herny Hand Held Chain Saw. This guide provides essential safety instructions to ensure the safe use of your product. Please read this manual carefully before using the chain saw to prevent accidents and injuries.

General Safety Guidelines

- Always read and understand the user manual before operating the product.
- Keep the chain saw out of reach of children and unauthorized users.
- Wear appropriate personal protective equipment (PPE) including gloves, safety goggles, and ear protection.
- Ensure that the work area is clear of obstacles and bystanders.
- Do not operate the chain saw in wet or damp conditions.
- Inspect the chain saw before each use for any signs of damage or wear.
- Follow all local regulations regarding the use of chain saws.

Specific Safety Precautions for Use

- Always hold the chain saw with both hands while operating.
- Maintain a firm grip and ensure your footing is stable.
- Do not cut above shoulder height to maintain control.
- Be aware of your surroundings, including overhead hazards like power lines.
- Do not operate the chain saw while under the influence of drugs or alcohol.
- Never attempt to make adjustments or repairs while the chain saw is running.
- If the chain saw becomes jammed, turn it off and wait for the chain to stop before attempting to clear the jam.
- Use the chain saw only for its intended purpose.

Instructions for Installation and Usage

1. Unpacking the Product:

- Carefully remove the chain saw from its packaging.
- Inspect the chain saw for any damage that may have occurred during shipping.

2. Setting Up the Chain Saw:

- Ensure the chain is properly tensioned before use. Follow the manufacturer's guidelines for tensioning.
- Attach the chain saw to a secure and stable surface if needed.

3. Starting the Chain Saw:

- Ensure that the chain saw is on a flat surface.
- Engage the chain brake before starting the engine.
- Follow the starting instructions provided in the user manual.

4. Operating the Chain Saw:

- Begin cutting at a low speed to maintain control.
- Use smooth, steady motions while cutting.
- Always be prepared to stop the chain saw if necessary.

5. After Use:

- Turn off the chain saw and allow it to cool before storing.
- Clean the chain saw and ensure it is free of debris.
- Store the chain saw in a dry place, out of reach of children.

Disposal Instructions

- Dispose of the chain saw and its components in accordance with local regulations.
- Do not dispose of the chain saw in regular household waste.
- Consider recycling options for metal and plastic parts if available.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Uncle Herry Hand Held Chain Saw, please contact your local distributor or manufacturer representative. Ensure that you have the product details and any relevant information ready for a prompt response.

Thank you for prioritizing safety while using your Uncle Herry Hand Held Chain Saw. By following these guidelines, you can help ensure a safe and enjoyable experience.

Säkerhetsinstruktioner för Uncle Herny Hand Held Chain Saw och UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife

Introduktion

Tack för att du valt Uncle Herny Hand Held Chain Saw och UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa säker användning av produkterna. Vänligen läs noggrant igenom dessa instruktioner innan du använder produkterna.

Allmänna säkerhetsriktlinjer

- Använd alltid produkterna i enlighet med tillverkarens anvisningar.
- Förvara produkterna på en säker plats, utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkterna regelbundet för skador och slitage.
- Rapportera osäkra produkter och olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

Uncle Herny Hand Held Chain Saw

- Använd alltid skyddsglasögon och hörselskydd när du använder sågen.
- Håll händerna borta från sågens blad under användning.
- Använd inte sågen i fuktiga eller regniga förhållanden.
- Se till att arbetsområdet är fritt från hinder och personer.
- Stäng av sågen om den inte används och koppla bort strömförsörjningen.

UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife

- Använd kniven endast för avsett ändamål.
- Håll kniven borta från barn och osäkra personer.
- Se till att kniven är ordentligt inlåst i läderfodralet när den inte används.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Var försiktig vid rengöring och underhåll av kniven för att undvika skador.

Instruktioner för installation och användning

Uncle Herny Hand Held Chain Saw

1. Kontrollera att sågen är i gott skick innan användning.
2. Sätt på skyddsglasögon och hörselskydd.
3. Ställ in sågen på en stabil yta och koppla in strömmen.
4. Håll sågen med båda händerna och starta den enligt tillverkarens anvisningar.
5. Använd sågen i en kontrollerad rörelse och undvik att böja eller vrida sågen under användning.

UH Next Gen 301UH Full Tang Detail Skinner Fixed Blade Knife

1. Ta kniven ur läderfodralet med försiktighet.
2. Använd kniven med en fast och säker grepp.
3. Utför skärning i en riktning bort från kroppen och håll fingrarna borta från bladet.
4. Rengör kniven efter användning och torka den noggrant.
5. Förvara kniven i läderfodralet när den inte används.

Avfallsinstruktioner

- Kassera trasiga eller oanvändbara delar av produkterna på ett miljövänligt sätt.
- Följ lokala bestämmelser för avfallshantering av elektriska och elektroniska produkter.
- Se till att alla vassa delar är ordentligt inpackade för att förhindra skador under avfallshantering.

Kontaktinformation för vidare stöd

För frågor eller mer information om produkterna, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Det är viktigt att ha en EUbaserad kontakt för säkerhetsfrågor.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda produkterna på ett säkert sätt skyddar du dig själv och andra.