

4 Inch Shorty

The new Bubba Blade™ Shorty works like a mini Chef's knife and is the perfect knife for the field or kitchen. The Shorty design caters specifically to those with arthritis or weak hand strength or those who need a smaller knife than our 8 inch Chef's knife to prepare their meals. This Bubba Blade™ features an offset blade, allowing you to utilize the entire cutting edge, and a serrated edge to make cutting easier.

NO IMAGE
AVAILABLE

Attributes

- Name: 4 Inch Shorty
- Manufacturer: BUBBA
- Product no.: EU1001351
- Mfr. No.: BB1-SH-BP
- Color: Red
- Delivery weight: 0.272kg
- Shipping height: 38mm
- Shipping width: 171mm
- Shipping length: 340mm
- UPC: 019962035012

Table of Contents

- [Startpage](#)
- [English: BUBBA 4 Inch Shorty Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 4 Inch Shorty](#)

BUBBA 4 Inch Shorty Safety Instructions

Introduction

Thank you for purchasing the BUBBA 4 Inch Shorty knife. This product is designed for both field and kitchen use, providing a versatile tool for meal preparation. To ensure your safety and the longevity of your knife, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always handle the knife with care to avoid accidents or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Use the knife only for its intended purpose.
- Do not attempt to modify or repair the knife yourself.
- Store the knife in a safe place when not in use, preferably in its sheath.
- Be aware of your surroundings when using the knife to avoid unintended injuries.

Specific Safety Precautions for Use

- Ensure your hands are dry and free from any substances that may cause slipping.
- Use a cutting board or a stable surface when using the knife.
- Always cut away from your body to minimize the risk of injury.
- Use the serrated edge for cutting through tougher materials and the straight edge for precision tasks.
- If you experience any discomfort or pain while using the knife, stop immediately and consult a medical professional if necessary.
- For individuals with arthritis or weak hand strength, take extra care to hold the knife securely and consider using additional grip aids if needed.

Instructions for Installation and Usage

1. Unpacking the Knife

- Remove the knife from its packaging carefully to avoid cutting yourself.
- Inspect the knife for any damage or defects before use.

2. Using the Knife

- Grasp the textured handle firmly to maintain control.
- Position the blade at the desired angle against the food item you wish to cut.
- Apply gentle pressure and let the knife do the work; do not force it through tough materials.
- Clean the knife after each use with warm, soapy water and dry it thoroughly to prevent rust.

3. Storing the Knife

- Always store the knife in its synthetic sheath when not in use.
- Keep the knife in a designated drawer or knife block away from children and pets.

Disposal Instructions

- When the knife has reached the end of its life or is no longer usable, dispose of it responsibly.
- Wrap the knife in a protective material (e.g., cardboard) to prevent injuries during disposal.
- Follow local regulations for disposing of sharp objects and recycling materials.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of your BUBBA 4 Inch Shorty knife, please contact the manufacturer directly. Ensure you have the product details ready for a more efficient response.

By following these safety instructions, you can enjoy the benefits of your BUBBA 4 Inch Shorty knife while minimizing risks. Thank you for choosing BUBBA products, and happy cooking!

Säkerhetsinstruktioner för BUBBA 4 Inch Shorty

Introduktion

Tack för att du valt BUBBA 4 Inch Shorty. Denna kniv är designad för att ge en säker och effektiv skärupplevelse, oavsett om du är i köket eller ute i fält. För att säkerställa din säkerhet och knivens livslängd, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd kniven endast för dess avsedda syfte, dvs. skärning av livsmedel och andra lämpliga material.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid att kniven är i gott skick innan användning. Titta efter sprickor, skador eller slöhet på bladet.
- Förvara kniven på en säker plats, helst i det medföljande syntetiska fodralet när den inte används.
- Rapportera eventuella skador eller defekter till återförsäljaren.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven med båda händerna för ökad kontroll, särskilt om du har nedsatt handstyrka.
- Använd en skärbräda av lämpligt material för att förhindra att kniven glider.
- Undvik att skära på hårda ytor, vilket kan skada bladet.
- Var försiktig när du hanterar kniven, särskilt vid rengöring. Se till att bladet är vänd bort från kroppen.
- Använd aldrig kniven för att öppna förpackningar eller som ett verktyg för andra ändamål.

Instruktioner för installation och användning

1. Förberedelse:

- Ta bort kniven från dess fodral.
- Kontrollera att kniven är ren och torr innan användning.

2. Användning:

- Håll kniven i ett fast grepp och skär med en jämn rörelse.
- Utnyttja den sågade kanten för att göra skärningen enklare, särskilt på hårdare material.
- Använd kniven i en vinkel som känns bekväm och säker för dig.

3. Rengöring:

- Rengör kniven omedelbart efter användning med varmt vatten och mild tvål.
- Torka kniven noggrant för att förhindra rost.
- Förvara kniven i sitt fodral när den inte används.

Avfallshantering

- Kassera kniven på ett säkert sätt när den inte längre är i bruk. Se till att bladet är skyddat för att förhindra skador på andra.
- Kontakta lokala myndigheter för information om hur du korrekt kan återvinna eller kassera kniven.

Kontaktinformation för ytterligare support

För frågor eller rapportering av säkerhetsproblem, vänligen kontakta din återförsäljare eller kontrollera EU:s Safety Gateplattform för uppdateringar om eventuella återkallelser eller säkerhetsmeddelanden.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att göra det bidrar du till en säker och effektiv användning av din BUBBA 4 Inch Shorty kniv.