

7 Inch Fixed Blade - 7 Inch Fixed Hunting

The 7-inch Hunting Knife is the ultimate hunting knife for the Outdoorsman. The extended cutting blade and our patented no-slip-grip handle will give you the added safety you need to skin and gut the game even when your hands are covered with blood and guts.

NO IMAGE
AVAILABLE

Attributes

- Name: 7 Inch Fixed Hunting
- Manufacturer: BUBBA
- Product no.: EU1001354
- Mfr. No.: BB1-WD
- Color: Red
- Delivery weight: 0.454kg
- Shipping height: 38mm
- Shipping width: 162mm
- Shipping length: 425mm
- UPC: 696859308482

Table of Contents

- [Startpage](#)
- [English: BUBBA 7 Inch Fixed Blade Hunting Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 7tums Jaktkniv](#)

BUBBA 7 Inch Fixed Blade Hunting Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA 7 Inch Fixed Blade Hunting Knife. This knife is designed for outdoor enthusiasts and hunters, providing an effective tool for skinning and gutting game. To ensure your safety and the safe use of this product, please read the following safety instructions carefully.

General Safety Guidelines

- Always handle the knife with care to prevent accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure the knife is stored securely in its sheath when not in use.
- Regularly inspect the knife for any signs of damage or wear.
- Do not use the knife for purposes other than its intended use.
- Always cut away from your body and keep your fingers clear of the blade.

Specific Safety Precautions for Use

- Use the knife only in welllit areas to maintain visibility.
- Wear appropriate protective gear, such as gloves, when using the knife.
- Avoid using the knife if you are tired or under the influence of substances that may impair your judgment.
- When skinning or gutting game, ensure the animal is secured to prevent unexpected movements.
- If the knife becomes stuck, do not force it. Instead, carefully assess the situation and free the blade without risking injury.

Instructions for Installation and Usage

1. Unpacking the Knife

- Carefully remove the knife from its packaging.
- Inspect the knife for any visible damage before use.

2. Using the Knife

- Grasp the handle firmly, ensuring your grip is secure.
- Position the blade at the appropriate angle for cutting.
- Begin cutting slowly, applying steady pressure without forcing the blade.

3. Cleaning and Maintenance

- Clean the blade with warm soapy water after each use.
- Dry the blade thoroughly to prevent rust.
- Store the knife in its synthetic sheath when not in use.

4. Sharpening the Blade

- Use a proper sharpening tool designed for high carbon stainless steel blades.
- Follow the manufacturer's instructions for sharpening to maintain the blade's integrity.

Disposal Instructions

- When the knife reaches the end of its life cycle, dispose of it responsibly.
- Wrap the blade in protective material to prevent injury during disposal.
- Follow local regulations for the disposal of sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding the BUBBA 7 Inch Fixed Blade Hunting Knife, please refer to the manufacturer's contact information provided with the product packaging.

Conclusion

Your safety is our priority. By following these guidelines, you can ensure a safe and enjoyable experience with your BUBBA 7 Inch Fixed Blade Hunting Knife. Always prioritize safety and be aware of your surroundings while using this product. Thank you for choosing BUBBA, and happy hunting!

Säkerhetsinstruktioner för BUBBA 7tums Jaktkniv

Introduktion

Tack för att du valt BUBBA 7tums Jaktkniv. Denna jaktkniv är utformad för att ge dig säkerhet och effektivitet under jakt och utomhusaktiviteter. För att säkerställa en trygg användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt och säkert sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid knivens skick innan användning. Om bladet är skadat, slitet eller rostigt, sluta använda den.
- Använd kniven endast för dess avsedda ändamål, dvs. jakt och utomhusaktiviteter.
- Förvara kniven i det medföljande syntetiska fodralet när den inte används.
- Rapportera eventuella skador eller olyckor som involverar produkten till lämpliga myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett fast grepp på handtaget för att förhindra att kniven glider ur handen.
- Var medveten om din omgivning och andra personer när du använder kniven.
- Skär alltid bort från kroppen och håll fingrarna borta från bladet.
- Använd skyddshandskar om du hanterar byten som kan vara hala eller svåra att greppa.
- Vid rengöring, använd en mjuk trasa och undvik starka kemikalier som kan skada bladet eller handtaget.

Instruktioner för installation och användning

- För att använda BUBBA 7tums Jaktkniv:
 - Ta bort kniven från fodralet och kontrollera att den är i gott skick.
 - Håll kniven i ett fast grepp, se till att fingrarna är borta från bladets väg.
 - Utför de önskade skärningarna eller uppgifterna med kniven.
 - När du är klar, rengör kniven noggrant och torka den med en mjuk trasa.
 - Sätt tillbaka kniven i det syntetiska fodralet för säker förvaring.

Avfallshanteringsinstruktioner

- När kniven inte längre är i bruk eller om den är skadad, återvinn den på ett ansvarsfullt sätt.
- Kontrollera lokala riktlinjer för avfallshantering och återvinning av metallprodukter.
- Undvik att kasta kniven i vanligt avfall, eftersom detta kan orsaka skador på avfallshanteringspersonal.

Kontaktinformation för ytterligare support

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller kontrollera deras officiella webbplats. Se till att alltid ha produktens modellnummer och inköpsinformation tillgänglig när du söker support.

Genom att följa dessa säkerhetsinstruktioner bidrar du till en trygg och säker användning av BUBBA 7tums Jaktkniv. Tack för att du prioriterar säkerheten!