

SWSA10 Clip Point Black Inlay Handle

- 8Cr13MoV Ti-Nitride Coated High Carbon S.S. Blade Aluminum w/G10 Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA10 Clip Point Black Inlay Handle
- Manufacturer: M&P
- Product no.: EU1001439
- Mfr. No.: 1084300
- Color: Black/Silver
- Delivery weight: 0.249kg
- Shipping height: 24mm
- Shipping width: 37mm
- Shipping length: 90mm
- UPC: 661120413615

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for M&P SWSA10 Clip Point Black Inlay Handle](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA10 Clip Point Black Inlay Handle](#)

Safety Instruction Guide for M&P SWSA10 Clip Point Black Inlay Handle

Introduction

Thank you for choosing the M&P SWSA10 Clip Point Black Inlay Handle. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual carefully before using the product to avoid any potential hazards.

General Safety Guidelines

- Ensure that the knife is kept out of reach of children and vulnerable individuals.
- Always inspect the knife before use for any signs of damage or defects.
- Use the knife only for its intended purpose to prevent injury.
- Never use the knife in a manner that could cause harm to yourself or others.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about any product recalls through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers clear of the blade.
- Use a stable and secure surface when cutting.
- Do not attempt to catch a falling knife.
- Ensure that the knife is properly locked in place when in use.
- Avoid using excessive force when cutting to prevent the blade from breaking.
- Clean and dry the knife after each use to maintain its condition.

Instructions for Installation and Usage

- **Opening the Knife:**
 - Locate the dual thumbstuds on either side of the blade.
 - Use your thumb to press on the thumbstud while pulling the blade outward.
- **Locking Mechanism:**
 - Ensure the liner lock engages fully to secure the blade in the open position.
 - Check that the blade does not move when the lock is engaged.
- **Using the Pocket Clip:**
 - Attach the pocket clip to your belt or pocket for easy access.
 - Ensure the clip is secure to prevent the knife from falling out.
- **Closing the Knife:**
 - Press the liner lock to release the blade.
 - Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.
- **Maintenance:**
 - Regularly check the blade for sharpness and sharpen as necessary.
 - Lubricate the pivot point periodically to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly, following local regulations for hazardous waste.
- If the knife is damaged beyond repair, ensure it is securely wrapped to prevent accidental injury during disposal.

Contact Information for Further Support

For any safety inquiries or support regarding your M&P SWSA10 Clip Point Black Inlay Handle, please refer to the manufacturer's official website or contact your local distributor.

Thank you for your attention to these safety guidelines. Enjoy using your knife responsibly!

Säkerhetsinstruktioner för M&P SWSA10 Clip Point Black Inlay Handle

Introduktion

Tack för att du valt M&P SWSA10 Clip Point Black Inlay Handle. Denna guide ger viktiga säkerhetsinstruktioner för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom dessa instruktioner noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd endast produkten för dess avsedda syfte.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Vid skada eller defekt, sluta använda produkten omedelbart och kontakta tillverkaren.
- Följ alltid lokala lagar och förordningar angående knivar och vapen.

Specifika säkerhetsåtgärder för användning

- Använd kniven med försiktighet och var alltid medveten om bladets position.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Håll alltid kniven borta från ansiktet och kroppen när du använder den.
- Använd ett fast grepp på handtaget för att förhindra att kniven glider ur handen.
- Förvara kniven i ett säkert och torrt utrymme när den inte används.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tumknappen med tummen.
- Kontrollera att Liner Lockfunktionen är korrekt aktiverad innan du använder kniven.
- För att stänga kniven, tryck på Liner Lock och vik bladet tillbaka in i handtaget.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för enkel tillgång.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfall.
- Om kniven är skadad eller inte längre användbar, följ lokala riktlinjer för farligt avfall.
- Återvinn materialet om möjligt, men se till att bladet är säkert inpackat för att undvika skador.

Kontaktinformation för vidare stöd

För frågor eller säkerhetsinquiry, vänligen kontakta tillverkaren direkt. Se förpackningen eller produktens dokumentation för kontaktinformation.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och effektiv användning av din M&P SWSA10 Clip Point Black Inlay Handle. Tack för att du väljer våra produkter!