

SWSA10 Clip Point Black Inlay Handle - SWSA10CP Clip Point Black Inlay Handle Clam Pack

- 8Cr13MoV Ti-Nitride Coated High Carbon S.S. Blade Aluminum w/G10 Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA10CP Clip Point Black Inlay Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001440
- Mfr. No.: 1084301
- Color: Black/Silver
- Delivery weight: 0.218kg
- Shipping height: 275mm
- Shipping width: 22mm
- Shipping length: 90mm
- UPC: 661120413622

Table of Contents

- [Startpage](#)
- [English: M&P SWSA10 Clip Point Black Inlay Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA10 Clip Point Black Inlay Handle](#)

M&P SWSA10 Clip Point Black Inlay Handle Safety Instructions

Introduction

Thank you for choosing the M&P SWSA10 Clip Point Black Inlay Handle. This guide provides essential safety instructions to ensure the safe use of your knife. Please read and follow these guidelines carefully to avoid accidents and injuries.

General Safety Guidelines

- Always handle the knife with care.
- Keep the knife out of reach of children.
- Do not use the knife for purposes other than intended.
- Inspect the knife regularly for any signs of damage or wear.
- Store the knife in a safe place when not in use.
- Do not attempt to modify the knife in any way.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers clear of the blade.
- Use the knife on a stable surface to prevent slipping.
- Ensure that the blade is fully deployed and locked before use.
- Avoid using excessive force when cutting, as this may cause the blade to slip.
- If the knife becomes stuck during use, do not force it. Carefully assess the situation before proceeding.
- Be aware of your surroundings and avoid distractions while using the knife.

Instructions for Installation and Usage

- **Opening the Knife:**
 - Locate the dual thumb studs on either side of the blade.
 - Use your thumb to push the thumb stud outward to open the blade.
 - Ensure the blade is fully extended and locked in place before use.
- **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Position the blade at the desired cutting angle.
 - Apply steady pressure while cutting, ensuring your hands are clear of the blade.
- **Closing the Knife:**
 - Press the liner lock located on the side of the handle.
 - Gently push the blade back into the handle until it is fully closed.
 - Ensure the blade is securely locked in the closed position before storing.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, consider recycling the materials where possible.
- Do not dispose of the knife in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns related to the M&P SWSA10 Clip Point Black Inlay Handle, please reach out to the designated EU contact point for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P SWSA10 Clip Point Black Inlay Handle. Always prioritize safety and be aware of your surroundings while using the knife. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för M&P SWSA10 Clip Point Black Inlay Handle

Inledning

Tack för att du valt M&P SWSA10 Clip Point Black Inlay Handle. Denna produkt är designad för att ge en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant innan du använder produkten för att säkerställa korrekt och säker användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast produkten för dess avsedda syfte.
- Var försiktig när du hanterar kniven för att undvika skador.
- Undvik att använda produkten om du är trött eller distraherad.
- Se till att kniven är i ett låst läge när den inte används.
- Använd skyddshandskar vid behov för att skydda händerna vid användning.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd den dubbla tumknappen för att öppna kniven.
- Se till att kniven är helt öppen och låst innan du använder den.

2. Användning:

- Håll kniven i ett fast grepp.
- Använd den clip point designen för precision i snitt.
- Var medveten om omgivningen när du använder kniven för att undvika olyckor.

3. Stänga kniven:

- Tryck på liner lock för att frigöra bladet.
- Stäng försiktigt kniven tills den är helt stängd.

Avfallshantering

- Kasta inte produkten i vanlig hushållssopor.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Återvinn materialet där det är möjligt.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerhetsåtgärder, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens modellnummer tillgängligt för snabbare hjälp.

Vi tackar för att du valt M&P SWSA10 Clip Point Black Inlay Handle och hoppas att du får en säker och positiv upplevelse med produkten.