

SW1101 Drop Point Rubberized Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Textured Aluminum Handle
- Dual Thumbstuds
- Finger Flipper
- Liner Lock
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SW1101 Drop Point Rubberized Black Handle
- Manufacturer: M&P
- Product no.: EU1001447
- Mfr. No.: 1084308
- Color: Black
- Delivery weight: 0.118kg
- Shipping height: 24mm
- Shipping width: 37mm
- Shipping length: 75mm
- UPC: 661120413332

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for M&P SW1101 Drop Point Rubberized Black Handle](#)
- [Svenska: Säkerhetsinstruktioner för M&P SW1101 Drop Point Gummihandtag](#)

Safety Instruction Guide for M&P SW1101 Drop Point Rubberized Black Handle

Introduction

Thank you for choosing the M&P SW1101 Drop Point Rubberized Black Handle. This knife is designed for safe and effective use. Please read this safety instruction guide carefully to ensure proper handling and maintenance, and to understand the safety precautions necessary for your protection.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Ensure that the knife is stored in a safe place when not in use.
- Regularly inspect the knife for any signs of damage or wear.
- Use the knife only for its intended purpose; do not use it for tasks it was not designed for.
- Follow all local laws and regulations regarding knife ownership and use.

Specific Safety Precautions for Use

- Be mindful of your surroundings when using the knife to avoid accidental injury to yourself or others.
- Always cut away from your body and keep your fingers clear of the blade.
- Use the dual thumbstuds and finger flipper to safely open the knife.
- Ensure the liner lock is engaged before using the knife to prevent accidental closure during use.
- If the knife becomes dull, sharpen it properly before use; do not use a dull knife as it can lead to accidents.
- If the knife is dropped or subjected to force, inspect it for damage before continuing to use it.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the dual thumbstuds or the finger flipper to open the knife. Ensure your fingers are clear of the blade path.

2. Using the Knife:

- Hold the knife firmly by the rubberized textured aluminum handle.
- Cut in a controlled manner, ensuring that you maintain a stable grip.
- Always keep the knife pointed away from your body and others.

3. Closing the Knife:

- To close the knife, ensure the blade is clear of any objects, then disengage the liner lock.
- Carefully fold the blade back into the handle while keeping fingers clear of the blade.

4. Storing the Knife:

- Store the knife in a safe location, ideally in a sheath or protective case.
- Avoid placing the knife in areas where it could accidentally open or cause injury.

Disposal Instructions

- When the knife is no longer usable, dispose of it responsibly.

- Check local regulations for proper disposal methods for knives and sharp objects.
- Ensure that the knife is rendered unusable before disposal to prevent accidental injury.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's contact information provided with the product.

Conclusion

By following these safety instructions, you can ensure safe usage of your M&P SW1101 Drop Point Rubberized Black Handle. Always prioritize safety and be aware of your surroundings when using this product. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P SW1101 Drop Point Gummihandtag

Introduktion

Tack för att du valt M&P SW1101 Drop Point med gummihandtag. Denna säkerhetsinstruktionsguide är utformad för att ge dig viktig information om säker användning, installation och avfallshantering av produkten. Vänligen läs igenom dessa instruktioner noggrant för att säkerställa en trygg och säker användning.

Allmänna säkerhetsriktlinjer

- Kontrollera alltid produkten före användning för att säkerställa att den är i gott skick.
- Använd produkten endast enligt avsedda syften.
- Håll produkten utom räckhåll för barn och sårbara individer.
- Rapportera eventuella skador eller defekter till tillverkaren eller försäljningsstället.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil yta.
- Håll fingrarna borta från bladet när du fäller ut det.
- Använd fingertumknappen och fingerflippern för att fälla ut bladet på ett säkert sätt.
- Se till att liner lock är korrekt engagerad innan du använder kniven.
- Använd fickklämman och snoddhålet för att fästa kniven säkert när den inte används.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingertumknappen eller fingerflippern för att fälla ut bladet.
- Kontrollera att liner lock är korrekt låst innan användning.

2. Användning:

- Använd kniven för avsedda syften, som skärning av material.
- Undvik att använda kniven för att skära hårda eller oregelbundna ytor som kan skada bladet.

3. Stänga kniven:

- Tryck på liner lock för att frigöra bladet.
- Vik bladet tillbaka till handtaget försiktigt.

4. Rengöring:

- Rengör kniven med en mjuk trasa efter varje användning.
- Undvik att använda starka kemikalier eller slipande material.

Avfallshanteringsinstruktioner

- Kasta inte produkten i hushållsavfall.
- Följ lokala föreskrifter för avfallshantering av metallprodukter.
- Om produkten är skadad eller inte längre behövs, lämna den på en återvinningsstation för metall.

Kontaktinformation för vidare stöd

För frågor om säkerhet eller produktinformation, vänligen kontakta tillverkaren eller den återförsäljare där produkten köptes. Kontrollera EU:s Safety Gateplattform för uppdateringar om eventuella återkallelser eller säkerhetsinformation relaterad till produkten.

Tack för att du tar del av dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss!