

Clip Point Blade Black Inlay Handle - M&P MPM2.0DA30CP - M&P M2.0 Clip Point Black Handle Clam Pack

- AUS-8 Black Oxide Coated High Carbon S.S. Blade Aluminum Handle
- Dual Action: Spring Assisted or Manual Opening
- Finger Actuator
- Glass Breaker
- Pocket Clip with Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: M&P MPM2.0DA30CP - M&P M2.0 Clip Point Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001462
- Mfr. No.: 1084319
- Color: Black
- Delivery weight: 0.136kg
- Shipping height: 24mm
- Shipping width: 70mm
- Shipping length: 95mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P Clip Point Blade Black Inlay Handle Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Point Blade Black Inlay Handle M&P MPM2.0DA30CP](#)

M&P Clip Point Blade Black Inlay Handle Safety Instruction Guide

Introduction

Thank you for choosing the M&P Clip Point Blade Black Inlay Handle. This manual provides essential safety instructions to ensure the safe and effective use of your knife. Please read this guide carefully before using the product to avoid potential hazards and to promote safe handling.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Ensure that the blade is fully closed or locked when not in use.
- Use the knife only for its intended purposes.
- Inspect the knife before each use for any signs of damage or malfunction.
- Store the knife in a safe place, preferably in a sheath or protective case.
- Do not attempt to modify or repair the knife yourself.
- If the knife is damaged, discontinue use immediately and seek professional assistance.

Specific Safety Precautions for Use

- **Blade Safety:** The AUS8 Black Oxide Coated High Carbon Stainless Steel blade is sharp. Handle it with caution to avoid cuts or injuries.
- **Opening Mechanism:** Familiarize yourself with the dual action opening mechanism (springassisted or manual) to ensure safe operation.
- **Finger Actuator:** Use the finger actuator responsibly to avoid unintentional blade deployment.
- **Glass Breaker:** The integrated glass breaker is designed for emergency situations. Use it only as intended.
- **Pocket Clip:** When using the pocket clip, ensure that it is securely attached to your clothing to prevent accidental drops.
- **Lanyard Hole:** Utilize the lanyard hole for added security when carrying the knife, but ensure it does not interfere with the knife's operation.

Instructions for Installation and Usage

1. Opening the Knife:

- To open the knife, use the finger actuator to deploy the blade. Ensure your fingers are clear of the blade path.
- For manual opening, grasp the handle firmly and pull the blade out carefully.

2. Using the Knife:

- Always cut away from your body and keep your fingers out of the cutting path.
- Use the knife on a stable surface to maintain control.
- Do not use the knife for prying, twisting, or any actions that could damage the blade or cause injury.

3. Closing the Knife:

- To close the knife, ensure that your fingers are clear of the blade path.
- Gently push the blade back into the handle until it clicks into place.

4. Maintenance:

- Regularly clean the blade and handle with a soft cloth to prevent rust and maintain performance.
- Lubricate the opening mechanism periodically to ensure smooth operation.

Disposal Instructions

- When the knife reaches the end of its life cycle or is no longer functional, dispose of it responsibly.
- Follow local regulations for disposing of sharp objects to prevent injury to waste handlers.
- If applicable, consider recycling parts of the knife that are made from recyclable materials.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Clip Point Blade, please consult the manufacturer's website or contact the designated EU contact point for assistance. Always refer to the latest safety updates and recall notices on the EU's Safety Gate platform.

By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your M&P Clip Point Blade. Thank you for your attention to safety!

Säkerhetsinstruktioner för M&P Clip Point Blade Black Inlay Handle M&P MPM2.0DA30CP

Introduktion

Tack för att du valt M&P Clip Point Blade med svart inläggshandtag. Denna säkerhetsinstruktionsguide är utformad för att säkerställa säker användning av produkten och för att informera om viktiga säkerhetsåtgärder. Vänligen läs igenom hela dokumentet noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för tecken på skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med största försiktighet.
- Undvik att skära mot kroppen eller andra personer.
- Använd kniven på en stabil yta för att minimera risken för olyckor.
- Stäng alltid kniven när den inte används.
- Öppna kniven med fjärrassisterad eller manuell öppning enligt instruktionerna.
- Använd glasbrytaren endast i nödsituationer.
- Fickklämman bör användas för att säkert fästa kniven, så att den inte tappas.

Instruktioner för installation och användning

1. Öppning av kniven:

- För att öppna kniven, använd fjärrassisterad mekanism genom att trycka på knappen eller dra ut bladet manuellt.
- Se till att bladet är helt utsträckt innan du börjar använda kniven.

2. Användning av kniven:

- Håll kniven i ett fast grepp, med pekfingret på bladets rygg för extra kontroll.
- Skär med en jämn rörelse och undvik plötsliga drag.

3. Stängning av kniven:

- För att stänga kniven, tryck på knappen för att fälla in bladet eller dra tillbaka bladet manuellt.
- Kontrollera att bladet är helt intryckt innan du förvarar kniven.

4. Användning av glasbrytaren:

- Använd glasbrytaren endast i nödsituationer för att bryta glas.
- Sikta noggrant och tryck med en jämn kraft för att undvika skador.

5. Fickklämma:

- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker förvaring.
- Kontrollera att klämman är ordentligt fastsatt innan användning.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering av vassa föremål.
- Om kniven är skadad eller inte längre används, se till att den förvaras på ett säkert sätt tills den kan kasseras korrekt.

Kontaktinformation för ytterligare support

För frågor eller ytterligare information om produkten, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Kontrollera också EU:s Safety Gateplattform för uppdateringar och information om återkallelser.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda produkten på ett säkert sätt skyddar du både dig själv och andra.