

Clip Point Black Handle - MP300 M&P Clip Point Blade Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Matte Finish Textured Aluminum Handle
- Liner Lock
- Dual Thumbstuds
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: MP300 M&P Clip Point Blade Black Handle
- Manufacturer: M&P
- Product no.: EU1001479
- Mfr. No.: 1085896
- Color: Black
- Delivery weight: 0.159kg
- Shipping height: 24mm
- Shipping width: 37mm
- Shipping length: 83mm
- UPC: 661120413950

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for M&P Clip Point Black Handle MP300](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Point Black Handle MP300](#)

Safety Instruction Guide for M&P Clip Point Black Handle MP300

Introduction

Thank you for choosing the M&P Clip Point Black Handle MP300. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this document carefully to understand the safety measures and guidelines.

General Safety Guidelines

- Always use the knife for its intended purpose. Misuse can lead to accidents or injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear. Do not use if damaged.
- Store the knife in a safe place when not in use, preferably in a sheath or designated storage.
- Do not attempt to modify or alter the knife in any way.
- Be aware of your surroundings when using the knife to avoid accidents.

Specific Safety Precautions for Use

- Always cut away from your body to prevent injury.
- Use the knife on a stable and secure surface to avoid slipping.
- Ensure your hands are dry and free of distractions when handling the knife.
- Use the liner lock properly to secure the blade during use.
- Be cautious when using the dual thumbstuds to open the blade. Ensure your fingers are clear of the blade path.
- Avoid using excessive force when cutting; let the blade do the work.
- Do not use the knife for prying, as this may damage the blade or cause injury.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the dual thumbstuds on either side of the blade.
- Press down on the thumbstud with your thumb to open the blade smoothly.
- Ensure the liner lock engages fully to secure the blade in an open position.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the blade at the desired angle for cutting.
- Slice through the material with steady pressure, ensuring your other hand is clear of the blade.

3. Closing the Knife:

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

4. Attaching the Pocket Clip:

- If desired, attach the pocket clip to the handle for convenient carrying.
- Ensure the clip is securely fastened and positioned for easy access.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, consider recycling the metal components where possible.
- Ensure the blade is covered or wrapped to prevent injury during disposal.
- Follow local regulations for disposing of knives and sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P Clip Point Black Handle MP300, please consult the product packaging or visit the manufacturer's website for further assistance.

By following these safety instructions, you can enjoy the benefits of your M&P Clip Point Black Handle MP300 while minimizing the risk of injury. Thank you for your attention to safety.

Säkerhetsinstruktioner för M&P Clip Point Black Handle MP300

Introduktion

Tack för att du valt M&P Clip Point Black Handle MP300. Denna guide innehåller viktiga säkerhetsinstruktioner och användarinformation för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom hela dokumentet noggrant innan användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för tecken på skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och koncentration.
- Undvik att använda kniven för andra ändamål än vad den är avsedd för.
- Se till att kniven är i ett säkert låst läge när den inte används.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Håll fingrarna borta från bladet när du använder kniven.

Instruktioner för installation och användning

1. Öppning av kniven:

- Använd tumknappen för att öppna kniven försiktigt.
- Se till att kniven är helt öppen och låst innan användning.

2. Stängning av kniven:

- Tryck på liner lock för att frigöra bladet.
- Vik försiktigt tillbaka bladet tills det är helt stängt.

3. Användning av fickklämma:

- Fäst fickklämman på bältet eller i fickan för säker förvaring.
- Kontrollera att klämman sitter ordentligt fast och inte riskerar att lossna.

Avfallshantering

- Kasta inte kniven i hushållsavfall. Följ lokala föreskrifter för avfallshantering av skarpa föremål.
- Återvinn materialet om möjligt, enligt lokala återvinningsregler.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiries, vänligen kontakta en lokal återförsäljare eller besök tillverkarens webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!