

Clip Point Black Handle - MP300CP M&P Clip Point Blade Black Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Matte Finish Textured Aluminum Handle
- Liner Lock
- Dual Thumbstuds
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: MP300CP M&P Clip Point Blade Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001480
- Mfr. No.: 1085897
- Color: Black
- Delivery weight: 0.168kg
- Shipping height: 275mm
- Shipping width: 20mm
- Shipping length: 83mm
- UPC: 661120413967

Table of Contents

- [Startpage](#)
- [English: M&P Clip Point Black Handle MP300CP Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Point Black Handle MP300CP](#)

M&P Clip Point Black Handle MP300CP

Safety Instruction Guide

Introduction

Thank you for choosing the M&P Clip Point Black Handle MP300CP. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this document carefully before use to understand the safety precautions and proper handling techniques.

General Safety Guidelines

- Ensure the knife is kept out of reach of children and vulnerable individuals.
- Always handle the knife with care, ensuring that the blade is pointed away from your body and others.
- Regularly inspect the knife for any signs of damage or wear. If any issues are found, discontinue use immediately.
- Store the knife in a safe and secure location when not in use.
- If you are not familiar with knife handling, seek guidance from someone with experience.
- Always use the knife for its intended purpose to avoid accidents.

Specific Safety Precautions for Use

- Always use both hands to open the knife, ensuring a firm grip on the handle.
- Close the knife carefully, avoiding contact with the blade.
- Do not use the knife for prying or as a tool for tasks it is not designed for.
- Avoid using the knife in wet conditions to prevent slipping.
- Do not attempt to modify or repair the knife yourself; seek professional assistance if needed.
- If the knife becomes stuck during use, do not force it. Carefully assess the situation before proceeding.

Instructions for Installation and Usage

- To open the knife:
 - Hold the knife in one hand with the blade facing away from you.
 - Use your thumb to push the thumb stud located on the blade until it clicks into the open position.
- To close the knife:
 - Ensure your fingers are clear of the blade.
 - Press the liner lock mechanism to release the blade and gently fold it back into the handle.
- To attach the pocket clip:
 - Align the pocket clip with the designated holes on the handle.
 - Secure the clip using the provided screws, ensuring it is tightened adequately.
- For optimal performance, clean the knife regularly with a soft cloth and apply a small amount of lubricant to the pivot area if necessary.

Disposal Instructions

- Dispose of the knife responsibly at a designated waste facility.
- Ensure the blade is securely closed or wrapped to prevent injury during disposal.
- Follow local regulations regarding the disposal of sharp objects.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of the M&P Clip Point Black Handle MP300CP, please contact your local retailer or the manufacturer directly.

Conclusion

By following the safety instructions outlined in this guide, you can ensure a safe and enjoyable experience with your M&P Clip Point Black Handle MP300CP. Always prioritize safety and responsible handling to prevent accidents and injuries. Thank you for your attention to these important safety guidelines.

Säkerhetsinstruktioner för M&P Clip Point Black Handle MP300CP

Introduktion

Tack för att du valt M&P Clip Point Black Handle MP300CP. Denna produkt är utformad för att ge en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa korrekt användning och för att undvika potentiella risker.

Allmänna säkerhetsriktlinjer

- Kontrollera alltid att produkten är i gott skick innan användning.
- Använd produkten endast för dess avsedda syfte.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Använd skyddsutrustning vid behov, såsom handskar.
- Rapportera eventuella skador eller defekter till försäljaren.

Specifika säkerhetsåtgärder för användning

- Var försiktig när du öppnar och stänger bladet för att undvika skador.
- Använd aldrig kniven på en ojämn eller instabil yta.
- Undvik att använda kniven för att skära genom hårda material som metall eller glas.
- Håll kniven borta från ansiktet och kroppen när du använder den.
- Förvara kniven i ett säkert och torrt utrymme när den inte används.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tummknappen med tummen.
- När bladet är fullt utsträckt, låt liner locken klicka på plats för att säkra bladet.
- För att stänga kniven, tryck på liner locken och vik bladet tillbaka i handtaget.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för enkel åtkomst.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfall.
- Följ lokala föreskrifter för avfallshantering av metallprodukter.
- Om produkten är skadad eller inte längre användbar, kontakta en återvinningscentral för korrekt hantering.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om säkerhetsåtgärder, vänligen kontakta den lokala återförsäljaren eller besök tillverkarens webbplats för support.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.