

S.A. Red Accent - S&W S.A. Red Accent Box

- Spring assisted opening
- 8Cr13MoV steel with 3.25" blade length and weighs 4.7 oz
- Rubberized aluminum handle with black oxide blade coating
- Liner lock, thumbstud, tungsten window punch and seat belt cutter
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W S.A. Red Accent Box
- Manufacturer: M&P
- Product no.: EU1001503
- Mfr. No.: 1100038
- Delivery weight: 0.15kg
- Shipping height: 23mm
- Shipping width: 38mm
- Shipping length: 85mm
- UPC: 661120075981

Table of Contents

- [Startpage](#)
- [English: M&P S.A. Red Accent S&W S.A. Red Accent Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P S.A. Red Accent S&W S.A. Red Accent Box](#)

M&P S.A. Red Accent S&W S.A. Red Accent Box Safety Instruction Guide

Introduction

Thank you for choosing the M&P S.A. Red Accent S&W S.A. Red Accent Box. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Do not use the knife for purposes other than its intended use.
- Inspect the knife regularly for any signs of damage or wear.
- If the knife is damaged or malfunctioning, discontinue use immediately.
- Follow all local laws and regulations regarding knife ownership and use.

Specific Safety Precautions for Use

- Use caution when opening the knife; the springassisted opening can cause the blade to deploy quickly.
- Always cut away from your body to minimize the risk of injury.
- When using the seat belt cutter or window punch, ensure you are applying the tool to the correct material to avoid accidents.
- Do not attempt to modify or alter the knife in any way.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.

Instructions for Installation and Usage

1. Opening the Knife:

- To open the knife, press the thumb stud while applying slight pressure on the handle.
- The springassisted mechanism will deploy the blade quickly.

2. Using the Blade:

- Hold the knife firmly by the rubberized aluminum handle.
- Use the blade for cutting tasks only; avoid prying or applying excessive force.

3. Using the Seat Belt Cutter:

- Position the seat belt cutter against the seat belt material.
- Apply a firm, controlled motion to slice through the belt.

4. Using the Window Punch:

- Aim the tungsten window punch at the corner of the window for maximum effectiveness.
- Strike the punch with sufficient force to break the glass.

5. Closing the Knife:

- To close the knife, press the liner lock to release the blade.
- Fold the blade back into the handle carefully to avoid injury.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged and cannot be repaired, consider recycling the materials where possible.
- Do not dispose of the knife in regular household waste if it poses a safety risk.

Contact Information for Further Support

For any inquiries regarding the safety and use of your M&P S.A. Red Accent S&W S.A. Red Accent Box, please refer to the contact details provided with the product or visit the manufacturer's website for more information.

Thank you for your attention to these safety guidelines. Your safety is our priority.

Säkerhetsinstruktioner för M&P S.A. Red Accent S&W S.A. Red Accent Box

Introduktion

Tack för att du valt M&P S.A. Red Accent S&W S.A. Red Accent Box. Denna produkt är designad för att ge en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning och för att följa EU:s allmänna produktsäkerhetsförordning (GPSR).

Allmänna säkerhetsriktlinjer

- Produktsäkerhet: Använd produkten endast enligt avsedd användning för att minimera risker.
- Övervaka användning: Håll ett öga på användare, särskilt barn, för att förhindra olyckor.
- Rapportera osäkra produkter: Informera myndigheter om osäkra produkter eller olyckor.
- Kontrollera återkallelse: Håll dig informerad om eventuella produktåterkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd skyddsglasögon om du skär genom hårda material.
- Håll kniven borta från barn och djur.
- Använd alltid kniven på en stabil yta för att förhindra olyckor.
- Se till att kniven är i gott skick innan användning, kontrollera bladet för skador.
- Förvara kniven på en säker plats när den inte används.

Instruktioner för installation och användning

- **Öppning av kniven:** Använd tumstudsens för att öppna kniven. Fjäderassisterad öppning gör det enkelt och snabbt.
- **Användning av liner lock:** Se till att liner lock är korrekt engagerad för att förhindra att bladet stängs av misstag under användning.
- **Stängning av kniven:** Tryck på liner lock och stäng bladet försiktigt för att undvika skador.
- **Förvaring:** Använd fickklämman för att fästa kniven på bältet eller i fickan för säker förvaring.

Avfallshantering

- Avfallshantering av produkten ska ske enligt lokala regler och förordningar.
- Kasta inte produkten i hushållssoporna. Kontakta lokala myndigheter för korrekt avfallshantering.

Kontaktinformation för vidare support

För frågor eller ytterligare information, vänligen kontakta den angivna kontaktpunkten i EU för säkerhetsfrågor.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss!