

Stonewash Keychain Folding Knife - S&W Stonewash Keychain Box

- Folding Knife
- 3Cr13 steel with 2.25" blade length and weighs 2.4 oz
- Stainless steel handle with stonewash coating
- Money clip, nail nick, frame lock, bottle opener and keychain lanyard
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Stonewash Keychain Box
- Manufacturer: M&P
- Product no.: EU1001511
- Mfr. No.: 1100064
- Color: Grey
- Delivery weight: 0.077kg
- Shipping height: 18mm
- Shipping width: 33mm
- Shipping length: 55mm
- UPC: 661120076063

Table of Contents

- [Startpage](#)
- [English: M&P Stonewash Keychain Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Stonewash Nyckelring Fällkniv](#)

M&P Stonewash Keychain Folding Knife

Safety Instructions

Introduction

Thank you for choosing the M&P Stonewash Keychain Folding Knife. This guide provides important safety instructions and guidelines to ensure safe and proper use of your knife. Please read this manual carefully before use.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Ensure that the blade is fully locked in place before using the knife.
- Do not use the knife for purposes other than intended.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, do not use it and contact customer support for assistance.
- Store the knife in a safe place when not in use to prevent accidental injury.

Specific Safety Precautions for Use

- When opening or closing the knife, keep fingers clear of the blade to avoid cuts.
- Use the knife on stable surfaces and avoid using it while holding it in your hand unless necessary.
- Do not attempt to modify or disassemble the knife.
- Use the bottle opener feature only for its intended purpose.
- Avoid using excessive force when cutting to prevent blade breakage or accidents.
- Be cautious when using the knife in wet or slippery conditions.

Instructions for Installation and Usage

- To open the knife:
 - Locate the nail nick on the blade.
 - Use your thumb to lift the blade out of the handle until it locks into place.
- To close the knife:
 - Press the frame lock to release the blade.
 - Carefully fold the blade back into the handle until it clicks into place.
- For using the money clip:
 - Attach bills securely under the money clip for safe carrying.
- For using the pocket clip:
 - Clip the knife onto your pocket or bag for easy access.
- When using the keychain lanyard:
 - Attach the knife to your keychain for convenient carrying.

Disposal Instructions

- When the knife has reached the end of its life, dispose of it responsibly.
- Check local regulations for proper disposal methods for metal items.
- If the knife is damaged, consider recycling the metal components where possible.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Stonewash Keychain Folding Knife, please reach out to your local authorized dealer or manufacturer contact point.

Conclusion

Following these safety instructions will help ensure a safe and enjoyable experience with your M&P Stonewash Keychain Folding Knife. Thank you for your attention to these guidelines, and please use your knife responsibly.

Säkerhetsinstruktioner för M&P Stonewash Nyckelring Fällkniv

Introduktion

Tack för att du valt M&P Stonewash Nyckelring Fällkniv. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa säker och korrekt användning av produkten. Vänligen läs igenom hela dokumentet innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten på ett säkert sätt och i enlighet med dessa instruktioner.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage innan användning.
- Om produkten skadas eller visar tecken på defekt, sluta använda den omedelbart.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett ändamål.
- Var försiktig när du öppnar och stänger kniven för att undvika skador på dig själv eller andra.
- Håll kniven borta från ansiktet och kroppen när du använder den.
- Använd skyddshandskar om du arbetar med material som kan skada kniven eller orsaka olyckor.
- Förvara kniven på en säker plats när den inte används, helst i ett fodral eller med skyddet på bladet.

Instruktioner för installation och användning

- För att öppna kniven, tryck på ramlocket och dra handtaget utåt.
- För att stänga kniven, tryck på ramlocket igen och vik bladet tillbaka in i handtaget.
- Använd pengaklippen för att fästa kniven på bälte eller väska för enkel åtkomst.
- Flasköppnaren kan användas för att öppna flaskor, men var försiktig så att du inte skadar kniven eller dig själv.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfallet om den är skadad eller defekt.
- Kontakta lokala avfallshanteringsmyndigheter för information om hur du korrekt avlägsnar kniven.
- Återvinn materialet om möjligt, i enlighet med lokala återvinningsföreskrifter.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiries, vänligen kontakta den lokala återförsäljaren där produkten köptes eller besök tillverkarens officiella webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner! Din säkerhet är vår högsta prioritet.