

Stonewash Keychain Folding Knife - S&W Stonewash Keychain Clam Pack

- Folding Knife
- 3Cr13 steel with 2.25" blade length and weighs 2.4 oz
- Stainless steel handle with stonewash coating
- Money clip, nail nick, frame lock, bottle opener and keychain lanyard
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Stonewash Keychain Clam Pack
- Manufacturer: M&P
- Product no.: EU1001512
- Mfr. No.: 1100065
- Color: Grey
- Delivery weight: 0.095kg
- Shipping height: 240mm
- Shipping width: 20mm
- Shipping length: 55mm
- UPC: 661120076070

Table of Contents

- [Startpage](#)
- [English: M&P Stonewash Keychain Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Stonewash Nyckelring Fällkniv](#)

M&P Stonewash Keychain Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P Stonewash Keychain Folding Knife. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear. Do not use a damaged knife.
- Ensure the knife is closed when not in use to prevent accidental cuts.
- Use the knife only for its intended purpose.
- Be cautious when using the knife in wet conditions, as the handle may become slippery.
- Store the knife in a safe location to prevent accidental opening or injury.

Specific Safety Precautions for Use

- When using the blade, always cut away from your body and keep your fingers clear of the cutting path.
- Use the money clip and bottle opener features with care to avoid injury.
- Do not attempt to modify the knife or its components.
- Ensure that the frame lock is engaged before using the knife to prevent accidental closure.
- Do not use the knife for prying, as this can damage the blade or cause injury.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife securely in one hand.
- Use your thumb to press the nail nick and gently pull the blade out until it is fully extended.
- Ensure the frame lock clicks into place, securing the blade.

2. Using the Knife:

- To cut, position the blade against the material you wish to cut.
- Apply steady pressure while moving the blade in a controlled manner.
- After use, carefully close the knife by pressing the frame lock and folding the blade back into the handle.

3. Using Additional Features:

- **Money Clip:** Use the money clip to securely hold cash or cards. Ensure it is not overloaded to maintain its functionality.
- **Bottle Opener:** Use the bottle opener feature to open bottles by applying gentle pressure to the cap.
- **Keychain Lanyard:** Attach the knife to your keychain for easy access. Ensure it is securely fastened.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, consider recycling the metal components where facilities are available.
- Do not dispose of the knife in regular household waste. Check local regulations for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Stonewash Keychain Folding Knife, please refer to the EU contact point or your retailer for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P Stonewash Keychain Folding Knife. Always prioritize safety and proper handling to prevent accidents and injuries. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P Stonewash Nyckelring Fällkniv

Introduktion

Tack för att du valt M&P Stonewash Nyckelring Fällkniv. Denna fällkniv är designad för att vara praktisk och säker att använda. För att säkerställa en trygg användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid kniven för skador innan användning.
- Använd kniven endast för dess avsedda syfte.
- Rapportera eventuella skador eller defekter till återförsäljaren.

Specifika säkerhetsåtgärder för användning

- Undvik att använda kniven i fuktiga miljöer för att förhindra rost.
- Se till att bladet är helt låst innan du använder kniven.
- Använd skyddshandskar om du är osäker på ditt grepp eller om du har känslig hud.
- Håll kniven borta från ansiktet och kroppen under användning.
- Använd kniven på en stabil yta för att förhindra olyckor.

Instruktioner för installation och användning

- För att öppna kniven, tryck på ramlåset och vik ut bladet tills det låser sig på plats.
- För att stänga kniven, tryck på ramlåset igen och vik tillbaka bladet försiktigt.
- Använd pengaklämman för att fästa kniven på bältet eller i fickan för enkel åtkomst.
- Flasköppnaren kan användas för att öppna flaskor, men se till att kniven är i ett säkert läge innan du gör detta.

Avfallsinstruktioner

- Kassera kniven på ett ansvarsfullt sätt. Följ lokala regler för avfallshantering.
- Om kniven är skadad eller inte längre används, överväg att återvinna metallkomponenterna där det är möjligt.

Kontaktinformation för vidare support

För frågor eller mer information, vänligen kontakta din återförsäljare eller den lokala myndigheten för produktinformation och säkerhet.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss!