

Tactical Pen Black w/Glass Breaker Box

- 6" overall length and weighs 1.9 oz
- 6061 aircraft aluminum
- Uses Schmidt P900M Parker Style Black Ball Point Pen Refill
- Patent pending, spring loaded window punch and twist cap
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P Tactical Pen Black w/Glass Breaker Box
- Manufacturer: M&P
- Product no.: EU1001541
- Mfr. No.: 1100098
- Color: Black
- UPC: 661120076360

Table of Contents

- [Startpage](#)
- [English: M&P Tactical Pen Black w/Glass Breaker Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Tactical Pen Black med Glasbrytare](#)

M&P Tactical Pen Black w/Glass Breaker

Safety Instruction Guide

Introduction

Thank you for choosing the M&P Tactical Pen Black with Glass Breaker. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your tactical pen. Please read this document carefully before using the product.

General Safety Guidelines

- Always use the tactical pen for its intended purpose.
- Keep the pen out of reach of children to prevent accidental injury.
- Inspect the pen regularly for any signs of damage or wear. Do not use if damaged.
- Avoid using excessive force when utilizing the glass breaker feature.
- Ensure the pen is stored securely when not in use to prevent accidental injury.

Specific Safety Precautions for Use

- **Glass Breaker Usage:**
 - Use the glass breaker feature only in emergency situations.
 - Aim the glass breaker at the corner of the glass for optimal effectiveness.
 - Maintain a safe distance from the glass to avoid injury from shards.
- **Writing Use:**
 - Ensure that the pen is capped when not in use to prevent ink leakage.
 - Use on appropriate paper surfaces to avoid damage to the pen tip.
- **General Handling:**
 - Do not use the pen as a weapon or for any purpose other than its intended use.
 - Avoid exposing the pen to extreme temperatures or moisture.

Instructions for Installation and Usage

- **Installing the Refill:**
 1. Unscrew the pen cap counterclockwise.
 2. Remove the old refill if necessary by pulling it out gently.
 3. Insert a new Schmidt P900M Parker Style Black Ball Point Pen Refill into the barrel.
 4. Screw the pen cap back on securely.
- **Using the Glass Breaker:**
 1. Hold the pen firmly with the glass breaker end facing the glass.
 2. Apply pressure to the glass breaker to activate the springloaded mechanism.
 3. Strike the glass at a corner for best results.
- **Writing:**
 1. Remove the cap from the pen.

2. Write on the desired surface. Replace the cap after use to prevent ink drying.

Disposal Instructions

- Dispose of the pen responsibly. Follow local regulations for disposal of metal and plastic products.
- If the pen is no longer functional, consider recycling the components where applicable.
- Do not dispose of the pen in fire as it may explode or release harmful substances.

Contact Information for Further Support

For any inquiries or concerns regarding the M&P Tactical Pen, please refer to the contact information provided by your retailer or manufacturer. Ensure you have the product details ready for a quicker response.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your M&P Tactical Pen Black w/Glass Breaker. Always prioritize safety and be aware of your surroundings when using the pen. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P Tactical Pen Black med Glasbrytare

Introduktion

Tack för att du valt M&P Tactical Pen Black med Glasbrytare. Denna penna är designad för att vara både funktionell och säker. Det är viktigt att följa dessa säkerhetsinstruktioner noggrant för att säkerställa en säker och effektiv användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att undvika skador.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för tecken på skador eller slitage. Använd inte produkten om den är skadad.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd inte glasbrytaren på oavsiktliga ytor eller i situationer där det kan orsaka skada.
- Undvik att använda pennan som ett vapen; den är avsedd för skrivning och säkerhet.
- Var försiktig när du byter bläckpatron för att undvika att skada mekanismen.
- Använd endast rekommenderade bläckpatroner (Schmidt P900M Parker Style Black Ball Point Pen Refill) för att säkerställa optimal funktion.

Instruktioner för installation och användning

1. Byta bläckpatron:

- Skruva av pennans bakdel.
- Ta bort den använda bläckpatronen.
- Sätt i en ny bläckpatron och skruva tillbaka bakdelen.

2. Användning av glasbrytare:

- Håll pennan i ett fast grepp.
- Rikta glasbrytaren mot det område som ska krossas.
- Tryck med jämn kraft för att bryta glaset.

3. Fickklämma:

- Använd fickklämman för att fästa pennan på kläder eller väskor för enkel åtkomst.

Avfallsinstruktioner

- Kassera använda bläckpatroner enligt lokala föreskrifter för avfallshantering.
- För produkten i sin helhet, överväg att återvinna den om möjligt, i enlighet med lokala återvinningsprogram.

Kontaktinformation för ytterligare support

För frågor om säkerhet eller användning av produkten, vänligen kontakta tillverkaren eller besök deras officiella hemsida för mer information.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.