

Tactical Pen OD Green w/Glass Breaker - M&P Tactical Pen OD Green w/Glass Breaker Box

- 6" overall length and weighs 1.9 oz
- 6061 aircraft aluminum
- Uses Schmidt P900M Parker Style Black Ball Point Pen Refill
- Patent pending, spring loaded window punch and twist cap
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P Tactical Pen OD Green w/Glass Breaker Box
- Manufacturer: M&P
- Product no.: EU1001543
- Mfr. No.: 1100100
- Color: Olive Drab Green
- UPC: 661120076384

Table of Contents

- [Startpage](#)
- [English: M&P Tactical Pen OD Green w/Glass Breaker Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Tactical Pen OD Green med Glasbrytare](#)

M&P Tactical Pen OD Green w/Glass Breaker

Safety Instruction Guide

Introduction

Thank you for choosing the M&P Tactical Pen OD Green w/Glass Breaker. This versatile tool is designed for practical use in everyday situations. To ensure your safety and the safe operation of this product, please read this guide carefully before use.

General Safety Guidelines

- Ensure the pen is used as intended to avoid injury or damage.
- Keep the pen out of reach of children to prevent accidental use or injury.
- Regularly inspect the pen for any signs of damage. If damaged, discontinue use immediately.
- Store the pen in a safe location when not in use to prevent accidents.
- Be aware of your surroundings when using the glass breaker feature to ensure safety.

Specific Safety Precautions for Use

- Do not use the pen for any purpose other than writing or breaking glass in emergencies.
- Avoid applying excessive force when writing to prevent breakage.
- Use the glass breaker feature only in emergency situations and with caution.
- Do not point the pen at yourself or others when using it.
- Ensure the pen cap is securely fastened when not in use to prevent accidental injury.

Instructions for Installation and Usage

1. Using the Pen:

- Remove the cap by twisting it counterclockwise.
- Insert the Schmidt P900M Parker Style Black Ball Point Pen Refill if necessary.
- Twist the cap back on securely after use.

2. Using the Glass Breaker:

- Ensure you are in a safe environment.
- Hold the pen firmly and position the glass breaker tip against the glass surface.
- Apply a quick, firm pressure to break the glass. Use caution to avoid injury from glass shards.

3. Maintaining the Pen:

- Clean the pen regularly with a soft, dry cloth.
- Avoid exposure to extreme temperatures or moisture.

Disposal Instructions

- Dispose of the pen responsibly at an appropriate recycling facility.
- Follow local regulations for the disposal of metal products.
- If the pen is damaged beyond repair, ensure that it is disposed of in a way that prevents injury to others.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Tactical Pen OD Green w/Glass Breaker, please refer to the manufacturer's contact point provided with your product packaging.

By following these guidelines, you can ensure the safe use of your M&P Tactical Pen OD Green w/Glass Breaker. Always prioritize safety and stay informed about any updates or changes related to the product.

Säkerhetsinstruktioner för M&P Tactical Pen OD Green med Glasbrytare

Introduktion

Tack för att du valt M&P Tactical Pen OD Green med Glasbrytare. Denna produkt är designad för att vara både praktisk och säker att använda. För att säkerställa en trygg och effektiv användning av pennan, vänligen följ de säkerhetsinstruktioner som anges i denna guide.

Allmänna säkerhetsriktlinjer

- Säkerställ att produkten används enligt anvisningarna för att minimera risker.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd inte pennan som ett vapen eller i något avsett syfte som inte är avsett för skrivande.
- Undvik att använda glasbrytaren i situationer där det kan orsaka skador på andra personer eller egendom.
- Se till att pennan är stängd när den inte används för att förhindra oavsiktlig skada.
- Förvara pennan på en säker plats för att förhindra att den tappas bort eller används av barn.

Instruktioner för installation och användning

1. Användning av kulspetspenna:

- Ta bort locket på pennan genom att vrida det moturs.
- Tryck ned spetsen för att börja skriva.
- När du är klar, vrid tillbaka locket för att skydda spetsen.

2. Användning av glasbrytare:

- Använd glasbrytaren endast i nödsituationer för att bryta glas.
- Sikta på ett hörn av glaset för effektivast resultat.
- Använd en säkerhetsrörelse och håll ett avstånd från ansiktet.

3. Underhåll:

- Rengör pennan med en mjuk, torr trasa för att ta bort smuts och skräp.
- Byt ut kulspetsens refill vid behov för att säkerställa optimal prestanda.

Avfallsinstruktioner

- Kassera produkten enligt lokala bestämmelser för avfallshantering.
- Separera metallkomponenter från plastkomponenter, om möjligt.
- Återvinn materialet där det är möjligt.

Kontaktinformation för ytterligare support

Vid frågor eller behov av support, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabb hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.