

Ray Clip Point Blade Rubberized Handle

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Rubberized Aluminum Handle
- Finger Flipper
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade Ray Clip Point Blade Rubberized Handle
- Manufacturer: Shrade
- Product no.: EU1001545
- Mfr. No.: 1084279
- Color: Black
- Delivery weight: 0.118kg
- Shipping height: 24mm
- Shipping width: 36mm
- Shipping length: 95mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade Ray Clip Point Blade Rubberized Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Ray Clip Point Blade Rubberized Handle](#)

Safety Instruction Guide for Shrade Ray Clip Point Blade Rubberized Handle

Introduction

Thank you for choosing the Shrade Ray Clip Point Blade with a Rubberized Handle. This knife is designed for durability and ease of use. To ensure your safety and the safe use of this product, please read and follow the instructions and safety guidelines provided in this manual.

General Safety Guidelines

- Always use the knife in a safe and responsible manner.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Do not use the knife for unintended purposes.
- If the knife becomes damaged, discontinue use immediately and seek a replacement.

Specific Safety Precautions for Use

- Handle the knife with care to avoid cuts and injuries.
- Always cut away from your body and keep your fingers clear of the blade.
- Use the finger flipper only as intended to open the blade.
- Ensure the liner lock is securely engaged before using the knife.
- When carrying the knife, always use the pocket clip or lanyard hole to secure it safely.
- Do not attempt to disassemble the knife; it is designed to be used as is.

Instructions for Installation and Usage

1. Opening the Knife

- Use the finger flipper to open the blade.
- Ensure that the blade is fully extended and locked in place before use.

2. Using the Knife

- Hold the knife firmly by the rubberized aluminum handle.
- Position your fingers away from the blade edge while cutting.
- Apply even pressure when cutting through materials.

3. Closing the Knife

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

4. Carrying the Knife

- Use the pocket clip to secure the knife to your pocket or belt.
- Alternatively, use the lanyard hole to attach the knife to a lanyard for added safety.

Disposal Instructions

- When the knife has reached the end of its usable life, dispose of it responsibly.
- Follow local regulations for the disposal of sharp objects to prevent injury to waste handlers.

- Consider recycling the materials if possible.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of this product, please refer to the manufacturer's contact information provided with your purchase.

Conclusion

By following these guidelines, you can ensure a safe and enjoyable experience with your Shrade Ray Clip Point Blade Rubberized Handle. Always prioritize safety and responsible use to maximize the effectiveness of this product. Thank you for your attention to these important safety instructions.

Säkerhetsinstruktioner för Shrade Ray Clip Point Blade Rubberized Handle

Introduktion

Tack för att du har valt Shrade Ray Clip Point Blade med gummibelagt handtag. Denna produkt är designad för att ge en säker och effektiv användning. För att säkerställa din säkerhet och för att maximera produktens livslängd, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt anvisningarna.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och se till att knivbladet är korrekt låst innan användning.
- Använd kniven endast för dess avsedda syfte. Undvik att använda den för att skära hårda material som kan skada bladet.
- Håll fingrarna borta från knivbladet under användning.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Använd fickklämman för att fästa kniven på kläder eller utrustning för att förhindra att den faller.
- Undvik att använda kniven när du är trött eller distraherad.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna kniven. Se till att bladet är helt utsträckt och låst på plats.

2. Använd kniven:

- Håll kniven i en säker position, med bladet bort från dig och andra.
- Använd kniven för att skära, men undvik att använda den för att bryta eller slå på hårda ytor.

3. Stäng kniven:

- Tryck på liner lock för att frigöra bladet.
- Vik bladet tillbaka in i handtaget tills det är helt stängt.

4. Förvaring:

- Förvara kniven på en säker plats, borta från barn och husdjur.
- Använd fickklämman för att fästa kniven på ett bälte eller i en väska för säker transport.

Avfallshanteringsinstruktioner

- När produkten inte längre är i bruk, se till att den avyttras på ett säkert sätt.
- Kniven bör kasseras som skräp, men kontrollera lokala riktlinjer för avfallshantering och återvinning av metallprodukter.

- Se till att kniven är stängd och säker innan du kasserar den.

Kontaktinformation för vidare stöd

För frågor och mer information om produkten, vänligen kontakta tillverkaren via deras officiella kanaler. Kontrollera alltid att du har den senaste informationen och att produkten är säker att använda.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss!