

Ray Clip Point Blade Rubberized Handle Clam Pack

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Rubberized Aluminum Handle
- Finger Flipper
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade Ray Clip Point Blade Rubberized Handle Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001546
- Mfr. No.: 1084280
- Color: Black
- Delivery weight: 0.136kg
- Shipping height: 24mm
- Shipping width: 70mm
- Shipping length: 95mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instructions for Shrade Ray Clip Point Blade Rubberized Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Ray Clip Point Blade Rubberized Handle](#)

Safety Instructions for Shrade Ray Clip Point Blade Rubberized Handle

Introduction

Thank you for choosing the Shrade Ray Clip Point Blade with a Rubberized Handle. This guide provides essential safety instructions to ensure the safe use of your knife. Please read and follow these guidelines carefully to avoid any potential hazards.

General Safety Guidelines

- Ensure that the knife is kept out of reach of children and vulnerable individuals.
- Always handle the knife with care and respect.
- Inspect the knife before each use to ensure it is in good working condition.
- Do not use the knife for purposes other than its intended use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always cut away from your body to prevent accidental injury.
- Use the finger flipper feature responsibly to open the blade.
- Ensure the liner lock is fully engaged before using the knife.
- Do not force the blade open if it does not move freely.
- Avoid using excessive force while cutting to prevent blade breakage.
- If the knife becomes damaged or shows signs of wear, discontinue use immediately.
- Always store the knife securely when not in use.

Instructions for Installation and Usage

• Opening the Knife:

- Utilize the finger flipper to open the blade. Ensure your fingers are clear of the blade path.

• Locking the Blade:

- Confirm that the liner lock is engaged before using the knife. The blade should not move when the lock is in place.

• Using the Pocket Clip:

- Attach the pocket clip to your clothing or bag for easy access. Ensure it is securely fastened to prevent accidental loss.

• Using the Lanyard Hole:

- If desired, attach a lanyard to the lanyard hole for additional security and easier handling.

• Cleaning and Maintenance:

- Clean the blade after each use with a damp cloth. Avoid submerging the knife in water.
- Regularly check the blade and handle for any signs of damage or wear.

Disposal Instructions

- Dispose of the knife responsibly when it is no longer usable.
- Follow local regulations for disposal of sharp objects to prevent injury to waste management personnel.
- Consider recycling components where applicable, following local recycling guidelines.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Shrade Ray Clip Point Blade, please refer to the manufacturer's website or customer service resources available in your region.

Säkerhetsinstruktioner för Shrade Ray Clip Point Blade Rubberized Handle

Introduktion

Tack för att du valt Shrade Ray Clip Point Blade med gummibelagt handtag. Denna produkt är designad för att ge dig en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning av din kniv.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsedda ändamål.
- Rapportera osäkra produkter och olyckor till myndigheterna.
- Kontrollera regelbundet för återkallelseuppdateringar på EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven för att undvika skador.
- Håll kniven borta från ansiktet och kroppen när du använder den.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Stäng alltid kniven när den inte används.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Se till att liner lockfunktionen är aktiverad innan du använder kniven.
- Använd fickklämman för att fästa kniven på bältet eller väskan för säker förvaring.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingerflippern för att öppna bladet. Se till att handen är borta från bladets väg.
2. **Kontrollera låset:** Kontrollera att liner lockfunktionen är korrekt aktiverad innan du använder kniven.
3. **Använd kniven:** Använd kniven för avsedda ändamål, som skärning av material. Var alltid medveten om knivens position.
4. **Stäng kniven:** När du är klar, tryck på liner lock för att frigöra bladet och stäng det försiktigt.
5. **Förvaring:** Förvara kniven på en säker plats, helst i ett fodral eller med fickklämman fäst.

Avfallsinstruktioner

- Kasta aldrig kniven i hushållsavfallet om den är skadad eller trasig.
- Kontakta lokala avfallshanteringsmyndigheter för att få information om korrekt avfallshantering av knivar.
- Återvinn materialet i enlighet med lokala riktlinjer om möjligt.

Kontaktinformation för vidare stöd

För frågor om säkerhet och användning av Shrade Ray Clip Point Blade, vänligen kontakta vår kundtjänst via den angivna kontaktmetoden på förpackningen eller vår webbplats.

Tack för att du följer dessa säkerhetsinstruktioner och för att du bidrar till en säker användning av våra produkter.