

SCH704 w/Cutter Black

- 9Cr18MoV Steel
- Rubberized Aluminum Handle
- Black Oxide Blade Coating
- Strap Cutter and Window Punch
- Finger Flipper

NO IMAGE
AVAILABLE

Attributes

- Name: SCH704 w/Cutter Black
- Manufacturer: Shrade
- Product no.: EU1001551
- Mfr. No.: 1084287
- Color: Black
- Delivery weight: 0.136kg
- Shipping height: 23mm
- Shipping width: 45mm
- Shipping length: 83mm
- UPC: 661120413486

Table of Contents

- [Startpage](#)
- [English: Shrade SCH704 w/Cutter Black Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH704 w/Cutter Black](#)

Shrade SCH704 w/Cutter Black Safety Instructions

Introduction

Thank you for choosing the Shrade SCH704 w/Cutter Black. This manual provides essential safety instructions to ensure the safe and effective use of your knife. Please read this guide carefully before use.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Inspect the knife before each use to ensure it is in good working condition.
- Use the knife only for its intended purpose; misuse can lead to injury.
- Be aware of your surroundings when using the knife to prevent accidental injury to yourself or others.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface to avoid slips and injuries.
- **Blade Care:** Keep the blade sharp. A dull blade can slip and cause injury. Sharpen the blade as needed.
- **Finger Flipper:** Use the finger flipper mechanism carefully to open the knife. Ensure your fingers are clear of the blade path.
- **Strap Cutter and Window Punch:** Use these features only for their intended purposes. Do not attempt to use them for cutting materials they are not designed for.
- **Personal Protective Equipment:** Consider wearing cutresistant gloves when using the knife for added safety.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife securely in one hand.
- Use your thumb to push the finger flipper to open the blade smoothly.
- Ensure the blade locks into place before use.

2. Using the Strap Cutter:

- Position the strap securely.
- Place the strap cutter against the strap and apply even pressure to cut through.
- Always cut away from your body and keep hands clear of the cutting path.

3. Using the Window Punch:

- Identify the window area you wish to break.
- Hold the knife firmly and position the window punch against the glass.
- Apply a quick, firm pressure to break the glass if necessary.

4. Closing the Knife:

- Ensure the blade is pointed away from you.
- Press the release mechanism to unlock the blade.
- Carefully fold the blade back into the handle until it clicks into place.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged or no longer usable, ensure it is disposed of in a way that prevents accidental injury to others.
- Consider recycling materials where applicable.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade SCH704 w/Cutter Black, please refer to the product packaging or visit the manufacturer's website for further assistance.

Important Note: Always prioritize safety when using any knife. Report any unsafe products or incidents to the relevant authorities and check for recall updates on the EU's Safety Gate platform. Thank you for ensuring your safety and the safety of those around you.

Säkerhetsinstruktioner för Shrade SCH704 w/Cutter Black

Introduktion

Tack för att du valt Shrade SCH704 w/Cutter Black. Denna produkt är designad för att ge långvarig prestanda och säkerhet. Vänligen läs noggrant igenom dessa säkerhetsinstruktioner innan användning för att säkerställa korrekt och säker användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten för skador innan användning. Använd inte om den är skadad.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven för att undvika skador.
- Undvik att rikta bladet mot dig eller andra personer under användning.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Håll kniven ren och i gott skick för att säkerställa säker användning.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingerflippern för att öppna kniven. Se till att fingrarna är borta från bladet under öppningsprocessen.
2. **Användning av kniven:**
 - Använd kniven för avsedda syften, som skärning av rep eller andra material.
 - För att använda remskäraren, placera remmen i skärkanalen och tryck ned för att klippa.
 - Använd fönsterknäckaren i nödsituationer, men endast när det är absolut nödvändigt.
3. **Stäng kniven:** När du är klar med användningen, stäng kniven försiktigt genom att trycka på låsmekanismen och fälla tillbaka bladet.

Avfallshantering

- Kassera produkten i enlighet med lokala föreskrifter för avfallshantering.
- Se till att kniven är stängd och säker innan du slänger den för att undvika skador på personer som hanterar avfallet.

Kontaktinformation för vidare stöd

För frågor eller ytterligare information om säkerheten hos denna produkt, vänligen kontakta tillverkaren eller besök deras officiella webbplats. Se till att alltid ha produktens modellnummer och inköpsinformation till hands för snabbare hjälp.

Vi tackar för att du följer dessa säkerhetsinstruktioner och önskar dig en säker och nöjsam användning av din Shrade SCH704 w/Cutter Black.