

SCH706 Drop Point Blade Carbon Fiber Handle - SCH706CP Drop Point Blade Carbon Fiber Handle Clam Pack

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Ti-Nitride Steel w/Carbon Fiber Inlay Handle
- Thumbstud
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SCH706CP Drop Point Blade Carbon Fiber Handle Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001556
- Mfr. No.: 1084292
- Delivery weight: 0.127kg
- Shipping height: 229mm
- Shipping width: 23mm
- Shipping length: 69mm
- UPC: 661120413530

Table of Contents

- [Startpage](#)
- [English: Shrade SCH706 Drop Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH706 Drop Point Blade Carbon Fiber Handle](#)

Shrade SCH706 Drop Point Blade Safety Instructions

Introduction

Thank you for choosing the Shrade SCH706 Drop Point Blade with a Carbon Fiber Handle. This product is designed for safe and effective use. Please read this safety instruction guide carefully to ensure you understand how to use the knife safely and responsibly.

General Safety Guidelines

- Always handle the knife with care to prevent accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure you are using the knife in a safe environment, free from distractions.
- Inspect the knife before use to ensure it is in good condition and functioning properly.
- Do not use the knife for purposes other than intended, such as prying or as a screwdriver.

Specific Safety Precautions for Use

- **Blade Safety:** The blade is sharp and can cause serious injury. Always keep the blade closed when not in use.
- **Locking Mechanism:** Ensure the liner lock is engaged when the blade is open to prevent accidental closure during use.
- **Thumbstud:** Use the thumbstud to open the blade safely. Do not force the blade open.
- **Pocket Clip:** Use the pocket clip to secure the knife when carrying it. Ensure it is firmly attached to your pocket or belt.
- **Lanyard Hole:** If using a lanyard, ensure it is securely attached and does not interfere with the blade's operation.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your thumb to push the thumbstud until the blade opens fully.
- Ensure the liner lock clicks into place to secure the blade.

2. Using the Knife:

- Always cut away from your body.
- Use a stable surface when cutting.
- Do not apply excessive force to the blade.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it is fully closed.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, consider recycling the metal components where applicable.
- Ensure that the knife is securely wrapped to prevent injury during disposal.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's contact information provided on the packaging or product documentation.

Thank you for your attention to these safety guidelines. Enjoy your Shrade SCH706 Drop Point Blade responsibly!

Säkerhetsinstruktioner för Shrade SCH706 Drop Point Blade Carbon Fiber Handle

Introduktion

Tack för att du har valt Shrade SCH706 Drop Point Blade med kolfiberhandtag. Denna kniv är designad för att ge hög kvalitet och säkerhet vid användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en säker och korrekt användning av produkten.

Allmänna säkerhetsriktlinjer

- Denna produkt är avsedd för vuxna användare. Håll kniven utom räckhåll för barn.
- Använd alltid kniven på ett säkert sätt och håll den borta från ansikte och kropp för att undvika skador.
- Kontrollera alltid kniven för skador innan användning. Använd inte kniven om den är skadad.
- Förvara kniven på en säker plats när den inte används, helst i ett skyddande fodral eller en knivhållare.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett ändamål. Den är designad för skärande uppgifter och bör inte användas för att bryta eller slå.
- Håll alltid kniven i en säker vinkel när du skär för att undvika olyckor.
- Använd en skärbräda eller en annan säker yta för att skära på.
- Använd aldrig kniven i närheten av vatten eller andra hala ytor för att förhindra att du tappar kontrollen över den.
- Om kniven har en tummknapp, se till att den är ordentligt låst innan du använder den.

Instruktioner för installation och användning

1. **Öppna kniven:** Tryck på tummknappen för att öppna bladen. Se till att kniven är riktad bort från dig själv och andra.
2. **Lås kniven:** Kontrollera att liner locksystemet är aktiverat för att förhindra att kniven stängs av misstag under användning.
3. **Skärning:** Använd kniven på ett kontrollerat sätt. Skär långsamt och med precision.
4. **Stäng kniven:** För att stänga kniven, tryck på liner lock och vik bladen försiktigt tillbaka till handtaget.
5. **Förvaring:** Förvara kniven på en säker plats, helst i sitt klampack eller fodral, när den inte används.

Avfallshantering

- Kasta inte kniven i hushållsavfall. Kontakta lokala avfallshanteringsmyndigheter för information om korrekt avfallshantering av knivar.
- Om kniven är defekt eller skadad, se till att den är oåtkomlig för barn innan du kasserar den.

Kontaktinformation för vidare support

För frågor eller support, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Det är viktigt att ha en EUbaserad kontakt för säkerhetsfrågor.

Tack för att du valde Shrade. Vi hoppas att du får en säker och nöjsam upplevelse med din nya kniv!