

SCHEXC Outdoor Kit

- Steel w/Wrapped Textured Silicone Handles
- Interchangeable Tool System
- Includes: Saw Blade, Pick, Axe and Shovel that have Handles that expand from 9"-27"
- Steel Handles wrapped in textured silicon
- Features a safety lock icon and comes with a polyester case

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCHEXC Outdoor Kit
- Manufacturer: Shrade
- Product no.: EU1001559
- Mfr. No.: 1084299
- Color: Black
- Delivery weight: 2.821kg
- Shipping height: 81mm
- Shipping width: 179mm
- Shipping length: 1mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade SCHEXC Outdoor Kit Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCHEXC Outdoor Kit](#)

Shrade SCHEXC Outdoor Kit Safety Instructions

Introduction

Thank you for choosing the Shrade SCHEXC Outdoor Kit. This product is designed for outdoor enthusiasts and provides a versatile set of tools for various activities. To ensure your safety and the proper use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always inspect the tools before use to ensure they are in good condition.
- Keep the tools out of reach of children and pets when not in use.
- Use the tools only for their intended purposes as described in the product specifications.
- Always use personal protective equipment (PPE) such as gloves and safety goggles when using sharp tools.
- Do not use the tools in wet conditions to prevent slipping or accidents.
- Ensure that the safety lock is engaged when the tools are not in use.
- Be aware of your surroundings and avoid using the tools in crowded areas or near flammable materials.

Specific Safety Precautions for Use

- **Saw Blade:**
 - Use caution when handling the saw blade to avoid cuts.
 - Ensure the blade is securely attached before use.
 - Do not force the saw; let the blade do the work.
- **Pick:**
 - Use the pick only on solid surfaces.
 - Keep hands and feet clear of the pick's path while using.
- **Axe:**
 - Always swing the axe away from your body and others.
 - Use a stable surface to chop and ensure your footing is secure.
- **Shovel:**
 - Use proper lifting techniques to avoid back injuries.
 - Do not overload the shovel; lift only what you can handle safely.

Instructions for Installation and Usage

1. Assembly:

- Expand the handles to the desired length (9" to 27") before attaching any tools.
- Ensure all connections are secure and the safety lock is engaged.

2. Using the Tools:

- For the saw blade, grip the handle firmly and saw in a backandforth motion.
- For the pick, hold the handle securely and apply downward pressure to penetrate the surface.
- When using the axe, position the wood securely and swing with controlled force.

- For the shovel, scoop material with the blade and lift using your legs, not your back.

3. After Use:

- Clean all tools after use to prevent rust and damage.
- Store the tools in the provided polyester case to protect them when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of sharp tools in regular trash; consider recycling options where available.
- Remove batteries and dispose of them separately if applicable.

Contact Information for Further Support

For any safety inquiries or support, please refer to the contact details provided with your product packaging.

Thank you for prioritizing safety while using the Shrade SCHEXC Outdoor Kit. Enjoy your outdoor activities responsibly!

Säkerhetsinstruktioner för Shrade SCHEXC Outdoor Kit

Introduktion

Tack för att du valt Shrade SCHEXC Outdoor Kit. Denna guide innehåller viktiga säkerhetsanvisningar och användarinstruktioner för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom alla instruktioner noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att undvika skador.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid produkten för skador innan användning. Använd aldrig en skadad produkt.
- Vid eventuella frågor eller osäkerhet, kontakta en expert eller återförsäljare.
- Rapportera alla osäkra produkter och olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd skyddsglasögon och handskar vid användning av verktyg för att skydda mot flygande skräp.
- Se till att arbetsområdet är fritt från hinder och faror.
- Använd alltid verktygen på en stabil yta.
- Var försiktig med skarpa kanter och spetsiga delar av produkten.
- Undvik att använda produkten i ogynnsamma väderförhållanden, som kraftigt regn eller stark vind.

Instruktioner för installation och användning

1. Montering av verktyg:

- Se till att verktygssystemet är ordentligt installerat innan användning.
- Följ medföljande instruktioner för att byta ut verktyg.

2. Justering av handtag:

- Justera handtaget till önskad längd (9"27") genom att lossa låsmekanismen.
- Kontrollera att handtaget är ordentligt låst innan användning.

3. Användning av verktyg:

- För sågblad: Använd med ett jämnt tryck och undvik att överbelasta verktyget.
- För yxa: Använd en säker och kontrollerad rörelse för att undvika skador.
- För spade: Gräv alltid med en stabil fotställning och undvik att lyfta för mycket vikt.

4. Säkerhetslås:

- Använd säkerhetslåsikonen för att förhindra oavsiktlig användning när produkten inte är i bruk.

Avfallshanteringsinstruktioner

- Kasta inte produkten i hushållsavfall. Följ lokala riktlinjer för avfallshantering.
- Om produkten är skadad eller inte längre kan användas, se till att den återvinns på ett miljövänligt sätt.

Kontaktinformation för vidare support

För frågor eller mer information om säkerhet och användning, vänligen kontakta en lokal återförsäljare eller besök den officiella webbplatsen för Shrade.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.