

SCH U.G. Rub w/Fire Box

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 4.6 oz
- Rubber handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. Rub w/Fire Box
- Manufacturer: Shrade
- Product no.: EU1001562
- Mfr. No.: 1100046
- Color: Black
- Delivery weight: 0.145kg
- Shipping height: 23mm
- Shipping width: 44mm
- Shipping length: 85mm
- UPC: 661120076421

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH U.G. Rub w/Fire Box](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH U.G. Rub w/Fire Box](#)

Safety Instruction Guide for Shrade SCH U.G. Rub w/Fire Box

Introduction

Thank you for choosing the Shrade SCH U.G. Rub w/Fire Box. This folding knife is designed for safe and effective use. This guide provides essential safety instructions and guidelines to ensure your safety and the proper usage of the product. Please read this document carefully before using the knife.

General Safety Guidelines

- Always handle the knife with care to prevent injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use for any signs of damage or wear.
- Use the knife only for its intended purpose; do not use it for tasks it was not designed for.
- Always cut away from your body and keep your fingers clear of the blade.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- Do not attempt to modify or disassemble the knife.

Specific Safety Precautions for Use

- Ensure that the blade is fully deployed and locked before use.
- Avoid using excessive force when cutting; let the blade do the work.
- Be cautious of your surroundings when using the knife to avoid accidents.
- Use a cutting board or appropriate surface when cutting to prevent damage to the blade.
- If the knife becomes stuck, do not force it; carefully assess the situation before proceeding.
- Do not use the knife in wet or slippery conditions to maintain grip and control.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the finger flipper on the blade.
- Gently push down on the finger flipper to open the blade.
- Ensure that the liner lock engages to secure the blade in the open position.

2. Using the Knife:

- Hold the knife firmly by the rubber handle.
- Position the blade at the desired cutting angle.
- Apply gentle pressure to start cutting, ensuring your fingers are away from the blade.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully closed and secured before storing.

4. Maintenance:

- Regularly clean the knife with a soft cloth to remove dirt and debris.
- Lubricate the pivot points with a suitable knife oil to ensure smooth operation.
- Store the knife in a dry place to prevent rust and corrosion.

Disposal Instructions

- When the knife reaches the end of its life or is no longer safe to use, dispose of it responsibly.
- Check local regulations for proper disposal methods for metal products.
- Consider recycling the knife if possible, to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade SCH U.G. Rub w/Fire Box, please reach out to the designated EUbased contact point provided by the manufacturer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade SCH U.G. Rub w/Fire Box. Always prioritize safety and responsible usage to make the most of your product. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för Shrade SCH U.G. Rub w/Fire Box

Introduktion

Tack för att du valt Shrade SCH U.G. Rub w/Fire Box. Denna produkt är utformad för att ge en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid produkten på en stabil och säker yta.
- Undvik att använda produkten i fuktiga eller blöta miljöer.
- Var försiktig när du hanterar bladet för att förhindra skador.
- Använd skyddshandskar vid behov för att skydda händerna.
- Håll produkten borta från ögonen och ansiktet under användning.
- Se till att produkten är i gott skick innan användning; byt ut den om den är skadad.

Instruktioner för installation och användning

1. Installation

- Kontrollera att alla delar är inkluderade innan installation.
- Följ anvisningarna noggrant för att sätta ihop produkten.
- Se till att alla skruvar och fästen är ordentligt åtdragna.

2. Användning

- Håll produkten med ett fast grepp och använd fingerflippern för att öppna bladet.
- Använd liner lockfunktionen för att säkerställa att bladet förblir på plats under användning.
- Använd snoddhålet för att fästa produkten vid en säker plats om det behövs.
- Förvara alltid produkten i ett säkert läge när den inte används.

Avfallshanteringsinstruktioner

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Återvinn produkten om möjligt, eller lämna den till en auktoriserad återvinningsstation.

Kontaktinformation för vidare support

För säkerhetsfrågor eller ytterligare information, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att vara medveten och försiktig kan du säkerställa en

trygg och effektiv användning av din Shrade SCH U.G. Rub w/Fire Box.