

SCH U.G. Rub w/Fire Box - SCH U.G. Rub w/Fire Clam Pack

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 4.6 oz
- Rubber handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. Rub w/Fire Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001563
- Mfr. No.: 1100047
- Color: Black
- Delivery weight: 0.154kg
- Shipping height: 260mm
- Shipping width: 22mm
- Shipping length: 85mm
- UPC: 661120076438

Table of Contents

- [Startpage](#)
- [English: Shrade SCH U.G. Rub w/Fire Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH U.G. Rub w/Fire Box](#)

Shrade SCH U.G. Rub w/Fire Box Safety Instruction Guide

Introduction

Thank you for choosing the Shrade SCH U.G. Rub w/Fire Box. This folding knife is designed for durability and ease of use. To ensure your safety and the safety of others, please read this guide carefully before using the product.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Inspect the knife before each use to ensure it is in safe working condition.
- Store the knife in a secure place when not in use.
- Do not use the knife for purposes other than intended.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not attempt to modify or alter the knife in any way.
- Always use the finger flipper and thumb stud to open the blade; avoid using excessive force.
- Ensure the liner lock is fully engaged before using the knife to prevent accidental closure.
- Avoid using the knife in wet or slippery conditions to prevent loss of grip.
- Use caution when cutting; keep your fingers and other body parts away from the blade.
- If the blade becomes dull, sharpen it according to the manufacturer's instructions or seek professional sharpening services.

Instructions for Installation and Usage

• Opening the Knife:

- Hold the knife securely by the rubber handle.
- Use your index finger to push the finger flipper or thumb stud to open the blade.
- Ensure the blade locks into place before use.

• Using the Knife:

- Always cut away from your body.
- Use the knife on a stable surface to prevent slipping.
- Do not force the knife through materials that it is not designed to cut.

• Closing the Knife:

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

• Using the Pocket Clip:

- Attach the pocket clip to your belt or pocket for easy access.
- Ensure the clip is secure to prevent the knife from falling.

Disposal Instructions

- Dispose of the knife responsibly at a designated waste facility.
- If the knife is damaged or no longer usable, ensure it is rendered unusable before disposal to prevent accidental injury.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Shrade SCH U.G. Rub w/Fire Box, please refer to the manufacturer's contact information included with your product packaging.

Säkerhetsinstruktioner för Shrade SCH U.G. Rub w/Fire Box

Introduktion

Tack för att du valt Shrade SCH U.G. Rub w/Fire Box. Denna produkt är utformad för att ge en säker och effektiv användning. För att säkerställa din säkerhet och för att uppfylla EU:s allmänna produkt säkerhetsregler (GPSR), vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt de angivna instruktionerna för att minimera riskerna.
- Kontrollera produkten regelbundet för skador och slitage. Använd inte en skadad produkt.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Rapportera alla osäkra produkter och olyckor till de relevanta myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en säker och stabil yta.
- Undvik att använda kniven för uppgifter som den inte är avsedd för.
- Håll kniven borta från ansiktet och kroppen under användning.
- Använd alltid knivens fingerflipper och tumstuds för att öppna bladet.
- Stäng kniven när den inte används och förvara den på en säker plats.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.

Instruktioner för installation och användning

1. Öppning av kniven:

- Använd fingerflippern eller tumstudsens för att öppna bladet.
- Se till att bladet är helt öppet och låst innan du börjar använda det.

2. Användning av kniven:

- Håll kniven med ett fast grepp om gummihandtaget.
- Använd kniven för att skära, men undvik att använda den för att bryta eller göra kraftiga rörelser.

3. Stängning av kniven:

- Tryck på liner lock för att frigöra bladet.
- Vik bladet försiktigt tillbaka i handtaget tills det klickar på plats.

4. Förvaring av kniven:

- Förvara kniven i ett torrt och svalt utrymme.
- Använd fickklämman för att fästa kniven på bältet eller i en väska för enkel tillgång.

Avfallshanteringsinstruktioner

- Kassera produkten på ett miljövänligt sätt.
- Följ lokala riktlinjer för avfallshantering och återvinning.
- Om produkten är skadad eller inte längre behövs, se till att den inte kan användas av barn eller andra

sårbara grupper.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerhet och användning av Shrade SCH U.G. Rub w/Fire Box, vänligen kontakta din lokala återförsäljare eller besök vår officiella webbplats.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.