

SCH Pocket Survival Knife Box

- 3" overall length
- 2" stainless steel blade with black oxide blade coating
- Lanyard hole and lock for knife
- Money clip, bottle opener, whistle and fire starter
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH Pocket Survival Knife Box
- Manufacturer: Shrade
- Product no.: EU1001566
- Mfr. No.: 1100050
- Color: Green
- Delivery weight: 0.054kg
- Shipping height: 13mm
- Shipping width: 56mm
- Shipping length: 52mm
- UPC: 661120076469

Table of Contents

- [Startpage](#)
- [English: Shrade SCH Pocket Survival Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH Pocket Survival Knife Box](#)

Shrade SCH Pocket Survival Knife Safety Instruction Guide

Introduction

Thank you for choosing the Shrade SCH Pocket Survival Knife. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this document carefully before using the product to familiarize yourself with its features and safety precautions.

General Safety Guidelines

- Always handle the knife with care to prevent accidental cuts or injuries.
- Keep the knife out of reach of children and individuals who may not be able to use it safely.
- Regularly inspect the knife for any signs of damage or wear. If any issues are found, do not use the knife.
- Ensure that the knife is stored in a safe place when not in use, preferably in a sheath or protective case.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.

Specific Safety Precautions for Use

- **Blade Safety:**
 - The knife features a 2inch stainless steel blade. Always ensure the blade is securely locked in place before use.
 - Avoid applying excessive force while cutting to prevent blade breakage or slipping.
- **Lanyard and Lock:**
 - Use the lanyard hole and lock feature to secure the knife when not in use, especially in outdoor environments.
- **MultiFunction Use:**
 - This knife includes additional tools such as a money clip, bottle opener, whistle, and fire starter. Use these tools for their intended purposes only.
- **Fire Starter Safety:**
 - When using the fire starter, ensure you are in a safe area away from flammable materials.
- **Pocket Clip:**
 - Use the pocket clip to secure the knife to your clothing or gear, ensuring it does not fall or become lost during use.

Instructions for Installation and Usage

- **Using the Knife:**
 - To open the knife, press the lock mechanism and carefully pull the blade out.
 - Ensure the blade is fully extended and locked before using it for cutting tasks.
 - After use, carefully fold the blade back into the handle, ensuring the lock is engaged.
- **Using the Additional Tools:**
 - **Money Clip:** Slide the clip onto your bills for secure carrying.
 - **Bottle Opener:** Position the bottle cap under the opener and apply pressure to remove the cap.
 - **Whistle:** Use the whistle in emergencies to signal for help.
 - **Fire Starter:** Scrape the metal against the flint to create sparks, igniting dry tinder.
- **Cleaning and Maintenance:**
 - Clean the blade and tools after each use with a dry cloth.
 - Avoid using harsh chemicals that may damage the blade's coating.
 - Lubricate the blade hinge periodically to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly when it is no longer usable.
- Check local regulations for proper disposal methods for metal products.
- Do not dispose of the knife in regular household waste if it is still sharp or poses a risk of injury.

Contact Information for Further Support

For any questions or safety concerns regarding the Shrade SCH Pocket Survival Knife, please reach out to your local retailer or the manufacturer directly. Ensure you have your purchase details on hand for reference.

Conclusion

By following these safety instructions, you can enjoy the functionality of your Shrade SCH Pocket Survival Knife while minimizing risks. Always prioritize safety in every use to ensure a positive experience with your product. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för Shrade SCH Pocket Survival Knife Box

Introduktion

Grattis på ditt köp av Shrade SCH Pocket Survival Knife Box. Denna överlevnadskniv är designad för att vara en praktisk och mångsidig följeslagare för utomhusaktiviteter och nödsituationer. För att säkerställa säker användning och långvarig prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och i enlighet med lokala lagar och bestämmelser.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Byt ut den om den är skadad.
- Använd kniven endast för dess avsedda syften. Undvik att använda den för uppgifter som kan orsaka skador eller olyckor.
- Vid onlineköp, se till att du handlar från betrodda och auktoriserade återförsäljare.

Specifika säkerhetsåtgärder för användning

- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.
- Håll kniven borta från ansiktet och andra kroppsdelar när du använder den.
- Använd alltid kniven i en stabil och säker position för att undvika olyckor.
- Se till att kniven är korrekt låst när den inte används för att förhindra oavsiktlig öppning.
- Använd inte kniven för att skära genom hårda material som metall eller glas.

Instruktioner för installation och användning

1. Öppning av kniven:

- Håll kniven i ena handen med bladet vänd bort från dig.
- Använd låsfunktionen för att försiktigt frigöra bladet.

2. Användning av kniven:

- Bestäm det avsedda syftet för kniven (t.ex. skärning, öppning av flaskor).
- Använd kniven med en kontrollerad och stabil rörelse.
- Efter användning, stäng kniven och lås den på plats.

3. Underhåll av kniven:

- Rengör bladet efter varje användning med en fuktig trasa för att ta bort smuts och skräp.
- Torka kniven noggrant och förvara den på en torr plats.

Avfallshanteringsinstruktioner

- När du inte längre behöver kniven, se till att den är inaktiv och säker för avfall.
- Följ lokala riktlinjer för avfallshantering och återvinning av metallprodukter.
- Om kniven är skadad, se till att den är oåtkomlig innan du kasserar den för att förhindra olyckor.

Kontaktinformation för vidare stöd

För frågor om säkerhet eller produktinformation, vänligen kontakta en auktoriserad återförsäljare eller tillverkare. Se till att ha produktens modellnummer tillgängligt när du kontaktar.

Genom att följa dessa säkerhetsinstruktioner kan du njuta av din Shrade SCH Pocket Survival Knife Box på ett säkert och ansvarsfullt sätt. Tack för att du prioriterar säkerhet!