

SCH Pocket Survival Knife Box - Shrade SCH Pocket Survival Knife Clam Pack

- 3" overall length
- 2" stainless steel blade with black oxide blade coating
- Lanyard hole and lock for knife
- Money clip, bottle opener, whistle and fire starter
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH Pocket Survival Knife Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001567
- Mfr. No.: 1100051
- Color: Green
- Delivery weight: 0.059kg
- Shipping height: 150mm
- Shipping width: 16mm
- Shipping length: 52mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade SCH Pocket Survival Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH Pocket Survival Knife](#)

Shrade SCH Pocket Survival Knife Safety Instructions

Introduction

Thank you for choosing the Shrade SCH Pocket Survival Knife. This guide provides important safety instructions to ensure the safe and effective use of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear before use.
- Ensure the knife is stored in a safe and secure location when not in use.
- Do not use the knife for purposes other than intended.
- Follow all local laws and regulations regarding knife ownership and carry.

Specific Safety Precautions for Use

- **Blade Safety:**
 - Handle the blade with care to avoid cuts or injuries.
 - Always cut away from your body and keep your hands clear of the cutting path.
- **Lock Mechanism:**
 - Ensure the knife is locked in place when in use to prevent accidental closure.
 - Check the lock mechanism before each use to ensure it is functioning properly.
- **Lanyard Hole and Clip:**
 - Use the lanyard hole and pocket clip to secure the knife when not in use.
 - Do not attach the knife to any unstable or unsafe surfaces.
- **MultiFunction Features:**
 - Be cautious when using the money clip, bottle opener, whistle, and fire starter to avoid injury.
 - Familiarize yourself with the operation of each feature before use.

Instructions for Installation and Usage

1. Opening the Knife:

- Press the lock mechanism to release the blade.
- Gently pull the blade out until it is fully extended.
- Ensure the blade is locked in place before use.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Use a stable surface to cut, ensuring your hands and body are positioned safely away from the blade.
- Use the knife for cutting, slicing, or other intended functions only.

3. Closing the Knife:

- Press the lock mechanism to unlock the blade.
- Carefully fold the blade back into the handle until it clicks into place.
- Ensure the blade is fully retracted before storing.

4. Storing the Knife:

- Store the knife in a dry, secure place.
- Avoid damp or humid environments to prevent rust on the blade.
- Ensure the knife is out of reach of children and pets.

Disposal Instructions

- Dispose of the knife responsibly at the end of its life.
- If the knife is damaged or no longer functional, wrap it securely to prevent injury and dispose of it in accordance with local regulations.
- Consider recycling materials where possible.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade SCH Pocket Survival Knife, please consult the manufacturer's website or contact your local distributor for assistance.

Thank you for your attention to these safety instructions. Enjoy using your Shrade SCH Pocket Survival Knife responsibly.

Säkerhetsinstruktioner för Shrade SCH Pocket Survival Knife

Introduktion

Tack för att du valt Shrade SCH Pocket Survival Knife. Denna kniv är utformad för att ge säker och effektiv användning i olika överlevnadssituationer. För att säkerställa din säkerhet och optimala prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och ansvar.
- Håll kniven utom räckhåll för barn och oinvidga.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsedda ändamål.
- Vid transport, se till att kniven är säker för att undvika oavsiktlig skada.

Specifika säkerhetsåtgärder för användning

- **Skärskador:** Var alltid medveten om var knivens blad är. Använd den på en säker yta och rikta alltid bladet bort från kroppen.
- **Rostfritt stål:** Bladet är tillverkat av rostfritt stål med svart oxidbeläggning. Undvik att utsätta kniven för extremt fuktiga miljöer för att förhindra korrosion.
- **Snoddhål och lås:** Använd snoddhålet för säker förvaring och transport. Se till att låset är ordentligt stängt när kniven inte används.
- **Multifunktionella verktyg:** Var försiktig när du använder pengaklippare, flasköppnare, visselpipa och tändare. Använd dem endast för de avsedda syftena.

Instruktioner för installation och användning

1. **Öppna kniven:** Tryck på låset och försiktigt fäll ut bladet tills det klickar på plats.
2. **Användning av bladet:** Använd kniven för att skära, skrapa eller klippa. Se till att du har ett fast grepp och håll kniven i en vinkel som minimerar risken för skador.
3. **Stäng kniven:** När du är klar, tryck på låset och fäll försiktigt tillbaka bladet till handtaget.
4. **Fickklämman:** Använd fickklämman för att fästa kniven på bältet eller i fickan för enkel åtkomst.

Avfallshantering

- Avfallshantering av kniven ska ske enligt lokala föreskrifter för avfallshantering.
- Om kniven är skadad eller inte längre säker att använda, överväg att återvinna metallen där det är möjligt.

Kontaktinformation för vidare stöd

För frågor om säkerhet eller produktinformation, vänligen kontakta din återförsäljare eller tillverkare. Det finns också en EUbaserad kontaktpunkt för säkerhetsförfrågningar.

Slutord

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din Shrade SCH Pocket Survival Knife. Tack för att du är en ansvarsfull användare och bidrar till en säker miljö.