

SCH 12" Axe Box - SCH 4" Fixed Blade Para Clam

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 4" Fixed Blade Para Clam
- Manufacturer: Shrade
- Product no.: EU1001744
- Mfr. No.: 1121087
- Color: Black
- Delivery weight: 0.55kg
- UPC: 661120081609

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH 12" Axe Box SCH 4" Fixed Blade Para Clam](#)
- [Svenska: Säkerhetsanvisningar för Shrade SCH 12" Axe Box och SCH 4" Fixed Blade](#)

Safety Instruction Guide for Shrade SCH 12" Axe Box SCH 4" Fixed Blade Para Clam

Introduction

Thank you for choosing the Shrade SCH 12" Axe Box SCH 4" Fixed Blade Para Clam. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this guide carefully before using the axe and fixed blade knife.

General Safety Guidelines

- Always keep the axe and knife out of reach of children.
- Inspect the axe and knife before each use for any signs of damage or wear.
- Use the axe and knife only for their intended purposes.
- Store the axe and knife in a safe place when not in use.
- Always use protective gear, such as gloves and safety glasses, when using the axe and knife.
- Be aware of your surroundings and ensure that no one is in the vicinity when using the axe or knife.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always handle the blade with care to avoid cuts and injuries.
 - Do not attempt to catch a falling axe or knife.
- **Cutting Surface:**
 - Use a stable and flat surface when cutting or chopping.
 - Ensure that the cutting surface is free from obstacles.
- **Lanyard Use:**
 - Use the lanyard hole to secure the axe when working at heights to prevent accidental drops.
- **Sheath Usage:**
 - Always use the included sheath when storing or transporting the knife to protect the blade and prevent injuries.
- **Distraction:**
 - Avoid distractions while using the axe or knife to maintain focus and control.

Instructions for Installation and Usage

- **Using the Axe:**
 1. Ensure the axe is securely held with both hands.
 2. Stand with your feet shoulderwidth apart for stability.
 3. Swing the axe downward in a controlled motion, aiming for the target.
 4. After use, clean the axe and dry it thoroughly to prevent rust.
- **Using the Fixed Blade Knife:**
 1. Remove the knife from its sheath carefully.
 2. Hold the knife firmly, ensuring your fingers are away from the blade.
 3. Use the knife for cutting tasks only; do not use it for prying or twisting.
 4. After use, clean the knife and return it to the sheath.

Disposal Instructions

- Dispose of the axe and knife responsibly at a designated waste disposal facility.
- Follow local regulations for disposal of metal products.
- Do not throw the axe or knife in regular trash to avoid injury to waste handlers.

Contact Information for Further Support

For safety inquiries or further information regarding the Shrade SCH 12" Axe Box SCH 4" Fixed Blade Para Clam, please refer to the official Shrade website or contact their customer service.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy your Shrade products responsibly!

Säkerhetsanvisningar för Shrade SCH 12" Axe Box och SCH 4" Fixed Blade

Introduktion

Tack för att du valt Shrade SCH 12" Axe Box och SCH 4" Fixed Blade. Dessa verktyg är designade för att ge hög prestanda och säkerhet. För att säkerställa en trygg användning av produkten, vänligen läs igenom och följ dessa säkerhetsanvisningar noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador. Använd inte om den är skadad.
- Rapportera osäkra produkter och olyckor till behöriga myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar axeln eller kniven.
- Se till att du har en stabil och säker arbetsyta när du använder verktygen.
- Undvik att använda produkten i närheten av brandfarliga material.
- Förvara alltid produkten i det medföljande fodralet när den inte används.
- Använd aldrig produkten för syften som den inte är avsedd för.

Instruktioner för installation och användning

- Innan du använder produkten, kontrollera att den är i gott skick och att inga delar är lösa.
- För axeln:
 - Håll i handtaget med båda händerna för att säkerställa stabilitet.
 - Använd en säker och korrekt teknik för att undvika olyckor.
- För den fasta kniven:
 - Ta bort kniven från fodralet med försiktighet.
 - Använd kniven på ett säkert sätt, undvik att rikta den mot dig själv eller andra.
- Efter användning, rengör och torka av verktygen för att förhindra rost och skador.

Avfallshantering

- Kasta inte produkten i vanligt hushållsavfall.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Återvinn om möjligt, och se till att alla delar hanteras på ett miljövänligt sätt.

Kontaktinformation för ytterligare support

För frågor om säkerhet eller om du behöver mer information om produkten, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Se till att ha produktens modellnummer och köpdato till hands för snabbare hjälp.

Tack för att du följer dessa säkerhetsanvisningar. Din säkerhet är vår prioritet!