

SCH 12" Axe Box - SCH 4" Fixed Blade Drop Point Box

- 9CR18MOV STEEL BLADE, INJECTION PP & TPR HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 4" Fixed Blade Drop Point Box
- Manufacturer: Shrade
- Product no.: EU1001767
- Mfr. No.: 1124286
- Size: 4
- Delivery weight: 0.01kg
- UPC: 661120081630

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe and SCH 4" Fixed Blade Drop Point Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe och SCH 4" Fixed Blade Drop Point](#)

Shrade SCH 12" Axe and SCH 4" Fixed Blade Drop Point Safety Instruction Guide

Introduction

Thank you for choosing the Shrade SCH 12" Axe and SCH 4" Fixed Blade Drop Point. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before using the axe and knife.

General Safety Guidelines

- Always handle knives and axes with care to prevent injury.
- Keep the blade and edge sharp for effective cutting; dull blades can slip and cause accidents.
- Store the axe and knife in a safe place, out of reach of children.
- Always use the axe and knife for their intended purposes only.
- Inspect the axe and knife for any damage before each use, and do not use if damaged.
- Follow all local laws and regulations regarding the use of knives and axes.

Specific Safety Precautions for Use

- **Blade Safety:**
 - Always cut away from your body and keep your fingers clear of the blade's path.
 - Use a stable surface when cutting or chopping.
- **Handling the Axe:**
 - Grip the handle firmly and maintain a stable stance.
 - Do not swing the axe near other people or pets.
- **Using the Fixed Blade Knife:**
 - Use the knife on a cutting board or a designated surface.
 - Do not use the knife for prying or as a screwdriver.
- **Lanyard Hole:**
 - If using the lanyard hole, ensure the lanyard is securely attached to prevent dropping.
- **Sheath Usage:**
 - Always keep the blade covered with the sheath when not in use.
 - Do not carry the knife or axe without the sheath for safety.

Instructions for Installation and Usage

1. Using the Axe:

- Ensure the axe is clean and dry before use.
- Stand with feet shoulderwidth apart and hold the axe firmly.
- Swing the axe downwards with controlled force, aiming at the target.
- Always check the area for bystanders before swinging.

2. Using the Fixed Blade Knife:

- Remove the knife from its sheath carefully.
- Hold the knife firmly by the handle, ensuring your fingers are away from the blade.
- Perform cutting tasks as needed, ensuring a stable grip.
- After use, wipe the blade clean and return it to the sheath.

3. Maintenance:

- Regularly clean the blade with soap and water, then dry thoroughly.
- Periodically check the handle for any signs of wear or damage.
- Sharpen the blade as necessary to maintain cutting efficiency.

Disposal Instructions

- Dispose of the axe and knife responsibly.
- If the product is no longer usable, wrap the blades securely in a sturdy material to prevent injury during disposal.
- Check local regulations for proper disposal methods of sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade SCH 12" Axe and SCH 4" Fixed Blade Drop Point, please contact the appropriate EUbased customer service representative. Ensure that you have your product details available for reference.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your Shrade products. Always prioritize safety and be mindful of your surroundings when using knives and axes. Thank you for your attention to these important safety instructions.

Säkerhetsinstruktioner för Shrade SCH 12" Axe och SCH 4" Fixed Blade Drop Point

Introduktion

Tack för att du valt Shrade SCH 12" Axe och SCH 4" Fixed Blade Drop Point. Denna produkt är designad för att ge hög kvalitet och prestanda. För att säkerställa en trygg och säker användning av denna produkt, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt anvisningarna.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Inspektera produkten regelbundet för skador eller slitage. Använd inte produkten om den är skadad.
- Förvara produkten på en säker plats när den inte används.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar produkten.
- Se till att du har ett stabilt grepp om handtaget innan du använder produkten.
- Använd produkten endast för dess avsedda syfte.
- Undvik att använda produkten i trånga utrymmen där det kan vara svårt att manövrera.
- Var medveten om din omgivning och se till att ingen annan befinner sig i närheten när du använder produkten.

Instruktioner för installation och användning

1. Installation:

- Kontrollera att alla delar är inkluderade i förpackningen.
- Fäst handtaget på bladet enligt tillverkarens anvisningar.
- Se till att alla skruvar och fästen är ordentligt åtdragna innan användning.

2. Användning:

- Håll produkten med båda händerna för bättre kontroll.
- Använd ett stabilt underlag när du arbetar med produkten.
- Skär alltid bort från kroppen för att minimera risken för skador.
- Om produkten ska användas för att hugga, se till att det finns tillräckligt med utrymme runt dig.

Avfallsinstruktioner

- Kasta inte produkten i vanliga hushållsavfall.
- Kontakta din lokala avfallshantering för information om korrekt avfallshantering av metallprodukter.
- Återvinn materialet om möjligt.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om säkerhetsåtgärder, vänligen kontakta tillverkaren eller din lokala återförsäljare. Se till att ha produktens modellnummer tillgängligt för snabbare hjälp.

Avslutande anmärkningar

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din Shrade SCH 12" Axe och SCH 4" Fixed Blade Drop Point. Tack för att du bidrar till en säker användning av produkter!