

4.25" Fixed Blade Box - Shrade 4.25" Fixed Blade Clam

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Hard polymer sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade 4.25" Fixed Blade Clam
- Manufacturer: Shrade
- Product no.: EU1001770
- Mfr. No.: 1124289
- Size: 4.25
- Delivery weight: 0.01kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade 4.25" Fixed Blade Knife](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 4.25" Fixed Blade Kniv](#)

Safety Instruction Guide for Shrade 4.25" Fixed Blade Knife

Introduction

Thank you for purchasing the Shrade 4.25" Fixed Blade Knife. This guide is designed to provide you with essential safety instructions to ensure the safe use and maintenance of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children.
- Use the knife only for its intended purpose.
- Inspect the knife before each use for any signs of damage or wear.
- Store the knife in a safe place, preferably in its sheath, when not in use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the blade is sharp before use. A dull blade can be more dangerous as it requires more force to cut.
- Always cut away from your body and keep your fingers clear of the cutting path.
- Do not use the knife for prying or as a screwdriver.
- Wear appropriate personal protective equipment (PPE), such as gloves, if necessary.
- Avoid using the knife in wet conditions to prevent slipping.

Instructions for Installation and Usage

• Unpacking the Knife:

- Carefully remove the knife from the packaging.
- Inspect the knife and sheath for any damage.

• Using the Knife:

- Hold the knife firmly by the handle.
- If applicable, attach a lanyard through the lanyard hole for added security.
- Use the knife on a stable surface to prevent accidents.

• Cleaning and Maintenance:

- Clean the blade after each use with a soft cloth.
- Avoid using abrasive cleaners that may damage the blade or handle.
- Store the knife in its hard polymer sheath to protect the blade and prevent accidents.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, ensure that it is safely discarded to prevent accidents.
- Follow local regulations for the disposal of sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade 4.25" Fixed Blade Knife, please refer to the contact information provided with your product.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your Shrade 4.25" Fixed Blade Knife. Thank you for your attention to safety.

Säkerhetsinstruktioner för Shrade 4.25" Fixed Blade Kniv

Introduktion

Tack för att du har valt Shrade 4.25" Fixed Blade kniv. Denna guide ger viktiga säkerhetsinstruktioner för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom dessa instruktioner noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert sätt och i enlighet med tillverkarens instruktioner.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Vid onlineköp, säkerställ att du köper från en auktoriserad återförsäljare för att garantera produktens säkerhet.
- Rapportera alla osäkra produkter och olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsedda ändamål. Undvik att använda den för att skära hårda eller oegentliga material.
- Håll alltid kniven i en stabil position när du använder den för att förhindra olyckor.
- Använd skyddshandskar om möjligt för att skydda händerna.
- Förvara kniven i den medföljande hårda polymerfickan när den inte används för att förhindra skador.
- Var alltid uppmärksam på omgivningen när du använder kniven för att undvika att skada andra.

Instruktioner för installation och användning

- Ta bort kniven från förpackningen försiktigt för att undvika skador.
- Kontrollera att kniven är i gott skick innan användning. Titta efter sprickor eller andra defekter.
- Håll kniven med ett fast grepp, med fingrarna borta från bladets kant.
- Använd ett skärunderlag för att skydda ytor och för att säkerställa en stabil arbetsyta.
- Rengör kniven efter varje användning med mild tvål och vatten. Torka noggrant för att förhindra rost.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfall. Kontakta din lokala avfallshantering för riktlinjer för säker avfallshantering av vassa föremål.
- Återvinn förpackningen i enlighet med lokala återvinningsregler.

Kontaktinformation för vidare support

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller återförsäljaren där du köpte kniven. Se till att ha produktens information tillgänglig för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda kniven på ett säkert sätt skyddar du dig själv och andra.