

3.25" Ultraglide Folder Box

- 9CR18MOV STEEL BLADE, GLASS FIBER NYLON HANDLE
- Liner lock
- Dual thumb studs
- Lanyard hole
- Stonewash finish blade

NO IMAGE
AVAILABLE

Attributes

- Name: 3.25" Ultraglide Folder Box
- Manufacturer: Shrade
- Product no.: EU1001771
- Mfr. No.: 1124290
- Size: 3.25"
- Delivery weight: 0.01kg
- UPC: 661120081678

Table of Contents

- [Startpage](#)
- [English: Shrade 3.25" Ultraglide Folder Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.25" Ultraglide Folder Box](#)

Shrade 3.25" Ultraglide Folder Box Safety Instruction Guide

Introduction

Thank you for choosing the Shrade 3.25" Ultraglide Folder Box. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this guide carefully before using the product to understand how to avoid potential hazards and ensure a safe experience.

General Safety Guidelines

- Always use the knife for its intended purpose to avoid accidents.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- If the knife is damaged, do not use it and seek a replacement.
- Always cut away from your body and keep your fingers clear of the blade.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.
- Be cautious when using the knife in wet or slippery conditions, as this may increase the risk of accidents.

Specific Safety Precautions for Use

- Ensure the blade is fully locked in place before using the knife.
- Avoid using excessive force when cutting; let the blade do the work.
- Do not attempt to modify or disassemble the knife.
- Use the dual thumb studs to open the knife safely, ensuring your fingers are clear of the blade path.
- If the knife is equipped with a lanyard hole, use it to secure the knife during use to prevent accidental drops.
- Do not use the knife for prying or as a lever, as this may damage the blade and pose a safety risk.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your thumb to press on one of the dual thumb studs to open the blade.
- Ensure the blade is fully extended and locked in place before use.

2. Using the Knife:

- Position the item you wish to cut securely.
- Hold the knife with a firm grip and cut away from your body.
- Maintain awareness of your surroundings to avoid accidents.

3. Closing the Knife:

- To close the knife, press the liner lock located on the handle.
- Carefully fold the blade back into the handle while ensuring your fingers are clear of the blade path.

4. Cleaning and Maintenance:

- Clean the blade and handle with a soft cloth after each use.
- Avoid using abrasive materials that may scratch the surface.

- Regularly oil the pivot point to ensure smooth opening and closing.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, ensure it is disposed of in a manner that prevents injury to others.
- Consider recycling metal components where possible.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade 3.25" Ultraglide Folder Box, please refer to the product packaging or visit the official website for further assistance.

Conclusion

By following these safety instructions, you can help ensure a safe and enjoyable experience with your Shrade 3.25" Ultraglide Folder Box. Always prioritize safety and be mindful of the proper use and care of your knife. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för Shrade 3.25" Ultraglide Folder Box

Introduktion

Tack för att du valt Shrade 3.25" Ultraglide Folder Box. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för korrekt användning av produkten. Vänligen läs igenom hela dokumentet noggrant innan du använder kniven för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt anvisningarna för att minimera risken för skador.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Använd inte kniven om den är skadad eller om delar saknas.
- Rapportera alla osäkra produkter eller olyckor till lämpliga myndigheter.

Specifika säkerhetsåtgärder för användning

- Var alltid medveten om var knivens blad är placerat för att undvika oavsiktliga skador.
- Använd kniven på en stabil yta och håll den borta från kroppen under användning.
- Stäng alltid kniven när den inte används för att förhindra oavsiktlig öppning.
- Använd inte kniven för uppgifter den inte är avsedd för, såsom att öppna burkar eller som en skruvmejsel.
- Var försiktig när du hanterar bladet efter att det har slipats eller rengjorts.

Instruktioner för installation och användning

1. Öppna kniven:

- Tryck på den dubbla tummknappen för att frigöra låset.
- Fäll ut bladet tills det låses på plats.

2. Använda kniven:

- Håll kniven i ett fast grepp med handtaget i en säker position.
- Skär alltid bort från kroppen och håll fingrarna borta från bladets väg.

3. Stänga kniven:

- Tryck på den dubbla tummknappen för att frigöra låset.
- Vik bladet tillbaka in i handtaget tills det låser sig på plats.

4. Underhåll:

- Rengör bladet regelbundet med en mjuk trasa.
- Smörj gångjärnet med lämplig olja för att säkerställa smidig funktion.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet.
- Följ lokala riktlinjer för avfallshantering när du ska kassera kniven.
- Om kniven är skadad och inte kan användas, se till att den förvaras på en säker plats tills den kan

kasseras korrekt.

Kontaktinformation för vidare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller besök vår webbplats för mer information.

Tack för att du använder Shrade 3.25" Ultraglide Folder Box. Din säkerhet är vår prioritet.