

MEC 600 JR MARK V SHOT SHELL PRESS - MEC RELOADING 600 JR. MARK 5 SINGLE STAGE PRESS 410 GAUGE 2-1/2"

The MEC 600 Jr. has features normally found only on the high-end models making it one of the most popular, economical single-stage shotshell reloaders on the market today. Fast and efficient operation allows loading eight to ten boxes per hour, plus easily upgrades to the 285 CA primer feed system, which eliminates the need to handle each primer individually. Adjustable for 3" shells, and available in 12, 20, 28 gauge and .410 bore. Includes 1 Charge Bar & 3 Powder Bushings.

MEC 600 Jr Mark V Shot Shell Press, 410 Cal



Attributes

- Name: MEC RELOADING 600 JR. MARK 5 SINGLE STAGE PRESS 410 GAUGE 2-1/2"
- Manufacturer: MEC RELOADING
- Product no.: 749010670
- Mfr. No.: 1008447410
- Gauge: .410 Bore
- Delivery weight: 6.713kg
- Shipping height: 577mm
- Shipping width: 244mm
- Shipping length: 437mm
- UPC: 098489016179

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: MEC 600 JR MARK V SHOT SHELL PRESS Safety Instructions](#)
- [Svenska: Säkerhetsanvisningar för MEC 600 JR MARK V SHOT SHELL PRESS](#)

MEC 600 JR MARK V SHOT SHELL PRESS Safety Instructions

Introduction

Thank you for choosing the MEC 600 Jr Mark V Shot Shell Press. This manual provides important safety instructions and guidelines to ensure the safe and effective use of your reloading press. Please read this guide carefully before using the product to familiarize yourself with its features and safety precautions.

General Safety Guidelines

- Always read and understand the manufacturer's instructions before using the MEC 600 Jr Mark V Shot Shell Press.
- Ensure that you are in a wellventilated area while using the press to avoid inhalation of dust or fumes.
- Keep the workspace clean and organized to prevent accidents.
- Store the press and all components in a dry location, away from moisture and extreme temperatures.
- Use the press only for its intended purpose, which is to reload shot shells for personal use.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when operating the press.

Specific Safety Precautions for Use

- Ensure that the press is securely mounted to a stable workbench before use.
- Do not overload the press beyond its specified capacity.
- Keep hands and fingers clear of moving parts during operation to avoid injury.
- Always check for proper alignment and secure attachment of components before starting the reloading process.
- Handle all components, including primers and powder, with care to avoid accidental ignition or spills.
- Never leave the press unattended while in operation.
- If you experience any unusual sounds or resistance during operation, stop immediately and inspect the press for any issues.

Instructions for Installation and Usage

Installation

1. **Choose a Suitable Location:** Select a stable, flat surface for mounting the press. Ensure that the area is welllit and free from distractions.
2. **Secure the Press:** Use bolts or screws to firmly attach the press to the workbench, ensuring it is stable and will not move during operation.
3. **Check Alignment:** Confirm that all components are aligned correctly and securely fastened before proceeding.

Usage

1. **Preparation:** Gather all necessary materials, including shot shells, powder, primers, and tools. Ensure you have a clean workspace.
2. **Loading Components:**
 - Follow the manufacturer's instructions for loading primers, powder, and shot into the press.
 - Doublecheck that all components are correctly positioned and secure.
3. **Operation:**
 - Operate the press smoothly and steadily. Avoid sudden movements.
 - Monitor the reloading process closely to ensure everything is functioning properly.
4. **PostUse:**

- Clean the press after each use to remove any residue.
- Store all components safely and securely after reloading.

Disposal Instructions

- Dispose of any unused or expired materials, such as primers and powder, in accordance with local regulations.
- Do not dispose of these materials in regular household waste.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the MEC 600 Jr Mark V Shot Shell Press, please refer to the manufacturer's customer service resources. It is important to have access to reliable support for any safety inquiries or product issues.

Reporting Unsafe Products

If you encounter any unsafe products or accidents, report them to the appropriate authorities. Stay informed about product recalls and safety updates by checking the EU's Safety Gate platform regularly.

By following these safety instructions, you can ensure a safe and enjoyable reloading experience with your MEC 600 Jr Mark V Shot Shell Press. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

Säkerhetsanvisningar för MEC 600 JR MARK V SHOT SHELL PRESS

Introduktion

Tack för att du valt MEC 600 JR MARK V SHOT SHELL PRESS. Denna manual innehåller viktiga säkerhetsanvisningar och riktlinjer för korrekt användning och underhåll av produkten. Vänligen läs igenom denna information noggrant för att säkerställa säkerheten vid användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll arbetsområdet rent och fritt från skräp för att undvika olyckor.
- Använd lämplig personlig skyddsutrustning, inklusive skyddsglasögon och handskar.
- Håll produkten utom räckhåll för barn och sårbara personer.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Kontrollera alltid att pressen är korrekt installerad innan användning.
- Använd endast rekommenderade hylsor och komponenter för att undvika skador.
- Ladda inte mer än det rekommenderade antalet patroner samtidigt.
- Undvik att rikta pressen mot dig själv eller andra under användning.
- Stäng av och koppla bort strömmen vid underhåll eller reparationer.
- Följ alltid tillverkarens anvisningar för justeringar och uppgraderingar.

Instruktioner för installation och användning

1. Installation

- Placera pressen på en stabil och plan yta.
- Använd skruvar eller klämmor för att fästa pressen ordentligt.
- Kontrollera att alla delar är korrekt monterade innan du börjar använda pressen.

2. Användning

- Fyll i hylsorna med rätt mängd krut och projektiler.
- Justera pressen för att passa 3" hylsor om så behövs.
- Utför en testladdning för att säkerställa att pressen fungerar korrekt innan du laddar flera patroner.
- Ladda patroner i enlighet med de rekommenderade riktlinjerna för säkerhet och effektivitet.

Avfallshanteringsanvisningar

- Avfall och oanvända produkter ska hanteras i enlighet med lokala föreskrifter för farligt avfall.
- Kontakta lokala myndigheter för information om korrekt avfallshantering.

Kontaktinformation för ytterligare support

För frågor eller ytterligare support, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare hjälp.

Genom att följa dessa säkerhetsanvisningar kan du säkerställa en säker och effektiv användning av MEC 600 JR MARK V SHOT SHELL PRESS. Tack för att du tar ansvar för din säkerhet och andras.