

5 ft. Extendable Tree Saw (1001) - 301UH/PH2N Stag Horn Skinner Combo

- D2 Steel Satin Finish Blade Stag Horn Handle
- Full Tang
- Brass Pins
- Lanyard Hole
- Leather Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: 301UH/PH2N Stag Horn Skinner Combo
- Manufacturer: Uncle Herry
- Product no.: EU1000422
- Mfr. No.: 1085926
- Color: Green/Black
- Delivery weight: 1.089kg
- Shipping height: 109mm
- Shipping width: 94mm
- Shipping length: 400mm
- UPC: 661120414452

Table of Contents

- [Startpage](#)
- [English: Uncle Henry 5 ft. Extendable Tree Saw \(1001\) Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Henry 5 ft. Extendable Tree Saw \(1001\) 301UH/PH2N Stag Horn Skinner Combo](#)

Uncle Henry 5 ft. Extendable Tree Saw (1001)

Safety Instructions

Introduction

Thank you for choosing the Uncle Henry 5 ft. Extendable Tree Saw. This manual provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this manual thoroughly before using the saw to understand potential hazards and how to avoid them.

General Safety Guidelines

- Always use the tree saw in accordance with the manufacturer's instructions.
- Ensure that you are in a safe environment before using the saw, free from obstacles and bystanders.
- Wear appropriate personal protective equipment (PPE), including gloves, safety glasses, and sturdy footwear.
- Keep the saw out of reach of children and unauthorized users.
- Regularly inspect the saw for any damage or wear before each use. Do not use a damaged tool.
- Store the saw in a dry, secure place when not in use.
- Follow all local regulations regarding the use of cutting tools and equipment.

Specific Safety Precautions for Use

- **Cutting Area:** Ensure that the area around the cutting site is clear of people, pets, and obstacles.
- **Stability:** Maintain a stable stance while using the saw to prevent slipping or losing balance.
- **Cutting Technique:** Always cut away from your body and keep your hands clear of the cutting path.
- **Extension Use:** When extending the saw, ensure that it is locked securely in place before use.
- **Distractions:** Avoid any distractions while using the saw. Stay focused on your task.
- **Weather Conditions:** Do not use the saw in wet or slippery conditions to prevent accidents.

Instructions for Installation and Usage

1. Inspection Before Use:

- Check the blade for sharpness and any signs of damage.
- Ensure the stag horn handle is secure and free from cracks.

2. Extending the Saw:

- To extend the saw, locate the locking mechanism.
- Pull the extension gently while holding the base of the saw.
- Once extended, ensure the locking mechanism is fully engaged.

3. Using the Saw:

- Position yourself securely and assess the branch or material to be cut.
- Hold the saw with both hands, using one hand on the handle and the other for stability.
- Begin cutting with a smooth, steady motion. Avoid forcing the saw through the material.

4. After Use:

- Clean the blade and handle with a dry cloth to remove any debris.
- Store the saw in its leather sheath to protect the blade and prevent accidents.

Disposal Instructions

- Dispose of the saw in accordance with local regulations.
- If the saw is damaged beyond repair, consider recycling the materials where possible.
- Do not dispose of the saw in regular household waste if it can pose a hazard.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Uncle Henry 5 ft. Extendable Tree Saw, please reach out to your local retailer or the manufacturer's customer service. They can provide assistance and address any questions you may have about the product.

Thank you for prioritizing safety while using the Uncle Henry 5 ft. Extendable Tree Saw. Enjoy your cutting tasks responsibly!

Säkerhetsinstruktioner för Uncle Herny 5 ft. Extendable Tree Saw (1001) 301UH/PH2N Stag Horn Skinner Combo

Introduktion

Tack för att du valt Uncle Herny 5 ft. Extendable Tree Saw. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för användning av produkten. Vänligen läs igenom dessa instruktioner noggrant innan du använder produkten för att säkerställa säker användning och för att undvika olyckor.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara personer.
- Kontrollera produkten före användning för att säkerställa att den är i gott skick och fri från skador.
- Använd alltid lämplig personlig skyddsutrustning, inklusive skyddsglasögon och handskar.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd inte produkten om du är trött eller under påverkan av alkohol eller droger.
- Se till att arbetsområdet är rent och fritt från hinder innan du använder sågen.
- Använd inte sågen på instabila eller lutande ytor.
- Håll alltid båda händerna på sågens handtag under användning.
- Använd aldrig sågen för andra ändamål än avsedda, såsom att skära material som inte är trä.

Instruktioner för installation och användning

1. Installation av sågen:

- Kontrollera att alla delar är inkluderade och i gott skick.
- Följ installationsanvisningarna i produktens manual för att montera sågen korrekt.
- Se till att alla skruvar och fästen är åtdragna innan användning.

2. Användning av sågen:

- Justera sågen till önskad längd innan du börjar använda den.
- Håll sågen i en stabil och säker position när du börjar skära.
- Gör alltid långa, jämna drag när du använder sågen för att undvika skador.
- Om sågen fastnar, stäng av den och ta bort den från materialet innan du försöker frigöra den.

Avfallshanteringsinstruktioner

- När produkten inte längre är i bruk, se till att den kasseras på ett miljövänligt sätt.
- Följ lokala riktlinjer för avfallshantering och återvinning av metall och plastmaterial.
- Lämna eventuella batterier eller elektriska komponenter till en auktoriserad återvinningsstation.

Kontaktinformation för vidare stöd

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta tillverkaren eller återförsäljaren där produkten

köptes. De kan ge ytterligare information och support angående säker användning av produkten.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och effektiv användning av Uncle Herry 5 ft. Extendable Tree Saw. Tack för att du bidrar till en säker användning av våra produkter!