

16 ft. Extendable Tree Saw - Uncle Herny UH Staglon 4" FB w/Leather Clam Pack

- Full Tang
- 7Cr17MoV steel with 4.25" blade length and weighs 5.3 oz
- Next Gen staglon handle with satin blade finish and nickel silver finger guard
- Leather lanyard strap and lanyard hole
- Leather sheath

NO IMAGE
AVAILABLE

Attributes

- Name: Uncle Herny UH Staglon 4" FB w/Leather Clam Pack
- Manufacturer: Uncle Herny
- Product no.: EU1000424
- Mfr. No.: 1100035
- Color: Green/Black
- Shipping height: 1,270mm
- Shipping width: 216mm
- Shipping length: 76mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Uncle HERNY 16 ft. Extendable Tree Saw and UH Staglon 4" FB w/Leather Clam Pack](#)
- [Svenska: Säkerhetsinstruktioner för Uncle HERNY 16 ft. Extendable Tree Saw](#)

Safety Instruction Guide for Uncle Herny 16 ft. Extendable Tree Saw and UH Staglon 4" FB w/Leather Clam Pack

Introduction

Thank you for choosing the Uncle Herny 16 ft. Extendable Tree Saw and UH Staglon 4" FB w/Leather Clam Pack. This guide provides essential safety information to ensure the safe use of your product. Please read this manual carefully before using the saw to prevent accidents and injuries.

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the saw for any damage or wear before each use.
- Ensure that the working area is clear of obstacles and bystanders.
- Use the product only for its intended purpose, as described in this manual.
- Wear appropriate personal protective equipment (PPE) such as gloves, safety glasses, and sturdy footwear.
- Be aware of your surroundings and avoid using the product in adverse weather conditions.
- Follow local regulations regarding tree cutting and maintenance.

Specific Safety Precautions for Use

- Ensure that the blade is sharp and properly secured before use.
- Do not attempt to cut branches that are larger than the saw's capacity.
- Always maintain a firm grip on the handle while using the saw.
- Use the saw with both hands for better control and stability.
- Avoid cutting above shoulder height to reduce the risk of falling debris.
- Do not use the saw if you are tired, under the influence of drugs or alcohol, or if you are not in a stable position.
- If the saw becomes stuck, do not attempt to force it; instead, carefully remove it from the cut.
- Always store the saw in a safe place when not in use, preferably in its sheath.

Instructions for Installation and Usage

Installation

- Ensure that the saw is fully assembled according to the manufacturer's instructions.
- Check that all components are securely attached and in good condition.

Usage

- Before using the saw, familiarize yourself with its features and functions.
- To extend the tree saw, follow the manufacturer's instructions carefully to avoid damage.
- Position yourself securely and ensure that your footing is stable before starting to cut.
- Begin cutting with a slow, steady motion, applying even pressure.
- After completing the cut, retract the saw and store it safely.

Disposal Instructions

- Dispose of the product in accordance with local regulations.

- Do not dispose of the saw in regular household waste.
- Consider recycling options for metal and other materials.

Contact Information for Further Support

For any safety inquiries or support regarding your Uncle Henry product, please refer to the appropriate contact channels provided by the manufacturer or retailer.

Conclusion

By following these safety instructions, you will ensure a safer experience while using the Uncle Henry 16 ft. Extendable Tree Saw and UH Staglon 4" FB w/Leather Clam Pack. Always prioritize safety and adhere to the guidelines to prevent accidents and injuries. Thank you for your commitment to safe practices.

Säkerhetsinstruktioner för Uncle Herny 16 ft. Extendable Tree Saw

Introduktion

Tack för att du valt Uncle Herny 16 ft. Extendable Tree Saw. För att säkerställa säker användning och lång livslängd av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant. Dessa riktlinjer är utformade för att skydda användare och uppfylla EU:s allmänna produkt säkerhetsförordning (GPSR).

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens instruktioner.
- Kontrollera produkten innan användning för att säkerställa att den är i gott skick och fri från skador.
- Förvara produkten på en säker plats, utom räckhåll för barn och djur.
- Rapportera eventuella skador eller defekter omedelbart till återförsäljaren.
- Håll dig informerad om eventuella återkallelser genom att kontrollera EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar och skyddsglasögon när du använder såg.
- Undvik att använda sågen i ogynnsamma väderförhållanden, såsom kraftig vind eller regn.
- Se till att det område där du arbetar är fritt från hinder och att andra personer är på ett säkert avstånd.
- Använd inte sågen om du är trött eller under påverkan av alkohol eller droger.
- Följ alltid säkerhetsanvisningarna för att förhindra skador på dig själv eller andra.

Instruktioner för installation och användning

1. Kontrollera produkten:

- Inspektera sågbladet för skador eller slitage.
- Se till att staglonhandtaget är i gott skick och fritt från sprickor.

2. Förberedelse för användning:

- Sätt på dig skyddshandskar och skyddsglasögon.
- Ställ in sågens längd så att den passar det arbete du ska utföra.

3. Användning av sågen:

- Håll sågen med båda händerna för stabilitet.
- Använd en jämn och kontrollerad rörelse när du sågar.
- Undvik att trycka för hårt; låt sågen göra jobbet.

4. Efter användning:

- Rengör sågen noggrant och torka den med en torr trasa.
- Förvara sågen i det medföljande läderfodralet för att skydda den från skador.

Avfallshantering

- Avyttra produkten enligt lokala föreskrifter för avfallshantering.
- Återvinn materialet där det är möjligt, såsom metall och läder.

Kontaktinformation för vidare stöd

För frågor eller ytterligare information, vänligen kontakta din återförsäljare eller konsultera EU:s Safety Gateplattform för att rapportera osäkra produkter och få information om återkallelser.

Genom att följa dessa säkerhetsinstruktioner kan du bidra till en säker och effektiv användning av Uncle Herny 16 ft. Extendable Tree Saw. Tack för att du prioriterar säkerheten!