

Carry Case (1002P) - Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife Clam Pack

- Full Tang
- 7Cr17MoV steel with 5" blade length and weighs 6.3 oz
- Next Gen staglon handle with satin blade finish and nickel silver finger guard
- Sharpening stone and lanyard hole
- Leather sheath

NO IMAGE
AVAILABLE

Attributes

- Name: Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife Clam Pack
- Manufacturer: Uncle Herny
- Product no.: EU1000426
- Mfr. No.: 1100087
- Color: Black
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 432mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Uncle Herny Carry Case \(1002P\) Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Herny Carry Case \(1002P\) och Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife](#)

Uncle Herny Carry Case (1002P) Safety Instructions

Introduction

Thank you for choosing the Uncle Herny Carry Case (1002P) and the Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife. This guide provides essential safety instructions to ensure the safe use of your product. Please read this manual carefully before use.

General Safety Guidelines

- Always handle the knife with care to prevent injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife and carry case for any damage before use.
- Do not use the knife for purposes other than intended.
- Follow all local laws and regulations regarding knife usage and ownership.
- Store the knife in its sheath when not in use to prevent accidents.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always cut away from your body.
 - Use a stable surface when cutting.
 - Avoid distractions while using the knife.
- **Storage:**
 - Store the knife in a dry place.
 - Ensure the knife is sheathed when stored.
 - Keep the carry case closed when not in use.
- **Maintenance:**
 - Regularly check the sharpness of the blade.
 - Use the included sharpening stone as needed, following the manufacturer's instructions.
 - Clean the knife with a dry cloth after use to prevent rust.
- **Lanyard Hole:**
 - Use the lanyard hole to secure the knife when in use, if applicable.
 - Ensure the lanyard is not a strangulation hazard.

Instructions for Installation and Usage

- **Using the Knife:**
 1. Remove the knife from the carry case.
 2. Ensure the blade is clean and sharp.
 3. Hold the knife firmly by the handle with the blade facing away from you.
 4. Make your cuts slowly and deliberately, maintaining control of the knife.

- **Using the Carry Case:**

1. Place the knife securely in the carry case after each use.
2. Ensure the case is closed to protect the blade.
3. Carry the case using the handle, avoiding any unnecessary movement that may lead to accidents.

Disposal Instructions

- Dispose of the knife and carry case responsibly.
- If the knife is damaged or no longer needed, consider recycling the metal components where facilities exist.
- Follow local regulations for the disposal of sharp objects to prevent injury.

Contact Information for Further Support

For any inquiries regarding the safety of this product, please refer to the EU contact point for product safety inquiries.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and enjoyable experience with the Uncle Henry Carry Case and Knife.

Säkerhetsinstruktioner för Uncle Herny Carry Case (1002P) och Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife

Introduktion

Tack för att du valt Uncle Herny Carry Case och Uncle Herny UH Next Gen 153UH Golden Spike Rat Tail Tang Fixed Blade Knife. Denna säkerhetsinstruktion är utformad för att hjälpa dig att använda produkten på ett säkert och effektivt sätt. Vänligen läs igenom dessa riktlinjer noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar för att säkerställa säkerhet och effektivitet.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för tecken på skada eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med stor försiktighet och undvik att rikta den mot dig själv eller andra.
- Se till att kniven är i gott skick innan användning; kontrollera att bladet är skarpt och utan sprickor.
- Använd läderfodralet för att skydda kniven när den inte används.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att öppna burkar eller som ett verktyg för att slå.
- Använd alltid kniven på en stabil och säker yta.
- Håll händerna borta från bladet när du arbetar med kniven.
- Använd skyddshandskar om nödvändigt för att förhindra skador.

Instruktioner för installation och användning

1. **Kontrollera förpackningen:** Kontrollera att alla delar är inkluderade och att det inte finns några synliga skador på produkten.
2. **Förberedelse:** Ta bort kniven från dess förpackning och se till att den är ren och torr innan användning.
3. **Användning av kniven:**
 - Håll kniven med ett fast grepp om handtaget.
 - Använd kniven för skärning, skärning eller andra avsedda uppgifter.
 - Efter användning, rengör kniven noggrant och torka den för att förhindra rost.
4. **Förvaring:** Förvara kniven i läderfodralet när den inte används för att skydda den och förhindra olyckor.

Avfallshanteringsinstruktioner

- Kasta inte kniven eller dess delar i hushållsavfall.
- Följ lokala regler och förordningar för avfallshantering av skarpa föremål.
- Om produkten är skadad och inte längre kan användas, kontakta en lokal avfallshanteringsanläggning för korrekt avfallshantering.

Kontaktinformation för ytterligare support

För frågor eller ytterligare information om produkten, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för att få bästa möjliga support.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda produkten på ett säkert sätt bidrar du till en tryggare användning och minskar risken för olyckor.