

12 Inch Flex

This knife is designed for the fisherman that likes some flex to the blade and is filleting larger fish. We used the Bubba Blade™ patented textured no-slip-grip handle and a high carbon stainless steel for effortless cutting and total knife control.

NO IMAGE
AVAILABLE

Attributes

- Name: BUBBA 12 Inch Flex
- Manufacturer: BUBBA
- Product no.: EU1001332
- Mfr. No.: BB1-12F
- Color: Red
- Delivery weight: 0.68kg
- Shipping height: 64mm
- Shipping width: 119mm
- Shipping length: 526mm
- EAN/UPC: 6.96859E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BUBBA 12 Inch Flex Knife](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 12 Inch Flex](#)

Safety Instruction Guide for BUBBA 12 Inch Flex Knife

Introduction

Thank you for choosing the BUBBA 12 Inch Flex Knife. This knife is specifically designed for fishermen who require flexibility in their blade for filleting larger fish. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the knife for its intended purpose: filleting fish.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use for any signs of damage or wear.
- Use the knife on a stable, nonslip surface to prevent accidents.
- Store the knife in a safe location when not in use, preferably in its synthetic sheath.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Handling:** The blade is sharp. Always handle the knife with care to avoid cuts.
- **Grip:** Use the patented BUBBA BLADE® textured handle for a secure grip.
- **Cutting Direction:** Always cut away from your body to prevent injury.
- **Lanyard Hole:** Use the lanyard hole to secure the knife when not in use to prevent accidental drops.
- **Sheath Usage:** Always use the synthetic sheath for safe storage and transport of the knife.
- **Cleaning:** Clean the knife after each use to maintain hygiene and prevent corrosion.

Instructions for Installation and Usage

- **Initial Inspection:** Before using the knife, check for any visible damage or defects. Do not use if damaged.
- **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Position the fish on a stable surface.
 - Start at the tail and cut towards the head, maintaining a steady motion.
 - Use the flexibility of the blade to navigate around bones and skin.
- **PostUse Care:**
 - Rinse the knife under warm water to remove any residue.
 - Dry the knife thoroughly with a clean cloth.
 - Store the knife in the synthetic sheath when not in use.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, follow local regulations for disposal of sharp objects.
- Ensure the knife is wrapped or secured to prevent injury during disposal.

Contact Information for Further Support

For any inquiries or concerns regarding safety, please refer to your local EU consumer protection agency. They can provide guidance and support regarding the safe use of this product.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe

and enjoyable experience with your BUBBA 12 Inch Flex Knife.

Säkerhetsinstruktioner för BUBBA 12 Inch Flex

Introduktion

Tack för att du har valt BUBBA 12 Inch Flex kniv. Denna kniv är speciellt designad för fiskare som föredrar lite flex i bladet för att filéa större fiskar. För att säkerställa en säker och effektiv användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd endast kniven för avsett ändamål, dvs. filéa fisk.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd alltid kniven med stor försiktighet för att undvika skador.
- Följ alltid lokala lagar och förordningar gällande användning av knivar.

Specifika säkerhetsåtgärder för användning

- Använd kniven på en stabil och säker yta.
- Håll knivbladet rent och fritt från skräp för att säkerställa en säker användning.
- Använd ett skärunderlag för att skydda både kniven och ytan du arbetar på.
- Använd alltid kniven med den riktiga handgreppstekniken för att minimera risken för olyckor.
- Undvik att använda kniven om du är trött eller distraherad.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att kniven är ren och i gott skick innan användning.
- Se till att du har ett lämpligt skärunderlag och att arbetsområdet är rent.

2. Användning:

- Ta tag i det texturerade halkfria handtaget med ett fast grepp.
- Placera knivbladet mot fisken i en vinkel som gör det enkelt att skära.
- Använd långsamma och kontrollerade rörelser för att filéa fisken.
- Var alltid medveten om var din hand är i förhållande till knivbladet.

3. Avslutning:

- Rengör kniven omedelbart efter användning för att förhindra rost och bakterietillväxt.
- Förvara kniven i det medföljande syntetiska fodralet för att skydda bladet och förhindra olyckor.

Avfallshantering

- Avfallshantering av kniven bör ske enligt lokala föreskrifter för avfallshantering.
- Om kniven är skadad eller ur funktion, se till att den kasseras på ett säkert sätt för att undvika skador på andra.

Kontaktinformation för vidare support

För frågor eller mer information om säkerheten för denna produkt, vänligen kontakta tillverkaren direkt. Det är viktigt att ha en kontaktpunkt inom EU för säkerhetsfrågor relaterade till produkten.

Slutord

Vi hoppas att du får en säker och njutbar upplevelse med din BUBBA 12 Inch Flex kniv. Genom att följa dessa säkerhetsinstruktioner kan du bidra till att säkerställa en trygg användning av produkten. Tack för att du valde BUBBA!