

## 5 Inch Lucky Lew Folding Knife - BUBBA 5 Inch Lucky Lew

Every fisherman needs this folding fillet knife as their good luck charm. You will want this with you wherever you go. Its folding abilities make it easy to store and quick to access. Its 5-inch non-stick coated and titanium bonded and secure lock-back design keeps it safe and user-friendly. It has a 1.5-inch serrated cutting edge and its 6-inch famous red non-slip-grip handle. This full tang constructed knife is nice for your everyday fishing trips. If you are not sure what you will catch, this knife is handy to have for whatever comes your way.

NO IMAGE  
AVAILABLE

### Attributes

- Name: BUBBA 5 Inch Lucky Lew
- Manufacturer: BUBBA
- Product no.: EU1001333
- Mfr. No.: BB1-5FK
- Color: Red
- Delivery weight: 0.363kg
- Shipping height: 64mm
- Shipping width: 119mm
- Shipping length: 345mm
- UPC: 019962430947

# Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BUBBA 5 Inch Lucky Lew Folding Knife](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 5 Inch Lucky Lew Fällkniv](#)

# Safety Instruction Guide for BUBBA 5 Inch Lucky Low Folding Knife

## Introduction

Thank you for choosing the BUBBA 5 Inch Lucky Low Folding Knife. This guide provides important safety instructions to ensure the safe use of your knife. Please read this document carefully before using the product.

## General Safety Guidelines

- Always use the knife for its intended purpose. This knife is designed for filleting fish and should not be used for other purposes.
- Keep the knife out of reach of children and vulnerable individuals to prevent accidents.
- Ensure that you are in a safe environment when using the knife, free from distractions and hazards.
- Inspect the knife before each use for any signs of damage or wear. Do not use if damaged.
- Store the knife in a safe place when not in use, preferably in its sheath.
- If you experience any accidents or injuries while using the knife, seek appropriate medical attention immediately.

## Specific Safety Precautions for Use

- Always handle the knife with care, keeping fingers away from the blade.
- Use the serrated edge for cutting through tougher materials, and the straight edge for finer cuts.
- When folding the knife, ensure that your fingers are clear of the hinge area to avoid pinching.
- Do not force the blade through materials it is not designed to cut.
- If the knife becomes stuck, do not pull or yank it free. Instead, gently work it loose.
- Avoid using the knife in wet or slippery conditions to maintain a firm grip.

## Instructions for Installation and Usage

### 1. Folding the Knife:

- To fold the knife, press the lockback mechanism located on the handle.
- Carefully fold the blade into the handle until it clicks into place.

### 2. Unfolding the Knife:

- To unfold the knife, press the lockback mechanism again.
- Gently pull the blade out until it is fully extended and securely locked in place.

### 3. Using the Knife:

- Hold the knife firmly by the handle, ensuring a comfortable grip.
- Use a stable cutting surface when filleting fish to maintain control.
- Always cut away from your body to prevent accidental injuries.

### 4. Cleaning and Maintenance:

- After use, clean the blade with warm, soapy water and dry it thoroughly.
- Avoid using abrasive materials that could scratch the blade's coating.
- Regularly check for any loose screws or damage, and tighten or replace as necessary.

## **Disposal Instructions**

- When disposing of the knife, ensure it is safely secured to prevent accidental injury.
- If the knife is no longer usable, consider recycling the metal components where possible.
- Follow local regulations regarding the disposal of sharp objects.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the BUBBA 5 Inch Lucky Lew Folding Knife, please refer to the manufacturer's contact information provided with the product packaging.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your BUBBA 5 Inch Lucky Lew Folding Knife. Thank you for your attention to safety.

# Säkerhetsinstruktioner för BUBBA 5 Inch Lucky Lew Fällkniv

## Introduktion

Tack för att du valt BUBBA 5 Inch Lucky Lew Fällkniv. Denna kniv är designad för att vara ett pålitligt verktyg för fiskare och utomhusentusiaster. För att säkerställa säker användning och långvarig prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

## Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra obehöriga.
- Kontrollera kniven före varje användning för att säkerställa att den är i gott skick.
- Använd kniven endast för dess avsedda syfte.
- Vid användning av kniven, se till att du har ett fast grepp och att du är i en stabil position.
- Undvik att använda kniven i fuktiga eller hala förhållanden för att minska risken för olyckor.
- Rapportera eventuella skador eller defekter på kniven till tillverkaren.

## Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven med bladet i ett säkert och kontrollerat läge.
- Stäng kniven när den inte används för att förhindra oavsiktlig skada.
- Var försiktig när du hanterar den tandade eggen; den kan orsaka skador om den inte hanteras korrekt.
- Använd kniven på ett stabilt underlag för att förhindra olyckor.
- Undvik att använda kniven för att skära hårda material som metall eller plast, vilket kan skada bladet.
- Vid rengöring, använd en mjuk trasa och undvik slipande material som kan skada beläggningen.

## Instruktioner för installation och användning

- För att fälla ut kniven, tryck på låsmekanismen och dra bladet försiktigt utåt.
- Kontrollera att bladet är helt utsträckt och låst innan du använder kniven.
- För att fälla tillbaka bladet, tryck på låsmekanismen igen och tryck bladet tillbaka till handtaget.
- Förvara kniven i det medföljande syntetiska fodralet när den inte används.
- Kontrollera regelbundet att snoddhålet är rent och fritt från skräp för att säkerställa korrekt funktion.

## Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet om den är skadad eller defekt.
- Om kniven är oduglig, överväg att återvinna materialet där det är möjligt.
- Följ lokala riktlinjer för avfallshantering och återvinning.

## Kontaktinformation för ytterligare support

För frågor angående säkerhet eller produktinformation, vänligen kontakta tillverkaren eller besök deras officiella webbplats. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du njuta av en säker och effektiv användning av din BUBBA 5 Inch Lucky Lew Fällkniv. Tack för att du värdesätter säkerhet och ansvar vid användning av dina verktyg.