

6 Inch Chubby

We have been asked to make this style of blade for a while now. We think you're going to love this knife, and it'll soon be your favorite. The curved 6" blade is ready for caping, and basically any meat-cutting that needs to be done. The Chubby will be your go-to knife. We also have had reports that wives are taking the Chubby over for the home kitchen, so you may want to get two!

NO IMAGE
AVAILABLE

Attributes

- Name: 6 Inch Chubby
- Manufacturer: BUBBA
- Product no.: EU1001343
- Mfr. No.: BB1-CH-BX
- Color: Red
- Delivery weight: 0.454kg
- Shipping height: 38mm
- Shipping width: 171mm
- Shipping length: 403mm
- UPC: 748252649133

Table of Contents

- [Startpage](#)
- [English: BUBBA 6 Inch Chubby Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 6 Inch Chubby](#)

BUBBA 6 Inch Chubby Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA 6 Inch Chubby Knife. This guide provides important safety instructions to ensure the safe and effective use of your knife. Please read and follow all instructions carefully to avoid injuries and ensure the longevity of your product.

General Safety Guidelines

- Always handle the knife with care to avoid cuts and injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose, which is meatcutting and caping.
- Inspect the knife regularly for any signs of damage or wear.
- Store the knife in a safe place, preferably in its sheath, when not in use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the blade is sharp before use. A dull blade can lead to accidents as more force may be needed.
- Use a stable cutting surface to prevent slipping while cutting.
- Always cut away from your body to minimize the risk of injury.
- Do not attempt to catch the knife if it slips from your hand.
- When passing the knife to someone else, lay it down on a flat surface instead of handing it directly.
- Avoid using the knife in wet or slippery conditions to maintain a firm grip.

Instructions for Installation and Usage

- **Unboxing:** Carefully remove the knife from its packaging. Ensure that there are no visible damages.
- **Initial Inspection:** Check the blade and handle for any defects. If any issues are found, do not use the knife and contact customer support.
- **Usage Instructions:**
 1. Place the knife on a stable, nonslip cutting board.
 2. Grip the handle firmly with your dominant hand.
 3. Position the food item securely on the cutting board.
 4. Use a smooth, controlled motion to cut through the meat.
 5. Clean the knife immediately after use to prevent contamination.
- **Cleaning:** Hand wash the knife with warm soapy water and dry it thoroughly. Avoid using a dishwasher as it may damage the blade and handle.
- **Storage:** Store the knife in its synthetic sheath when not in use to protect the blade and prevent accidents.

Disposal Instructions

When the knife has reached the end of its useful life, dispose of it responsibly: * Wrap the blade securely in thick paper or cardboard to prevent injuries during disposal. * Place the wrapped knife in a designated waste container for sharp objects. * Check local regulations for any specific disposal guidelines related to knives.

Contact Information for Further Support

For any questions or concerns regarding the BUBBA 6 Inch Chubby Knife, please refer to the contact information provided on the packaging or the manufacturer's website.

Thank you for your attention to these safety instructions. Enjoy your BUBBA 6 Inch Chubby Knife responsibly!

Säkerhetsinstruktioner för BUBBA 6 Inch Chubby

Introduktion

Tack för att du har valt BUBBA 6 Inch Chubby kniv. Denna kniv är designad för att ge en säker och effektiv skärupplevelse. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa korrekt användning och för att minimera risken för skador.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på en stabil och säker yta.
- Håll kniven borta från barn och andra som inte är utbildade i säker användning av knivar.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsedd användning; undvik att använda den för andra ändamål.
- Vid skärning, rikta alltid bladet bort från kroppen och andra personer.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett skärbräda när du skär mat.
- Håll kniven torr och ren för att förhindra att den blir hal eller svår att hantera.
- Undvik att använda kniven på hårda ytor som glas eller metall, vilket kan skada bladet.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.
- Förvara kniven i det medföljande syntetiska fodralet när den inte används för att förhindra oavsiktliga skador.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att arbetsytan är ren och fri från skräp.
- Ta bort kniven från fodralet med försiktighet.

2. Användning:

- Håll kniven i ett fast grepp med tummen på ena sidan av handtaget och fingrarna på andra sidan.
- Använd en stabil skärbräda och placera maten på skärbrädan.
- Skär med ett jämnt tryck och undvik att använda överdriven kraft.

3. Rengöring:

- Rengör kniven omedelbart efter användning med varmt vatten och mild tvål.
- Torka kniven noggrant med en ren handduk för att förhindra rost.

4. Förvaring:

- Förvara kniven i det medföljande syntetiska fodralet när den inte används.
- Håll kniven på en säker plats, utom räckhåll för barn.

Avfallshanteringsinstruktioner

- När kniven är slut på livslängd eller om den är skadad, se till att den kasseras på ett säkert sätt för att förhindra skador på andra.
- Kontakta lokala myndigheter för information om korrekt avfallshantering av metallprodukter.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om säker användning av BUBBA 6 Inch Chubby, vänligen kontakta tillverkaren eller din lokala återförsäljare. Se till att du har produktens modellnummer tillgängligt för snabbare service.

Rapportera osäkra produkter

Om du upptäcker en osäker produkt eller har en olycka, rapportera detta till relevanta myndigheter. Håll dig informerad om eventuella återkallelser genom att kontrollera EU:s Safety Gateplattform.

Tack för att du följer dessa säkerhetsinstruktioner. Vi hoppas att du får många års glädje av din BUBBA 6 Inch Chubby kniv.