

Sculpin Pocket Knife

Looking for a pocket knife? Bubba's Sculpin Pocket Knife features a textured G-10 handle and tanto blade style. This compact pocket knife can easily be opened with one hand in seconds. This Sculpin Pocket Knife folds up nicely to fit in your jeans or jacket pocket. It's handy for on-the-go and out at the fishing docks. The deep pocket clip allows for the blade to be upward and has a liner lock safety mechanism to it. Although smaller in stature it's the kind of knife everyone wishes they had. It's super durable in any condition it might be left in. Carry this knife with you wherever you are. It'll do all the work, so you don't have to.

NO IMAGE
AVAILABLE

Attributes

- Name: Sculpin Pocket Knife
- Manufacturer: BUBBA
- Product no.: EU1001355
- Mfr. No.: BB-CL-FK
- Color: Red
- Delivery weight: 0.227kg
- Shipping height: 58mm
- Shipping width: 119mm
- Shipping length: 277mm
- UPC: 653341606402

Table of Contents

- [Startpage](#)
- [English: BUBBA Sculpin Pocket Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Sculpin Pocket Knife](#)

BUBBA Sculpin Pocket Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Sculpin Pocket Knife. This guide provides essential safety instructions and guidelines to ensure the safe use of your pocket knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Ensure the knife is stored in a safe location, out of reach of children.
- Always inspect the knife before use for any signs of damage or wear.
- Use the knife only for its intended purpose.
- Keep the knife clean and wellmaintained for optimal performance.
- If the knife becomes damaged or malfunctions, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- **Blade Safety:**
 - Always be aware of the blade's position when opening or closing the knife.
 - Never point the blade towards yourself or others while using the knife.
- **Liner Lock:**
 - Ensure the liner lock is fully engaged when the knife is opened to prevent accidental closure during use.
- **Finger Flipper:**
 - Use the finger flipper to open the knife safely and efficiently. Avoid using excessive force.
- **Pocket Clip:**
 - When carrying the knife, ensure the pocket clip is securely fastened to your pocket or bag to prevent accidental drops.
- **Lanyard Hole:**
 - Consider using a lanyard through the lanyard hole for added security when carrying the knife.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly in one hand.
- Use your index finger to push the finger flipper, allowing the blade to open smoothly.
- Ensure the blade locks into place with the liner lock.

2. Using the Knife:

- Use the knife for cutting tasks only.
- Maintain a firm grip on the handle while in use.
- Avoid applying excessive force that may cause injury or damage.

3. Closing the Knife:

- Press the liner lock to disengage.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

4. Cleaning and Maintenance:

- Clean the blade with a soft cloth after each use to prevent corrosion.

- Regularly check the blade and handle for any signs of damage or wear.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is no longer usable, consider recycling the materials where possible.
- Ensure the blade is safely contained to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the BUBBA Sculpin Pocket Knife, please refer to the manufacturer's contact details provided with your purchase.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your BUBBA Sculpin Pocket Knife. Always prioritize safety and responsible usage. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för BUBBA Sculpin Pocket Knife

Introduktion

Tack för att du har valt BUBBA Sculpin Pocket Knife. Denna fickkniv är designad för att vara säker och lättanvänd. För att säkerställa en trygg användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och håll den borta från barn.
- Kontrollera alltid kniven för skador innan användning. Använd inte en skadad kniv.
- Förvara kniven på en säker plats när den inte används.
- Använd kniven endast för dess avsedda syften, som att skära eller öppna föremål.
- Följ alltid lokala lagar och förordningar gällande knivanvändning.

Specifika säkerhetsåtgärder för användning

- Håll alltid fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd fingerflippern för att öppna kniven, och se till att bladet är helt låst i öppet läge innan användning.
- Använd kniven med båda händerna om möjligt, särskilt vid skärning av hårda material.
- Undvik att använda kniven under påverkan av alkohol eller droger.
- Om kniven blir blöt, torka den noggrant för att förhindra rost och skador.

Instruktioner för installation och användning

• Öppna kniven:

1. Håll kniven i ena handen med bladet vänd bort från dig.
2. Använd fingerflippern för att öppna bladet.
3. Kontrollera att liner lock mekanismen är aktiverad och att bladet är helt öppet.

• Stänga kniven:

1. Tryck på liner lock för att frigöra bladet.
2. För försiktigt tillbaka bladet till handtaget tills det klickar på plats.

• Fickklämma:

- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker förvaring och enkel åtkomst.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet.
- Om kniven är skadad eller inte längre behövs, återvinn den på ett lämpligt sätt enligt lokala återvinningsbestämmelser.
- Se till att kniven är helt stängd och säker när du hanterar den för avfallshantering.

Kontaktinformation för vidare stöd

För frågor eller rapportering av osäkra produkter, vänligen kontakta din lokala myndighet eller besök EU:s Safety Gateplattform för att få mer information om återkallelser och säkerhetsuppdateringar.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din BUBBA Sculpin Pocket Knife. Tack för ditt förtroende för våra produkter.