

SWSA11 Drop Point Black/FDE Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Aluminum Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA11 Drop Point Black/FDE Handle
- Manufacturer: M&P
- Product no.: EU1001441
- Mfr. No.: 1084302
- Delivery weight: 0.136kg
- Shipping height: 24mm
- Shipping width: 38mm
- Shipping length: 88mm
- UPC: 661120413639

Table of Contents

- [Startpage](#)
- [English: M&P SWSA11 Drop Point Black/FDE Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA11 Drop Point Black/FDE Handtag](#)

M&P SWSA11 Drop Point Black/FDE Handle Safety Instructions

Introduction

Thank you for choosing the M&P SWSA11 Drop Point Knife. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this document carefully to familiarize yourself with the proper handling and care of your product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose; avoid using it for tasks that may cause damage to the blade or injury to yourself.
- Inspect the knife before each use for any signs of damage or wear. Do not use a damaged knife.
- Always cut away from your body and keep your fingers clear of the blade.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- If the knife is involved in an accident or causes injury, report it to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always handle the blade by the handle, avoiding contact with the sharp edge.
 - Be cautious when opening and closing the knife to prevent accidental cuts.
- **Locking Mechanism:**
 - Ensure the liner lock is fully engaged before using the knife to prevent accidental closure.
 - Check the locking mechanism regularly for functionality.
- **Dual Thumbstuds:**
 - Use the dual thumbstuds to open the knife safely, ensuring your fingers are clear of the blade path.
- **Rubberized Aluminum Handle:**
 - The rubberized handle provides a secure grip. Ensure your hands are dry to maintain grip while using the knife.
- **Pocket Clip:**
 - Use the pocket clip to secure the knife when not in use, preventing accidental drops or loss.

Instructions for Installation and Usage

Opening the Knife

1. Hold the knife securely by the handle.
2. Use your thumb to push on one of the dual thumbstuds to open the blade.
3. Ensure the blade is fully extended and the liner lock clicks into place.

Closing the Knife

1. Press the liner lock to disengage it.
2. Carefully fold the blade back into the handle while keeping your fingers clear of the blade path.
3. Store the knife in a safe location.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, consider recycling metal components where possible.
- Follow local regulations for the disposal of sharp objects to prevent injury to waste handlers.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P SWSA11 Drop Point Knife, please refer to the manufacturer's contact information provided at the point of purchase or on the packaging.

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P SWSA11 Drop Point Knife. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P SWSA11 Drop Point Black/FDE Handtag

Introduktion

Tack för att du valt M&P SWSA11 Drop Point kniv. Denna säkerhetsinstruktionsguide är utformad för att ge dig viktig information om säker användning, installation och avfallshantering av produkten. Vänligen läs dessa instruktioner noggrant för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner för att minimera riskerna.
- Kontrollera produkten regelbundet för eventuella skador eller slitage.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallningar via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett ändamål och undvik att använda den på hårda ytor som kan skada bladet.
- Håll fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd alltid ett fast grepp om handtaget för att förhindra att kniven glider ur handen.
- Undvik att använda kniven i blöta eller hala förhållanden.
- Förvara kniven i ett säkert och torrt utrymme när den inte används.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd tumstudsens för att enkelt öppna kniven.
- Se till att bladet är helt utsträckt innan du börjar använda det.

2. Stäng kniven:

- Tryck på liner lock för att frigöra bladet.
- Stäng kniven försiktigt och se till att fingrarna är borta från bladets väg.

3. Användning:

- Använd kniven för skärning, men undvik att använda den för att pricka eller hacka hårda material.
- Håll kniven i en vinkel som är säker och bekväm för dig.

4. Underhåll:

- Rengör kniven efter varje användning med en fuktig trasa.
- Smörj gångjärnen regelbundet för att säkerställa smidig öppning och stängning.

Avfallsinstruktioner

- Kasta inte kniven i vanliga hushållsavfall. Kontrollera lokala riktlinjer för avfallshantering av vassa föremål.
- Om kniven är skadad och inte längre kan användas, se till att den hanteras på ett säkert sätt för att

undvika skador.

Kontaktinformation för vidare stöd

För frågor angående säkerhet eller användning av M&P SWSA11 Drop Point kniv, vänligen kontakta en auktoriserad återförsäljare eller tillverkaren direkt.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda kniven på ett ansvarsfullt sätt bidrar du till en säker och positiv upplevelse.