

SWSA11 Drop Point Black/FDE Handle - SWSA11CP Drop Point Black/FDE Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Aluminum Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA11CP Drop Point Black/FDE Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001442
- Mfr. No.: 1084303
- Delivery weight: 0.168kg
- Shipping height: 28mm
- Shipping width: 80mm
- Shipping length: 88mm
- UPC: 661120413288

Table of Contents

- [Startpage](#)
- [English: M&P SWSA11 Drop Point Black/FDE Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA11 Drop Point Kniv](#)

M&P SWSA11 Drop Point Black/FDE Handle Safety Instructions

Introduction

Thank you for choosing the M&P SWSA11 Drop Point Knife. This safety instruction guide is designed to help you use this product safely and effectively. Please read all instructions carefully before use to ensure a safe experience.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Do not use the knife for purposes other than intended.
- Store the knife in a safe place when not in use.
- Be aware of your surroundings while using the knife to avoid accidents.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the blade is locked in place before using the knife.
- Use the knife on a stable surface to prevent slipping.
- Avoid using excessive force when cutting to minimize the risk of blade breakage.
- Do not attempt to catch a falling knife.
- Always cut away from your body to avoid injury.
- Use protective gloves if necessary when handling the knife.
- If the knife becomes damaged, discontinue use immediately.

Instructions for Installation and Usage

1. Unboxing the Knife

- Carefully remove the knife from its packaging.
- Inspect the knife for any visible damage.

2. Opening the Knife

- Use the dual thumbstuds to open the blade.
- Ensure the blade is fully extended and locked in place before use.

3. Using the Knife

- Hold the handle firmly and position the blade at the desired cutting angle.
- Apply even pressure while cutting to ensure a clean cut.
- If you need to close the knife, ensure your fingers are clear of the blade.

4. Cleaning and Maintenance

- Clean the blade with a soft cloth after each use.
- Avoid using harsh chemicals that may damage the blade or handle.
- Regularly check for any signs of wear and tear.

5. Storing the Knife

- Store the knife in a designated safe place, preferably in a sheath or knife block.
- Ensure the blade is closed and locked when storing.

Disposal Instructions

- When the knife is no longer usable, dispose of it responsibly.
- Follow local regulations for the disposal of sharp objects.
- If applicable, recycle parts of the knife according to local recycling guidelines.

Contact Information for Further Support

For any safety inquiries or issues regarding the M&P SWSA11 Drop Point Knife, please refer to the contact information provided by your retailer or manufacturer. Ensure you have your product details ready when seeking assistance.

Thank you for following these safety instructions. Enjoy using your M&P SWSA11 Drop Point Knife safely!

Säkerhetsinstruktioner för M&P SWSA11 Drop Point Kniv

Introduktion

Tack för att du valt M&P SWSA11 Drop Point Kniv. Denna produkt är designad för säker och effektiv användning. För att säkerställa att du får en trygg och positiv upplevelse med din kniv, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd kniven endast för avsett syfte.
- Håll kniven utom räckhåll för barn och sårbara personer.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd alltid kniven på en stabil yta.
- Förvara kniven på en säker plats när den inte används.

Specifika säkerhetsåtgärder för användning

- Var alltid medveten om din omgivning när du använder kniven.
- Använd kniven med båda händerna för att bibehålla kontrollen.
- Skär alltid bort från kroppen för att minimera risken för skador.
- Använd skyddshandskar om möjligt för att skydda händerna.
- Stäng kniven när den inte används för att förhindra oavsiktliga skador.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd den dubbla tummknappen för att enkelt öppna kniven.
2. **Lås kniven:** Kontrollera att liner lock är på plats innan du börjar använda kniven.
3. **Använd kniven:** Använd kniven enligt dess avsedda syfte. Skär alltid på en säker yta.
4. **Stäng kniven:** Tryck på liner lock för att stänga kniven efter användning.
5. **Fickklämma:** Använd fickklämman för att fästa kniven i fickan eller bältet för säker transport.

Avfallshantering

- Kasta inte kniven i vanliga sopor. Kontakta lokala myndigheter för information om korrekt avfallshantering av knivar.
- Om kniven är skadad eller ur funktion, se till att den förvaras på ett säkert sätt tills den kan kasseras korrekt.

Kontaktinformation för ytterligare stöd

För frågor eller rapporter om säkerhetsproblem, vänligen kontakta den angivna kontaktpunkten i EU. Kontrollera också EU:s Safety Gateplattform för uppdateringar om eventuella återkallelser eller säkerhetsvarningar.

Avslutande anmärkningar

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din M&P SWSA11 Drop Point Kniv. Tack för att du prioriterar säkerheten!