

SWSA12 Drop Point Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum Textured Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA12 Drop Point Black Handle
- Manufacturer: M&P
- Product no.: EU1001443
- Mfr. No.: 1084304
- Color: Black/Silver
- Delivery weight: 0.136kg
- Shipping height: 24mm
- Shipping width: 37mm
- Shipping length: 88mm
- UPC: 661120413295

Table of Contents

- [Startpage](#)
- [English: M&P SWSA12 Drop Point Black Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA12 Drop Point Kniv](#)

M&P SWSA12 Drop Point Black Handle Safety Instructions

Introduction

Thank you for choosing the M&P SWSA12 Drop Point Black Handle. This guide provides essential safety instructions to ensure the safe use and maintenance of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure the knife is stored in a safe place when not in use.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, discontinue use immediately and seek a replacement.
- Always use the knife for its intended purpose to avoid accidents.
- Report any unsafe product experiences or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always cut away from your body and keep fingers clear of the blade.
- Use a cutting surface that is stable and secure.
- Avoid using excessive force when cutting; let the blade do the work.
- Ensure the blade is clean and dry before use to maintain grip and control.
- Do not attempt to modify the knife in any way.
- When carrying the knife, ensure it is securely closed or sheathed.
- Avoid using the knife in wet or slippery conditions to prevent loss of control.

Instructions for Installation and Usage

• Opening the Knife:

- Locate the dual thumbstuds on either side of the blade.
- Use your thumb to press down on one of the thumbstuds to open the blade smoothly.

• Locking Mechanism:

- The liner lock engages automatically when the blade is fully opened.
- To close the knife, press the liner lock to the side and gently fold the blade back into the handle.

• Using the Pocket Clip:

- The pocket clip allows for easy carrying of the knife.
- Clip the knife securely to your pocket or belt for convenient access.

• Lanyard Hole:

- The lanyard hole can be used to attach a lanyard for additional safety and convenience.

• Maintenance:

- Regularly clean the blade with a soft cloth to remove dirt and moisture.
- Lubricate the pivot point with a suitable knife lubricant to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, ensure that the blade is securely covered or wrapped before disposal to prevent injury to others.
- Consider recycling components where applicable.

Contact Information for Further Support

For any inquiries or concerns regarding the M&P SWSA12 Drop Point Black Handle, please refer to the EU-based contact point provided with your product packaging.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your M&P SWSA12 Drop Point Black Handle. Thank you for your attention to safety.

Säkerhetsinstruktioner för M&P SWSA12 Drop Point Kniv

Introduktion

Tack för att du valt M&P SWSA12 Drop Point kniv. För att säkerställa en säker och korrekt användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant. Denna guide är utformad för att ge dig viktig information om säkerhet, användning och avfallshantering i enlighet med EU:s allmänna produkt säkerhetsförordning (GPSR).

Allmänna säkerhetsriktlinjer

- Produktsäkerhet: Använd alltid produkten i enlighet med dessa instruktioner för att minimera riskerna.
- Återkallelse: Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.
- Online shopping: Om du köper produkten online, se till att återförsäljaren följer säkerhetskraven.
- Skydd för sårbara grupper: Håll produkten utom räckhåll för barn och andra sårbara grupper.
- EUkontaktpunkt: För frågor om säkerhet, kontakta den angivna EUbaserade kontaktpunkten.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och se till att den är i gott skick innan användning.
- Håll kniven borta från barn och djur.
- Använd kniven endast för avsett ändamål. Undvik att använda den för att skära genom hårda eller olämpliga material.
- Kontrollera att knivbladet är korrekt låst innan användning.
- Var alltid medveten om din omgivning när du använder kniven för att undvika olyckor.

Instruktioner för installation och användning

- **Öppning av kniven:**
 - Använd den dubbla tumknappen för att öppna kniven. Tryck ned knappen med tummen för att frigöra bladet.
- **Låsning av kniven:**
 - När kniven är helt öppen, se till att liner locken är korrekt aktiverad för att säkerställa att bladet är låst på plats.
- **Stängning av kniven:**
 - För att stänga kniven, tryck ned liner locken och vik bladet tillbaka in i handtaget.
- **Användning av fickklämma:**
 - Fickklämman kan användas för att fästa kniven på bältet eller i fickan för enkel åtkomst.
- **Snoddhåll:**
 - Använd snoddhålet för att fästa en snodd eller lanyard för extra säkerhet och för att förhindra att kniven tappas bort.

Avfallshanteringsinstruktioner

- När kniven inte längre används eller är skadad, se till att den kasseras på ett säkert sätt.
- Följ lokala riktlinjer för avfallshantering för metallprodukter.
- Om möjligt, återvinn kniven för att minska miljöpåverkan.

Kontaktinformation för vidare support

För frågor om säkerhet eller produktinformation, vänligen kontakta den angivna EUbaserade kontaktpunkten som medföljer produkten.

Tack för att du följer dessa säkerhetsinstruktioner och för att du använder M&P SWSA12 Drop Point kniv.
Din säkerhet är vår prioritet.