

SWSA12 Drop Point Black Handle - SWSA12CP Drop Point Black Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum Textured Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SWSA12CP Drop Point Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001444
- Mfr. No.: 1084305
- Color: Black/Silver
- Delivery weight: 0.136kg
- Shipping height: 28mm
- Shipping width: 80mm
- Shipping length: 88mm
- UPC: 661120413301

Table of Contents

- [Startpage](#)
- [English: M&P SWSA12 Drop Point Black Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SWSA12 Drop Point Black Handle](#)

M&P SWSA12 Drop Point Black Handle Safety Instructions

Introduction

Thank you for choosing the M&P SWSA12 Drop Point Black Handle knife. This manual provides essential safety guidelines and instructions to ensure safe and effective use of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Always handle your knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose. Do not use it as a tool for prying or other inappropriate tasks.
- Inspect the knife before each use to ensure it is in good condition. Do not use if there are signs of damage.
- Store the knife in a safe place, preferably in a sheath or protective case, when not in use.
- If you experience any discomfort or pain while using the knife, stop using it immediately and seek assistance.

Specific Safety Precautions for Use

- Ensure that your hands are dry and clean before handling the knife to prevent slipping.
- Use a stable and secure surface when cutting. Avoid cutting on unstable or moving surfaces.
- Always cut away from your body to minimize the risk of injury.
- Use the dual thumbstuds to open the knife safely. Ensure your fingers are clear of the blade path.
- Engage the liner lock fully before using the knife to prevent accidental closure during use.
- Be cautious when using the pocket clip to carry the knife. Ensure it is securely attached to your clothing to prevent accidental drops.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the dual thumbstuds on both sides of the blade.
- Gently press the thumbstud with your thumb to open the blade. Ensure your fingers are clear of the blade path.

2. Using the Knife:

- Hold the knife firmly by the textured aluminum handle.
- Position the blade at the desired angle for cutting.
- Ensure that the liner lock is engaged to keep the blade open during use.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

4. Attaching the Pocket Clip:

- Clip the knife securely to your pocket or belt for easy access.
- Ensure the clip is firmly attached to prevent accidental loss.

5. Using the Lanyard Hole:

- If desired, attach a lanyard to the lanyard hole for additional security during transport.

Disposal Instructions

- Dispose of the knife responsibly according to local regulations.
- If the knife is damaged beyond use, ensure it is disposed of in a way that prevents any risk of injury to others.
- Consider recycling materials where applicable, following local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of your M&P SWSA12 Drop Point knife, please reach out to the manufacturer or your point of purchase for assistance.

Thank you for your attention to these safety instructions. Enjoy your M&P SWSA12 Drop Point knife responsibly!

Säkerhetsinstruktioner för M&P SWSA12 Drop Point Black Handle

Introduktion

Tack för att du valt M&P SWSA12 Drop Point Black Handle. Denna kniv är designad för att vara både funktionell och säker. Det är viktigt att du läser och följer dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och för dess avsedda syfte.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Följ alltid lokala lagar och förordningar angående knivanvändning.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast i en säker miljö, borta från brännbara material.
- När du använder kniven, håll den borta från kroppen och andra personer.
- Använd kniven med försiktighet och undvik att använda den under påverkan av alkohol eller droger.
- Stäng alltid kniven när den inte används och förvara den på en säker plats.
- Undvik att använda kniven för uppgifter som den inte är avsedd för, såsom att öppna burkar eller som en skruvmejsel.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tumknappen med tummen och dra knivbladet utåt.
- För att stänga kniven, tryck på liner lock med pekfingeret och tryck tillbaka bladet i handtaget.
- För att fästa kniven i ett bälte eller en ficka, använd fickklämman som är monterad på handtaget.
- Om du använder snoddhålet, se till att snodden är ordentligt fäst för att förhindra att den lossnar under användning.

Avfallsinstruktioner

- När kniven inte längre är användbar, se till att den kasseras på ett säkert sätt.
- Försök att återvinna materialet där det är möjligt, i enlighet med lokala avfallsbestämmelser.
- Lämna inte kniven i en plats där den kan utgöra en risk för andra.

Kontaktinformation för vidare stöd

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller besök tillverkarens officiella webbplats för mer information.

Tack för att du bidrar till en säker användning av M&P SWSA12 Drop Point Black Handle.