

SW1100 Drop Point Silver/Black Handle

- 8Cr13MoV Satin Finish High Carbon S.S. Blade Aluminum w/Textured Insert Handle
- Dual Thumbstuds
- Finger Flipper
- Frame Lock
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: M&P SW1100 Drop Point Silver/Black Handle
- Manufacturer: M&P
- Product no.: EU1001445
- Mfr. No.: 1084306
- Color: Black/Silver
- Delivery weight: 0.095kg
- Shipping height: 24mm
- Shipping width: 34mm
- Shipping length: 68mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P SW1100 Drop Point Silver/Black Handle Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P SW1100 Drop Point Silver/Black Handle](#)

M&P SW1100 Drop Point Silver/Black Handle Safety Instruction Guide

Introduction

Thank you for choosing the M&P SW1100 Drop Point Silver/Black Handle. This guide provides essential safety information to ensure the safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Inspect the knife for any damage before use. Do not use if damaged.
- Use the knife only for its intended purpose. Do not use it for prying or as a screwdriver.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.
- Be aware of your surroundings when using the knife to avoid accidents.

Specific Safety Precautions for Use

- Ensure that the blade is fully deployed before use. Use the dual thumbstuds or finger flipper to open the blade safely.
- Always cut away from your body and keep your fingers clear of the blade's path.
- Do not attempt to catch a falling knife; let it fall to avoid injury.
- When closing the knife, ensure that your fingers are clear of the blade to prevent cuts.
- If the knife becomes difficult to open or close, do not force it. Inspect for obstructions or damage.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the dual thumbstuds or the finger flipper to open the blade.
- Ensure the blade locks into place securely before use.

2. Using the Knife:

- Hold the knife firmly by the handle, ensuring a comfortable grip.
- Apply appropriate pressure for cutting tasks, avoiding excessive force.

3. Closing the Knife:

- Press the frame lock to release the blade.
- Carefully fold the blade back into the handle, ensuring fingers are clear of the blade.

4. Using the Pocket Clip and Lanyard Hole:

- The pocket clip allows for easy carrying. Attach it to your pocket or belt for convenience.
- The lanyard hole can be used to attach a lanyard for additional security.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, consider recycling the metal components where facilities are available.
- Ensure that the blade is covered or secured to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or assistance regarding the M&P SW1100 Drop Point Silver/Black Handle, please contact your local retailer or manufacturer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P SW1100 Drop Point Silver/Black Handle. Always prioritize safety and proper handling to prevent accidents. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P SW1100 Drop Point Silver/Black Handle

Introduktion

Tack för att du valt M&P SW1100 Drop Point Silver/Black Handle. Denna guide innehåller viktiga säkerhetsinstruktioner som du bör följa för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom alla instruktioner noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller tecken på slitage.
- Använd kniven endast för dess avsedda syfte.
- Vid onlineköp, se till att produkten uppfyller säkerhetsstandarder.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett stabilt underlag när du arbetar med kniven.
- Håll kniven skarp för att förhindra olyckor; en trubbig kniv kräver mer kraft och kan glida.
- Använd skyddshandskar om nödvändigt för att skydda dina händer.
- Undvik att rikta kniven mot dig själv eller andra när du använder den.
- Stäng alltid kniven när den inte används.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd den dubbla tumknappen för att öppna kniven. Se till att fingrarna är borta från bladet.
2. **Använd kniven:** Använd kniven för skärning av lämpliga material. Undvik att använda den på hårda ytor som kan skada bladet.
3. **Stäng kniven:** Tryck på ramlåset för att stänga kniven efter användning. Kontrollera att bladet är helt inuti handtaget innan du förvarar den.
4. **Förvaring:** Förvara kniven på en torr och säker plats, borta från barn.

Avfallshantering

- Kassera kniven på ett säkert sätt om den är skadad eller inte längre används. Se till att bladet är täckt eller inneslutet för att förhindra skador.
- Följ lokala riktlinjer för avfallshantering när du kasserar kniven.

Kontaktinformation för ytterligare support

För frågor eller säkerhetsinquiries, vänligen kontakta en EUbaserad kontaktpunkt. Kontrollera alltid för uppdateringar om återkallelser via EU:s Safety Gateplattform.

Sammanfattning

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och positiv upplevelse med din M&P SW1100 Drop Point Silver/Black Handle. Tveka inte att rapportera osäkra produkter eller olyckor till relevanta myndigheter. Tack för att du bidrar till en säkrare användning av produkter.