

SW1100 Drop Point Silver/Black Handle - M&P SW1100CP Drop Point Silver/Black Handle Clam Pack

- 8Cr13MoV Satin Finish High Carbon S.S. Blade Aluminum w/Textured Insert Handle
- Dual Thumbstuds
- Finger Flipper
- Frame Lock
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: M&P SW1100CP Drop Point Silver/Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001446
- Mfr. No.: 1084307
- Color: Black/Silver
- Delivery weight: 0.104kg
- Shipping height: 239mm
- Shipping width: 25mm
- Shipping length: 68mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P SW1100 Drop Point Silver/Black Handle Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P SW1100 Drop Point Kniv](#)

M&P SW1100 Drop Point Silver/Black Handle Safety Instruction Guide

Introduction

Thank you for choosing the M&P SW1100 Drop Point Knife. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual carefully before use to understand the safety precautions and proper handling techniques.

General Safety Guidelines

- Always use the knife in a welllit area to ensure visibility and control.
- Keep the knife out of reach of children and pets when not in use.
- Do not use the knife for purposes other than intended.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, do not attempt to repair it yourself. Contact a professional for repairs.
- Always cut away from your body and keep fingers clear of the blade.
- Store the knife in a safe place, preferably in a sheath or with a protective cover.
- Ensure the knife is clean and dry before storage to prevent corrosion.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always handle the blade with care; the blade is sharp and can cause injury.
 - Avoid using excessive force when cutting; let the blade do the work.
- **Lock Mechanism:**
 - Ensure the frame lock is fully engaged before use to prevent accidental closure.
 - Do not force the blade open if it is stuck; check for obstructions.
- **Thumbstuds and Flipper:**
 - Use the dual thumbstuds and finger flipper properly to open the blade.
 - Practice opening the knife in a controlled environment before using it in the field.
- **Lanyard Hole:**
 - If using a lanyard, ensure it is securely attached to prevent accidental drops.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your thumb to push the thumbstud or the finger flipper to open the blade.
- Ensure the blade is fully extended and locked in place before use.

2. Cutting Technique:

- Position the item being cut securely on a stable surface.
- Hold the knife at a safe angle and apply gentle pressure to cut through materials.
- Maintain control of the knife at all times during use.

3. Cleaning and Maintenance:

- After use, clean the blade with a soft cloth to remove any debris.
- For tougher stains, use mild soap and water, then dry thoroughly.
- Regularly lubricate the pivot point with a suitable knife oil to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly at the end of its life cycle.
- If the knife is damaged beyond repair, consider recycling the metal components where possible.
- Follow local regulations regarding the disposal of sharp objects to prevent injury.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P SW1100 Drop Point Knife, please reach out to the appropriate EU-based contact for assistance.

Conclusion

By following these safety instructions, you can ensure a safer experience while using your M&P SW1100 Drop Point Knife. Always prioritize safety and adhere to the guidelines provided to prevent accidents and injuries. Thank you for your attention to these important safety measures.

Säkerhetsinstruktioner för M&P SW1100 Drop Point Kniv

Introduktion

Tack för att du valt M&P SW1100 Drop Point kniven. Denna manual ger viktig information om säker användning och underhåll av produkten. Vänligen läs dessa instruktioner noggrant innan du använder kniven för att säkerställa säkerhet och korrekt användning.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och se till att den är i gott skick innan användning.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för tecken på slitage eller skador.
- Använd kniven endast för avsedda ändamål och följ alltid instruktionerna för användning.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med båda händerna för att säkerställa stabilitet.
- Se till att knivbladet är helt utfällt innan du använder det.
- Undvik att använda kniven i närheten av brännbara material.
- Skär alltid bort från kroppen och håll händerna borta från bladet.
- Använd skyddshandskar om nödvändigt för att förhindra skador.
- Förvara kniven på en säker plats när den inte används, helst i ett fodral.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd tumknappen eller fingerflippern för att fälla ut knivbladet. Se till att bladet är helt utfällt och låst på plats innan användning.
2. **Användning:** Håll kniven i en bekväm och säker position. Använd den för att skära, skrapa eller utföra andra uppgifter som kräver ett knivblad.
3. **Stäng kniven:** För att stänga kniven, tryck på ramlåset och fäll tillbaka bladet försiktigt. Se till att fingrarna är borta från bladets väg.
4. **Rengöring:** Torka av kniven med en ren, torr trasa efter varje användning för att förhindra rost och slitage.
5. **Underhåll:** Smörj knivens gångjärn regelbundet med ett lämpligt smörjmedel för att säkerställa smidig funktion.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfall. Följ lokala riktlinjer för avfallshantering av vassa föremål.
- Om kniven är skadad eller inte längre säker att använda, överväg att lämna den till en återvinningsstation som hanterar vassa föremål.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsinquiries relaterade till M&P SW1100 Drop Point kniven, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare service.

Vi tackar för att du valt M&P SW1100 Drop Point kniven och önskar dig en säker och nöjd användning!