

SW1101 Drop Point Rubberized Black Handle - SW1101CP Drop Point Rubberized Black Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Textured Aluminum Handle
- Dual Thumbstuds
- Finger Flipper
- Liner Lock
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SW1101CP Drop Point Rubberized Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001448
- Mfr. No.: 1084309
- Color: Black
- Delivery weight: 0.132kg
- Shipping height: 28mm
- Shipping width: 80mm
- Shipping length: 75mm
- UPC: 661120413349

Table of Contents

- [Startpage](#)
- [English: M&P SW1101 Drop Point Rubberized Black Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P SW1101 Drop Point Gummibelagt Svart Handtag](#)

M&P SW1101 Drop Point Rubberized Black Handle Safety Instructions

Introduction

Thank you for choosing the M&P SW1101 Drop Point Rubberized Black Handle. This product is designed with safety and performance in mind. Please read this safety instruction guide carefully to ensure safe and effective use of your knife.

General Safety Guidelines

- Always use the knife in a safe and responsible manner.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage or defects before use.
- Do not use the knife for purposes other than intended.
- Always cut away from your body and keep fingers clear of the blade.
- Store the knife in a secure location when not in use.

Specific Safety Precautions for Use

- Ensure the blade is locked in place before use.
- Use the finger flipper or dual thumbstuds to open the knife safely.
- Avoid using excessive force when cutting; let the blade do the work.
- Do not attempt to catch the knife if it slips from your hand.
- If the knife becomes dull, sharpen it before further use.
- Do not expose the knife to extreme temperatures or moisture.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the dual thumbstuds or finger flipper to open the knife.
- Ensure the blade locks into place securely.

2. Using the Knife:

- Hold the knife firmly by the rubberized textured aluminum handle.
- Position the blade at the desired cutting angle.
- Cut away from your body and keep your other hand clear of the blade.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully closed and locked before storing.

4. Storing the Knife:

- Store the knife in a safe location, preferably in a sheath or clam pack.
- Avoid placing heavy objects on top of the knife.

Disposal Instructions

- Dispose of the knife responsibly.
- If the knife is damaged or no longer functional, consider recycling the metal parts where applicable.
- Follow local regulations for the disposal of sharp objects to ensure safety.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the manufacturer's contact details provided with your product packaging.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy using your M&P SW1101 Drop Point Rubberized Black Handle safely and effectively!

Säkerhetsinstruktioner för M&P SW1101

Drop Point Gummibelagt Svart Handtag

Introduktion

Tack för att du valt M&P SW1101 Drop Point med gummibelagt svart handtag. Denna produkt är designad för att ge säker och effektiv användning. För att säkerställa din och andras säkerhet, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallande av produkter via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med spetsen bort från kroppen.
- Använd kniven på en stabil yta för att undvika olyckor.
- Undvik att använda kniven för ändamål som inte är avsedda, såsom att skära genom hårda material.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.
- Stäng alltid kniven efter användning och förvara den på en säker plats.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tumknappen eller använd fingerflippern.
- Kontrollera att liner lock är korrekt låst innan du använder kniven.
- För att stänga kniven, tryck på liner lock och vik ner bladet försiktigt.
- För att fästa fickklämman, skruva fast den på önskad plats på handtaget.
- Använd snoddhålet för att fästa en snodd eller rem för extra säkerhet.

Avfallshanteringsinstruktioner

- När kniven inte längre är i bruk, se till att den är ordentligt stängd.
- Kasta produkten på ett miljövänligt sätt, i enlighet med lokala avfallsbestämmelser.
- Undvik att slänga kniven i vanliga hushållsavfall; kontrollera om det finns särskilda insamlingsprogram för metallavfall.

Kontaktinformation för vidare support

För frågor eller ytterligare information om produkten, vänligen kontakta tillverkaren eller återförsäljaren. Se till att ha produktens serienummer och inköpsinformation tillgänglig för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Vi önskar dig en säker och trevlig upplevelse med din M&P SW1101 Drop Point kniv.