

SW1102TS Tanto Point Rubberized Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Textured Aluminum Handle
- Dual Thumbstuds
- Finger Flipper
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P SW1102TS Tanto Point Rubberized Black Handle
- Manufacturer: M&P
- Product no.: EU1001449
- Mfr. No.: 1084310
- Color: Black
- Delivery weight: 0.136kg
- Shipping height: 24mm
- Shipping width: 37mm
- Shipping length: 88mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P SW1102TS Tanto Point Rubberized Black Handle Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P SW1102TS Tanto Point Gummibelagd Svart Handtag](#)

M&P SW1102TS Tanto Point Rubberized Black Handle Safety Instruction Guide

Introduction

Thank you for choosing the M&P SW1102TS Tanto Point Rubberized Black Handle. This guide provides essential safety information and instructions for the proper use and maintenance of your knife. Please read this guide carefully to ensure safe handling and enjoyment of your product.

General Safety Guidelines

- Always handle the knife with care to prevent injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- Do not use the knife for purposes other than its intended use.
- Store the knife in a safe place when not in use, ensuring the blade is protected.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that your hands are dry before handling the knife to prevent slipping.
- Use the knife on a stable surface to minimize the risk of accidents.
- Always cut away from your body to avoid injury.
- Avoid using excessive force when cutting; let the blade do the work.
- Be cautious of the blade's sharpness; always assume it is sharp.
- Do not attempt to catch the knife if it slips from your hand.
- If using the knife in a crowded area, ensure that others are at a safe distance.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the dual thumbstuds or finger flipper to open the knife.
- Ensure that the blade is fully extended and locked in place.

2. Using the Knife:

- Hold the knife firmly by the rubberized textured aluminum handle.
- Position your fingers away from the blade when making cuts.
- When finished, close the knife using the liner lock mechanism to ensure safety.

3. Cleaning and Maintenance:

- Clean the blade with a damp cloth after use to remove any debris.
- Dry the knife thoroughly to prevent rusting.
- Regularly check the locking mechanism to ensure it is functioning correctly.

4. Storage:

- Store the knife in a designated knife sheath or a safe location.
- Avoid exposing the knife to extreme temperatures or moisture.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged beyond repair, wrap it securely to prevent injury during disposal.
- Consider recycling options for the metal components where applicable.

Contact Information for Further Support

For any safety inquiries or further support, please reach out to your local M&P representative or authorized dealer. Always ensure that you have the latest safety information and updates regarding your product.

Thank you for following these safety guidelines. Enjoy your M&P SW1102TS Tanto Point Rubberized Black Handle responsibly!

Säkerhetsinstruktioner för M&P SW1102TS Tanto Point Gummibelagd Svart Handtag

Introduktion

Tack för att du valt M&P SW1102TS Tanto Point med gummibelagd svart handtag. Denna produkt är designad för att ge hög kvalitet och säkerhet. För att säkerställa en säker användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna Säkerhetsriktlinjer

- Använd produkten endast för avsett syfte.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella skador eller farliga situationer till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika Säkerhetsåtgärder för Användning

- Använd alltid kniven med försiktighet och undvik att rikta den mot dig själv eller andra.
- Använd skyddshandskar om du har känslig hud eller om du hanterar produkten under längre perioder.
- Förvara kniven på en säker plats när den inte används, och använd alltid fickklämman för att fästa den på din klädsel för att förhindra olyckor.
- Undvik att använda kniven för uppgifter som den inte är avsedd för, såsom att öppna burkar eller som en skruvmejsel.

Instruktioner för Installation och Användning

1. **Öppna kniven:** Använd tummknappen eller fingerflippern för att fälla ut bladet.
2. **Lås bladet:** Se till att liner locken är korrekt på plats innan du använder kniven.
3. **Användning:** Använd kniven på en stabil yta och se till att ha kontroll över den under hela användningen.
4. **Stäng kniven:** Tryck på liner locken för att fälla tillbaka bladet när du är färdig med användningen.

Avfallshantering

- Kasta inte produkten i hushållsavfall. Följ lokala riktlinjer för avfallshantering.
- Om produkten är skadad eller inte längre används, se till att den hanteras på ett säkert sätt för att förhindra olyckor.

Kontaktinformation för Ytterligare Stöd

För frågor eller ytterligare information om säkerhet och användning av M&P SW1102TS, vänligen kontakta vårt supportteam via de angivna kontaktkanalerna i produktens förpackning eller på vår officiella webbplats.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din M&P SW1102TS Tanto Point med gummibelagd svart handtag. Tack för att du bidrar till en säker användning av våra produkter.