

SW1102TS Tanto Point Rubberized Black Handle - M&P

SW1102TSCP Tanto Point Rubberized Black Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Rubberized Textured Aluminum Handle
- Dual Thumbstuds
- Finger Flipper
- Liner Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P SW1102TSCP Tanto Point Rubberized Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001450
- Mfr. No.: 1084311
- Color: Black
- Delivery weight: 0.159kg
- Shipping height: 28mm
- Shipping width: 80mm
- Shipping length: 88mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for M&P SW1102TS Tanto Point Rubberized Black Handle](#)
- [Svenska: Säkerhetsanvisningar för M&P SW1102TS Tanto Point Gummibelagt Svart Handtag](#)

Safety Instruction Guide for M&P SW1102TS Tanto Point Rubberized Black Handle

Introduction

Thank you for choosing the M&P SW1102TS Tanto Point Rubberized Black Handle. This guide provides essential safety instructions and precautions to ensure your safe and effective use of this product. Please read all sections carefully before using the knife.

General Safety Guidelines

- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- Do not use the knife for purposes other than its intended use.
- Ensure the knife is stored securely when not in use to prevent accidents.
- If you notice any irregularities or issues with the knife, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers and other body parts clear of the blade.
- Use the knife on a stable surface to prevent slips and accidents.
- Ensure that the blade is fully deployed and locked before use.
- Avoid using excessive force when cutting; let the blade do the work.
- Be cautious when closing the knife; ensure fingers are clear of the blade.
- Do not attempt to modify or disassemble the knife.

Instructions for Installation and Usage

1. Opening the Blade:

- Use the dual thumb studs or finger flipper to open the blade.
- Ensure that the blade locks into place securely before use.

2. Using the Knife:

- Hold the handle firmly with a comfortable grip.
- Position the blade at the desired angle for cutting.
- Perform cuts with controlled motions, maintaining focus on the task.

3. Closing the Blade:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring fingers are clear of the blade path.

4. Storing the Knife:

- Store the knife in a safe location, preferably in a protective case or sheath.
- Ensure the knife is not accessible to children or unauthorized users.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.

- If the knife is damaged or no longer functional, consider recycling the materials if possible.
- Ensure that the blade is covered or secured to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P SW1102TS Tanto Point Rubberized Black Handle, please reach out to the designated EUbased contact point provided with your product packaging.

Conclusion

Your safety is our priority. By following these guidelines and precautions, you can ensure a safe and enjoyable experience with your M&P SW1102TS Tanto Point Rubberized Black Handle. Thank you for your attention to these safety instructions.

Säkerhetsanvisningar för M&P SW1102TS Tanto Point Gummibelagt Svart Handtag

Introduktion

Tack för att du valt M&P SW1102TS Tanto Point med gummibelagt svart handtag. Denna produkt är designad för att ge en säker och effektiv användning. För att säkerställa en trygg upplevelse, vänligen läs och följ dessa säkerhetsanvisningar noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Använd kniven endast för avsett syfte.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med båda händerna för bättre kontroll.
- Håll fingerskyddet på plats när kniven används.
- Se till att knivbladet är ordentligt låst innan användning.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Använd kniven i ett väl upplyst område för att förbättra sikten.

Instruktioner för installation och användning

1. Öppna förpackningen:

- Ta försiktigt bort kniven från förpackningen.
- Kontrollera att alla delar är intakta och i gott skick.

2. Fälla ut kniven:

- Använd tumknappen för att fälla ut bladet.
- Kontrollera att bladet är ordentligt låst i öppet läge.

3. Användning av kniven:

- Håll kniven i ett fast grepp.
- Använd kniven med en kontrollerad rörelse för att undvika olyckor.
- Stäng kniven genom att trycka på tumknappen och fälla tillbaka bladet.

4. Förvaring:

- Förvara kniven på en säker plats, borta från barn.
- Använd fickklämman för att fästa kniven på bältet eller i väskan för säker transport.

Avfallshanteringsanvisningar

- Kasta inte kniven i hushållsavfallet.
- Följ lokala riktlinjer för avfallshantering av skarpa föremål.
- Om kniven är trasig eller skadad, se till att den förvaras på ett säkert sätt tills den kan kasseras korrekt.

Kontaktinformation för vidare support

Vid frågor eller för mer information om säkerhetsanvisningar, vänligen kontakta den lokala återförsäljaren eller tillverkaren.

Genom att följa dessa säkerhetsanvisningar kan du säkerställa en trygg och effektiv användning av din M&P SW1102TS Tanto Point kniv. Tack för att du bidrar till en säker användning av våra produkter!