

S&W Karambit Fixed Blade - S&W Karambit FB

- 8Cr13MoV Stonewashed High Carbon S.S. Blade Glass Filled Nylon Slab Handle
- Full Tang
- Lanyard Hole
- Breakaway Neck Chain
- Nylon Fiber Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Karambit FB
- Manufacturer: M&P
- Product no.: EU1001456
- Mfr. No.: SW995
- Color: Black
- Delivery weight: 0.286kg
- Shipping height: 36mm
- Shipping width: 94mm
- Shipping length: 90mm
- EAN/UPC: 28634992331

Table of Contents

- [Startpage](#)
- [English: M&P S&W Karambit Fixed Blade Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P S&W Karambit Fixed Blade](#)

M&P S&W Karambit Fixed Blade Safety Instruction Guide

Introduction

Thank you for choosing the M&P S&W Karambit Fixed Blade. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure you are in a safe environment free from distractions when using the knife.
- Regularly inspect the knife for any signs of damage or wear.
- Follow all local laws and regulations regarding knife ownership and use.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface when using the knife.
- **Grip:** Ensure a secure grip on the handle to prevent slipping during use.
- **Direction of Cut:** Cut away from your body and keep your fingers clear of the cutting path.
- **Storage:** Store the knife in its sheath when not in use to prevent accidental injuries.
- **Sheath Use:** Ensure the knife is fully inserted into the sheath before storing it.
- **Lanyard Use:** Utilize the lanyard hole and breakaway neck chain for secure carrying, but ensure it does not get caught in moving parts or machinery.

Instructions for Installation and Usage

- **Using the Knife:**
 1. Remove the knife from its sheath by grasping the handle firmly.
 2. Ensure your cutting surface is stable and free of obstacles.
 3. Hold the knife with a secure grip, ensuring your fingers are away from the blade.
 4. Make cuts using controlled motions, always cutting away from your body.
- **Cleaning the Knife:**
 1. Clean the blade after each use with warm, soapy water.
 2. Dry the blade thoroughly to prevent rust.
 3. Avoid using abrasive materials that may damage the blade finish.
- **Sharpening the Blade:**
 1. Use a proper sharpening tool designed for high carbon stainless steel.
 2. Follow the manufacturer's instructions for sharpening techniques.
 3. Always sharpen the blade away from your body and ensure a stable grip.

Disposal Instructions

- When disposing of the knife, ensure it is rendered unusable to prevent accidents.
- Use appropriate waste disposal methods in accordance with local regulations.
- If the knife is damaged and cannot be repaired, consider recycling the materials where suitable.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the M&P S&W Karambit Fixed Blade, please refer to the product packaging or your retailer for contact details.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P S&W Karambit Fixed Blade. Always prioritize safety and responsibility when handling knives. Thank you for your attention and safe use!

Säkerhetsinstruktioner för M&P S&W Karambit Fixed Blade

Introduktion

Tack för att du valt M&P S&W Karambit Fixed Blade. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för användning av produkten. Vänligen läs noggrant igenom dessa instruktioner för att säkerställa en säker och effektiv användning av din kniv.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och respekt för dess skärpa.
- Förvara kniven på en säker plats, utom räckhåll för barn och andra sårbara personer.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsedd användning.
- Var medveten om din omgivning när du använder kniven för att undvika olyckor.

Specifika säkerhetsåtgärder vid användning

- Använd skyddshandskar om nödvändigt för att förhindra skador.
- Håll kniven borta från ansiktet och kroppen när du skär.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Använd alltid en skärbräda eller liknande underlag när du skär.
- Rengör kniven efter varje användning för att hålla den i gott skick.

Instruktioner för installation och användning

- För att fästa halskedjan, trä den genom nyckelhålet på handtaget.
- Se till att kniven är ordentligt säkrad i nylonfiberhölstret när den inte används.
- För att använda kniven, ta den ur hölstret och håll den med ett fast grepp.
- Använd kniven med en kontrollerad rörelse för att undvika skador.
- Förvara alltid kniven i hölstret när den inte används.

Avfallshanteringsinstruktioner

- Kasta inte kniven eller dess delar i vanliga sopor.
- Om kniven är skadad eller inte längre säker att använda, följ lokala riktlinjer för farligt avfall för att kassera den på ett säkert sätt.
- Återvinn materialet där det är möjligt, i enlighet med lokala återvinningsföreskrifter.

Kontaktinformation för ytterligare support

För frågor om säkerhet, användning eller underhåll av M&P S&W Karambit Fixed Blade, vänligen kontakta den lokala återförsäljaren eller tillverkaren för mer information.

Viktig information

- Rapportera osäkra produkter och olyckor till myndigheterna.
- Kontrollera regelbundet för återkallelseuppdateringar på EU:s Safety Gateplattform.

Genom att följa dessa säkerhetsinstruktioner kan du bidra till en säker och effektiv användning av din M&P S&W Karambit Fixed Blade. Tack för att du prioriterar säkerheten!