

MPM2.0SA20 - M&P M2.0™ Clip Point Blade Black/Aluminum Handle

- 4034 Black Oxide Coated High Carbon S.S. Blade Aluminum w/Rubber Inserts Handle
- Finger Actuator
- Secondary Lock Auto Locks When Opened
- Thin Profile
- Pocket Clip with Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPM2.0SA20 - M&P M2.0™ Clip Point Blade Black/Aluminum Handle
- Manufacturer: M&P
- Product no.: EU1001459
- Mfr. No.: 1084316
- Color: Black/Silver
- Delivery weight: 0.118kg
- Shipping height: 24mm
- Shipping width: 36mm
- Shipping length: 95mm
- UPC: 661120413714

Table of Contents

- [Startpage](#)
- [English: M&P MPM2.0SA20 Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPM2.0SA20](#)

M&P MPM2.0SA20 Safety Instruction Guide

Introduction

Thank you for choosing the M&P MPM2.0SA20 M&P M2.0™ Clip Point Blade with a Black/Aluminum Handle. This safety instruction guide is designed to ensure the safe and effective use of your product. Please read this guide thoroughly before using the knife to minimize risks and enhance your experience.

General Safety Guidelines

- Always use the knife in a safe and responsible manner.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use for any signs of damage or wear.
- Do not use the knife for purposes other than its intended use.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Blade Safety:** The blade is sharp. Handle with care to avoid cuts or injuries.
- **Finger Actuator:** Ensure your fingers are clear of the blade path when using the finger actuator.
- **Secondary Lock:** Always engage the secondary lock when the knife is not in use to prevent accidental opening.
- **Storage:** Store the knife in a safe place, preferably in a sheath or a designated storage area.
- **DistractionFree Environment:** Use the knife in a welllit area free from distractions to maintain focus.

Instructions for Installation and Usage

Installation

1. **Inspect the Knife:** Check for any visible damage or defects before use.
2. **Secure the Blade:** Ensure the blade is locked in place using the secondary lock before handling.

Usage

1. **Opening the Knife:**
 - Use the finger actuator to open the blade.
 - Ensure your fingers are clear of the blade's path during this process.
2. **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Use the knife only for cutting tasks; do not apply excessive force.
 - Be mindful of your surroundings and ensure that no one is in the immediate vicinity when using the knife.
3. **Closing the Knife:**
 - After use, carefully close the knife using the finger actuator.
 - Engage the secondary lock to secure the blade in the closed position.

Disposal Instructions

- Dispose of the knife in accordance with local regulations regarding sharp objects.
- If the knife is damaged or no longer functional, consider recycling the materials where applicable.
- Always ensure that the blade is safely covered or secured before disposal to prevent injury.

Contact Information for Further Support

For any inquiries or concerns regarding the M&P MPM2.0SA20, please refer to the manufacturer's official website or customer support channels. Ensure you have the product details available for reference.

By following these safety instructions, you can enjoy the use of your M&P MPM2.0SA20 knife while minimizing risks and ensuring safety for yourself and others. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P MPM2.0SA20

Introduktion

Tack för att du har valt M&P MPM2.0SA20 M&P M2.0™ Clip Point Blade med svart/aluminiumhandtag. Denna produkt är designad för att ge hög prestanda och säkerhet. För att säkerställa säker och korrekt användning, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten på ett säkert och ansvarsfullt sätt.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Inspektera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Kontrollera EU:s Safety Gateplattform för uppdateringar om återkallelser.

Specifika säkerhetsåtgärder vid användning

- Använd alltid produkten i en säker miljö.
- Håll fingrarna borta från bladets kant under användning.
- Använd fingeraktiveraren korrekt för att undvika oavsiktlig aktivering.
- Se till att det sekundära låset är aktiverat när produkten inte används.
- Använd fickklämman för att säkert fästa produkten när den inte är i bruk.

Instruktioner för installation och användning

1. Installation av fickklämma:

- Fäst fickklämman på önskad plats på handtaget.
- Kontrollera att klämman sitter ordentligt fast.

2. Användning av produkten:

- Aktivera produkten genom att trycka på fingeraktiveraren.
- Använd produkten med försiktighet, och se till att hålla den borta från ansiktet och kroppen.
- När du är klar, stäng produkten genom att aktivera det sekundära låset.

3. Underhåll:

- Rengör bladet regelbundet med en mjuk trasa.
- Smörj gångjärnet vid behov för att säkerställa smidig funktion.

Avfallsinstruktioner

- Kasta inte produkten i hushållsavfallet.
- Återvinn materialet i enlighet med lokala avfallsföreskrifter.
- Kontakta din lokala avfallshantering för information om korrekt avfallshantering.

Kontaktinformation för vidare support

För frågor eller support relaterade till säkerhet och användning, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer till hands för snabbare hjälp.