

Clip Point Blade Black Inlay Handle - MPM2.0DA30 - M&P M2.0™ Clip Point Black Handle

- AUS-8 Black Oxide Coated High Carbon S.S. Blade Aluminum Handle
- Dual Action: Spring Assisted or Manual Opening
- Finger Actuator
- Glass Breaker
- Pocket Clip with Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPM2.0DA30 - M&P M2.0™ Clip Point Black Handle
- Manufacturer: M&P
- Product no.: EU1001461
- Mfr. No.: 1084318
- Color: Black
- Delivery weight: 0.118kg
- Shipping height: 24mm
- Shipping width: 36mm
- Shipping length: 95mm
- UPC: 661120413738

Table of Contents

- [Startpage](#)
- [English: M&P Clip Point Blade Black Inlay Handle MPM2.0DA30 Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Point Blade Black Inlay Handle MPM2.0DA30](#)

M&P Clip Point Blade Black Inlay Handle MPM2.0DA30 Safety Instruction Guide

Introduction

Thank you for choosing the M&P Clip Point Blade Black Inlay Handle MPM2.0DA30. This guide provides essential safety instructions and usage guidelines to ensure your safety and the longevity of your product. Please read this document carefully before using the knife.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage or defects before use.
- Use the knife only for its intended purpose.
- Do not use the knife if it is damaged or malfunctioning.
- Always store the knife in a safe place when not in use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Be cautious when opening the knife, especially when using the springassisted feature.
- Ensure that your fingers are clear of the blade path when opening or closing the knife.
- Avoid using the knife in wet or slippery conditions to prevent loss of grip.
- Do not attempt to modify or disassemble the knife.
- Use the glass breaker feature only in emergency situations and with proper training.
- Do not use the knife for prying or as a tool for tasks it is not designed for.

Instructions for Installation and Usage

1. Opening the Knife:

- To open the knife, use the finger actuator located on the handle.
- For springassisted opening, apply gentle pressure on the actuator to deploy the blade.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Use a controlled motion to cut or slice, ensuring that your other hand is safely positioned away from the blade.

3. Closing the Knife:

- To close the knife, press the actuator while carefully folding the blade back into the handle.
- Ensure that your fingers are clear of the blade path during this process.

4. Storing the Knife:

- Store the knife in a secure location, preferably in a sheath or pouch.
- Avoid placing the knife in a drawer where it could accidentally open.

Disposal Instructions

- When the knife reaches the end of its life cycle, dispose of it responsibly.
- Check local regulations for the proper disposal of knives and sharp objects.
- Consider recycling the aluminum handle if applicable, following local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the safety or usage of the M&P Clip Point Blade, please refer to the contact information provided with your product packaging or visit the official M&P website for support.

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P Clip Point Blade Black Inlay Handle MPM2.0DA30. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P Clip Point Blade Black Inlay Handle MPM2.0DA30

Introduktion

Tack för att du har valt M&P Clip Point Blade Black Inlay Handle MPM2.0DA30. Denna säkerhetsinstruktionsguide är utformad för att säkerställa säker användning av produkten. Vänligen läs noggrant igenom denna guide innan du använder produkten för att minimera risker och maximera säkerheten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara personer.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller incidenter till berörda myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil och säker yta.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att öppna burkar eller som skruvmejsel.
- Var försiktig när du öppnar och stänger kniven, särskilt med fjädrad assistans.
- Använd fingeraktiveraren på ett säkert sätt för att undvika oavsiktlig öppning.
- Förvara kniven i ett säkert läge när den inte används.

Instruktioner för installation och användning

1. Öppning av kniven:

- För att öppna kniven, tryck på fingeraktiveraren. Fjädrad assistans kommer att hjälpa till att öppna bladet.
- För manuell öppning, använd fingrarna för att försiktigt dra ut bladet tills det är helt öppet.

2. Stängning av kniven:

- Tryck på fingeraktiveraren för att frigöra bladet.
- Vik bladet tillbaka in i handtaget tills det är helt stängt.

3. Användning av fickklämma:

- Fäst fickklämman på bältet eller i fickan för enkel åtkomst.
- Använd snoddhålet för att fästa en snodd eller rem om så önskas.

Avfallshanteringsinstruktioner

- Kassera kniven på ett säkert sätt när den inte längre är användbar.
- Följ lokala riktlinjer för avfallshantering och återvinning.
- Undvik att kasta kniven i allmänna avfallskärl för att förhindra skador på andra.

Kontaktinformation för vidare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta tillverkaren eller din lokala återförsäljare. Se till att ha produktens modellnummer till hands för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och säker användning av M&P Clip Point Blade Black Inlay Handle MPM2.0DA30. Tack för att du prioriterar säkerheten!