

MPSHF1 Clip Point Blade Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Glass Filled Nylon Handle
- Full Tang
- Thumb Jiming
- Thin Profile
- Pocket Clip, Lanyard Hole and Nylon Fiber Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: MPSHF1 Clip Point Blade Black Handle
- Manufacturer: M&P
- Product no.: EU1001463
- Mfr. No.: 1084320
- Color: Black
- Delivery weight: 0.159kg
- Shipping height: 30mm
- Shipping width: 55mm
- Shipping length: 85mm
- UPC: 661120413752

Table of Contents

- [Startpage](#)
- [English: M&P MPSHF1 Clip Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPSHF1 Clip Point Blade](#)

M&P MPSHF1 Clip Point Blade Safety Instructions

Introduction

Thank you for choosing the M&P MPSHF1 Clip Point Blade with a black handle. This guide provides important safety instructions to ensure the safe use of your knife. Please read this document carefully to understand how to use, maintain, and dispose of your knife safely.

General Safety Guidelines

- Always handle knives with care.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage before use. Do not use if damaged.
- Store the knife in a safe place, preferably in its sheath.
- Ensure you are in a safe environment when using the knife, away from flammable materials.
- Use the knife only for its intended purpose. Do not use it for prying or as a screwdriver.
- Always cut away from your body and keep your fingers clear of the blade.
- Be aware of your surroundings and avoid distractions while using the knife.

Specific Safety Precautions for Use

- **Blade Safety:** The blade is sharp and can cause injury. Handle with caution.
- **Full Tang Design:** The full tang construction provides strength but requires careful handling to avoid accidents.
- **Thumb Jimbing:** The thumb jimping feature allows for better control. Use it for a secure grip while cutting.
- **Thin Profile:** The thin profile of the blade may make it easier to slip. Maintain a firm grip at all times.
- **Pocket Clip and Lanyard Hole:** Use the pocket clip or lanyard hole to secure the knife when not in use, preventing accidental drops.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from the packaging, ensuring not to touch the blade edge.
2. **Inspection:** Check the knife for any visible defects. Ensure the blade is securely attached to the handle.
3. **Usage:**
 - Hold the knife firmly by the handle.
 - Use the thumb jimping for added grip and control.
 - When cutting, position the item securely and cut away from your body.
 - After use, clean the blade with a soft cloth and store it in the sheath.
4. **Maintenance:** Regularly check the blade for sharpness. Sharpen as needed using a proper knife sharpener.
5. **Storage:** Always store the knife in its nylon fiber sheath when not in use to prevent accidental injuries.

Disposal Instructions

- When disposing of the knife, ensure it is securely wrapped to prevent injury to waste handlers.
- Check local regulations for proper disposal methods for knives.
- Consider recycling if applicable, but ensure the blade is safely covered.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P MPSHF1 Clip Point Blade, please reach out to the designated EU contact point for assistance.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your M&P MPSHF1 Clip Point Blade. Thank you for prioritizing safety!

Säkerhetsinstruktioner för M&P MPSHF1 Clip Point Blade

Introduktion

Tack för att du valt M&P MPSHF1 Clip Point Blade med svart handtag. Denna produkt är designad för att ge en säker och effektiv användning. Vänligen läs dessa säkerhetsinstruktioner noggrant innan du använder produkten för att säkerställa säkerheten för dig själv och andra.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt anvisningarna för att undvika olyckor.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Inspektera produkten regelbundet för skador eller slitage.
- Vid användning av kniven, se till att du har ett fast grepp och en stabil arbetsyta.
- Rapportera eventuella skador eller defekter på produkten till försäljaren.

Specifika säkerhetsåtgärder för användning

- Använd aldrig kniven för att skära material som inte är avsett för detta ändamål.
- Var alltid medveten om din omgivning när du använder kniven för att undvika skador på dig själv eller andra.
- Förvara kniven i det medföljande nylonfiberfodralet när den inte används.
- Använd skyddshandskar om nödvändigt för att skydda händerna.
- Var försiktig med tumsjimping för att förhindra att fingrarna glider av bladet.

Instruktioner för installation och användning

1. **Öppna förpackningen:** Ta försiktigt bort kniven från förpackningen.
2. **Inspektera kniven:** Kontrollera att kniven är i gott skick och att inga delar saknas.
3. **Användning:**
 - Håll kniven med ett fast grepp.
 - Skär alltid bort från kroppen och andra personer.
 - Använd kniven på en stabil yta.
4. **Förvaring:** Efter användning, rengör kniven och förvara den i det medföljande nylonfiberfodralet för att skydda bladet och förhindra olyckor.

Avfallshantering

- Kassera kniven på ett säkert sätt om den är skadad eller inte längre användbar.
- Följ lokala riktlinjer för avfallshantering för metallprodukter.
- Använd ett skyddande fodral eller emballage när du kasserar kniven för att förhindra skador på andra.

Kontaktinformation för vidare support

För frågor eller ytterligare information om produkten, vänligen kontakta din återförsäljare eller den tillverkare som anges på förpackningen. För säkerhetsfrågor kan du även rapportera till relevanta myndigheter.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!