

MPSHF2 Clip Point Blade Black Handle

- 8Cr13MoV Ti-Nitride Coated High Carbon S.S. Blade Glass Filled Nylon Handle
- Full Tang
- Thumb Jimping
- Thin Profile
- Lanyard Hole, Belt Loop and Nylon Fiber Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: M&P MPSHF2 Clip Point Blade Black Handle
- Manufacturer: M&P
- Product no.: EU1001465
- Mfr. No.: 1084322
- Color: Black
- Delivery weight: 0.249kg
- Shipping height: 28mm
- Shipping width: 60mm
- Shipping length: 83mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P MPSHF2 Clip Point Blade Black Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPSHF2 Clip Point Blade Black Handle](#)

M&P MPSHF2 Clip Point Blade Black Handle Safety Instructions

Introduction

Thank you for choosing the M&P MPSHF2 Clip Point Blade with a Black Handle. This product is designed for durability and ease of use. However, to ensure your safety and the safety of others, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the knife in a safe and responsible manner.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage or defects before use.
- Do not use the knife for any purpose other than its intended use.
- Be aware of your surroundings when using the knife to avoid accidents.
- Store the knife in a safe place when not in use, preferably in its sheath.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Care:**
 - Keep the blade clean and dry to prevent rust and corrosion.
 - Avoid cutting hard surfaces that may damage the blade.
- **Handling:**
 - Always cut away from your body to minimize the risk of injury.
 - Use a stable cutting surface to ensure control while cutting.
- **Sheath Usage:**
 - Always store the knife in its nylon fiber sheath when not in use.
 - Ensure the blade is securely sheathed to prevent accidental cuts.
- **Lanyard Hole and Belt Loop:**
 - Use the lanyard hole or belt loop to secure the knife when not in use, preventing accidental drops.
- **Thumb Jimping:**
 - Utilize the thumb jimping feature for a better grip and control when using the knife.

Instructions for Installation and Usage

1. **Unboxing:**
 - Carefully remove the knife from its packaging, ensuring not to cut yourself in the process.
2. **Inspection:**
 - Check the knife for any visible defects or damage. If any are found, do not use the knife and

contact customer support.

3. Usage:

- Hold the knife firmly by the handle.
- Position the blade at the desired cutting angle.
- Apply even pressure while cutting, ensuring your other hand is clear of the blade path.

4. Cleaning and Maintenance:

- After use, clean the blade with a soft cloth to remove any debris.
- Store the knife in a dry place, preferably in its sheath.

Disposal Instructions

- When disposing of the knife, ensure it is rendered unusable to prevent accidental injuries.
- Wrap the blade in a protective material (such as cardboard) before disposal.
- Dispose of the knife in accordance with local regulations for sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P MPSHF2 Clip Point Blade, please refer to the manufacturer's contact details provided with the product packaging. Ensure you have the product information ready for reference.

Thank you for prioritizing safety and responsible usage of your M&P MPSHF2 Clip Point Blade. Enjoy your product!

Säkerhetsinstruktioner för M&P MPSHF2 Clip Point Blade Black Handle

Introduktion

Tack för att du har valt M&P MPSHF2 Clip Point Blade Black Handle. Denna säkerhetsinstruktionsguide är utformad för att säkerställa en trygg och säker användning av din kniv. Vänligen läs igenom alla instruktioner noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och håll den utom räckhåll för barn.
- Kontrollera alltid knivens skick innan användning för att säkerställa att den är fri från skador.
- Förvara kniven på en säker plats när den inte används, helst i det medföljande nylonfiberfodralet.
- Rapportera eventuella skador eller defekter på produkten till återförsäljaren.
- Håll kniven ren och torr för att förlänga dess livslängd.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven med båda händerna för att säkerställa stabilitet och kontroll.
- Skär alltid bort från kroppen och använd en skärbräda för att undvika olyckor.
- Använd inte kniven för att skära material som är för hårda eller för tuffa, vilket kan skada bladet.
- Undvik att använda kniven i fuktiga miljöer för att förhindra rost på bladet.
- Om kniven används för camping eller utomhusaktiviteter, se till att den är rengjord och torkad efter användning.

Instruktioner för installation och användning

1. **Öppna kniven:** Ta försiktigt bort kniven från nylonfiberfodralet.
2. **Inspektera kniven:** Kontrollera att bladet är helt och att handtaget är fast.
3. **Användning:**
 - Håll kniven i ett fast grepp med tummen på tummjimpingen för extra kontroll.
 - Skär med en jämn och kontrollerad rörelse.
4. **Stäng kniven:** När du är klar med användningen, förvara kniven i fodralet för att undvika skador och olyckor.

Avfallshantering

- När kniven inte längre är användbar, se till att den kasseras på ett säkert sätt för att förhindra olyckor.
- Återvinn kniven om möjligt, men se till att den är säker att hantera innan du gör det.
- Följ lokala riktlinjer för avfallshantering och återvinning.

Kontaktinformation för ytterligare stöd

För frågor eller rapporter om säkerhetsproblem, vänligen kontakta din återförsäljare eller besök M&P:s officiella webbplats för mer information.

Vi tackar för att du valt M&P MPSHF2 Clip Point Blade Black Handle. Din säkerhet är viktig för oss, och vi hoppas att dessa riktlinjer hjälper dig att använda produkten på ett säkert och effektivt sätt.